



## Hardware



1 Compact controls



2 Mounting and connection



3 CAN-Bus I/O

---



## Characteristics of the compact controls

---


1.	Compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905	1 - 2
1.1	Introduction	1 - 2
1.2	Characteristics and functions	1 - 3
1.3	Software	1 - 7

# Characteristics of the compact controls

## 1 Compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905

### 1.1 Introduction

The compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905 are conceived for the application with CAN Bus. Communicate to them over the CAN Bus with the drives and the I/O bus. The CNC Control actual in the operating panel integrates. The operating panels have fully graphicable color LC displays and foil keyes with mechanical pressure point.



#### Interfaces

CAN Bus	1000kbit for CANopen Drives
CAN Bus	500kbit for I/O box bus system according to CANopen Specification
Ethernet	(TCP/Ip) RJ45
Serially	RS232, RS422
PCMCIA	e.g. for external hard disk (CNC 905 option)
USB	(CNC 905 option)

## 1.2 Characteristics and functions

### Functions of the control

- Operating system BWO real-time kernel
- Logs TCP/IP stack, CANopen stack
- Soft PLC
- Construction of a simple CNC controller in connection with soft PLC and soft NC
- BWO file server
- Programming of the control surface also PROMA
- Block-by-block reloading with larger programs
- Graphic cycle programming
- Free DLL for the implementation of own programs

### CPU data

Static RAM	512kB
Run-time memory DRAM	16MB
Flash-disk-memory for operating system and control surface	8MB
Flag memory	60kB
NC memory	193kB
Remanent flags	4096
Parameter	20000

### Programmable box bus coupler

I/O knot for input/outputs	5
with in each case	
digital inputs	64
digital outputs	64
analog inputs	2 x16bit
analog outputs	2 x16bit

## Characteristics of the compact controls

---

### 1.2 Characteristics and functions

Versions	CNC 902	CNC 903	CNC 904	CNC 905
NC channel	1	1	1	1
Axes / Spindles	4	4	8	8
Spindle in C axes operation	1	1	1	1
Linear interpolation (Axes)	3	3	3	3
Cirkular interpolation (Axes)	2	2	3	3
Screw interpolation (Axes)	2+1	2+1	2+1	2+1
Spline interpolation	-	-	•	•
Polynomial interpolation	-	-	•	•
Polar transformation	-	-	•	•
Scara transformation	-	-	•	•

Symbols: • Functions are possible  
 - Functions are not possible

#### CNC Characteristics and functions

- Tangential axis
- Axes couple, reflect and exchange
- Restarting after abort
- Feed, corners, circle and outline dynamics
- Electronic gears and Handwheel
- Polar coordinates system
- Axes simulation
- Coordinates turn, reflect and shift
- Measuring and processing cycles
- Interpolation plane selection
- Tool radius path correction
- Automatic selection of linear and circular interpol.
- Zero points / zero shift
- Outline path short programming
- Parameter calculation
- Diagnostic functions
- Graphic cycle programming
- Graphic simulation

## 1.2 Characteristics and functions

### Operating panel data

LCD display in TFT version.

Resolution 640 x 480, 256 off 4096 colours

display size with CNC 902 / CNC 904 6.4"

CNC 903 / CNC 905 10.4"

Touch screen with resolution of 1024 x1024

42 function keys, of it 15 freely shapable,

PLC keys with display on LCD display,

Operating voltage 24V

Battery buffer for the clock

### Connections

(CNC 903 / CNC 905 on separate machine operating panel)

4 Override Potentiometer

1 Handwheel (TTL level cable length 1m, +5V)

1 Key-operated switsch


1 Joystick (in place of 3 override Potentis)

# Characteristics of the compact controls

## 1.2 Characteristics and functions

Compact controls CNC 902 / CNC 904

Dimensions (B x H in mm) 277 x 227



Compact controls CNC 903 / CNC 905 with additional machine operating panel

Dimensions (B x H in mm) 328 x 310

Machine operating panel (option) 80 x 310

## 1.3 Software

### **Programming software XPLC**

XPLC actual a programming software for the compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905. The software actual on PC executably.

With XPLC all functions of the control with stored program (PLC) with the compact controls can be taken in operation.

Details in addition in this manual paragraph 4. and 5.

### **Standard interface for CNC**

The standard adaption contains a list of the free, pre-allocated and reserved flag areas.

Details in addition in this manual paragraph 6.

### **Programming software NC**


With the programming software can NC programs with the available functions in the compact controls be created. Details in addition in the NC manual.

## Characteristics of the compact controls

### 1.3 Software

#### Operating system management program WINBV

Software on a PC to controlling of the CNC.



The display of the CNC is illustrated on a PC. The control can be served then from the PC.


Thus can be implemented:

- Diagnosis locally
- On-line remote diagnostics
- Operating system care
- Data administration
- Data protection
- NC archiving

Details in addition in this manual paragraph 7.

#### Data transfer on one SERVER

Software on a PC for data transfer with the CNC.



By the CNC can be accessed the drive assemblies of a server. Several controls can be connected at a server and load NC data from the server or save on the server.



## Mounting and connection

---

2.	Mounting and connection	
2.1	Compact control CNC 902 / CNC 904	2 - 2
2.1.1	Mass and weight	2 - 2
2.1.2	Panel cutout and mounting	2 - 3
2.1.3	Plug allocation	2 - 4
2.2	Compact control CNC 903 / CNC 905	2 - 6
2.2.1	Mass and weight	2 - 6
2.2.2	Panel cutout and mounting	2 - 7
2.2.3	Plug allocation	2 - 9
2.2.4	Connections	2 - 11

## 2.1 Compact control CNC 902 / CNC 904

### 2.1.1 Mass and weight

Dimensions	(width x height)	277mm x 227mm
max. depth of the rear edge of the front plate to the rear		55mm
max. depth of the front edge of the front plate forward		25mm
Strength of the front plate		approx. 4mm
Weight		approx. 1,6kg




## 2.1.2 Mounting cut out and fixing


**Mounting cut out** 247mm x 197mm (width x height)

**Fixing** with 10 threaded bolts M4 x 8, grounding rear side M4

No.	X	Y	Nr.	X	Y
1	10,0	10,0	6	267,0	217,0
2	95,7	10,0	7	181,3	217,0
3	181,3	10,0	8	95,7	217,0
4	267,0	10,0	9	10,0	217,0
5	267,0	113,5	10	10,0	113,5






## 2.1.3 Plug contacts



St1	3-polige plug	Power supply
P1, P2	9 pin D-SUB pin-type plug	CAN1, CAN 2 - interface
P3	9 pin D-SUB pin-type plug	RS422 or RS232 interface
J14, J15, J16	Selection of the interface P3	1 with 2 bridged = RS422 (preset) 2 with 3 bridged = RS232
Jp3	8 pin socket	Connection with host over RJ45
Jp10	5 pin plug	Connection handwheel (CNC 904 option)

## 2.1.3 Plug contacts


Power supply		CAN Interface CAN 1 / CAN 2		RS422 / RS232 interface		TCP/IP Host	
3 pin plug ST1		9 pin D-SUB pin-type plug P1 / P2		9 pin D-SUB pin-type plug P3		8 pin RJ45 JP3 EtherNet (socket)	
				RS422	RS232		
1	+24V	1	-	1	-	1	OP
2	0V	2	CAN - L	2	-	2	ON
3	Screen	3	CAN - GND	3	S+	3	IP
		4	-	4	-	4	-
		5	-	5	S-	5	-
		6	-	6	-	6	IN
		7	CAN - H	7	E-	7	-
		8	-	8	E+	8	-
		9	CAN - VCC	9	-		



## 2.2 Compact control CNC 903 / CNC 905

### 2.2.1 Mass and weight

<b>Dimensions</b>	(width x height)	328mm x 310mm
max. depth of the rear edge of the front plate to the rear		55mm
Strength of the front plate	approx.	4mm
Weight	approx.	2kg




## 2.2.2 Mounting cut out and fixing

**Mounting cut out** 300mm x 282mm (width x height).

**Fixing** with 12 threaded bolts M4 x 8, grounding rear side M4

No.	X	Y	Nr.	X	Y
1	54,0	10,0	7	274,0	300,0
2	164,0	10,0	8	164,0	300,0
3	274,0	10,0	9	54,0	300,0
4	318,0	50,0	10	10,0	250,0
5	318,0	155,0	11	10,0	155,0
6	318,0	250,0	12	10,0	50,0





## Mounting and connection

### 2.2.2 Mounting cut out and fixing machine operating panel


**Mounting cut out** 50mm x 280mm (width x height).

**Fixing** with 12 threaded bolts M4 x 8, grounding threaded bolt 9

Nr.	X	Y	Nr.	X	Y
1	40,0	10,0	5	40,0	300,0
2	70,0	50,0	6	10,0	250,0
3	70,0	155,0	7	10,0	155,0
4	70,0	250,0	8	10,0	50,0






## 2.2.3 Plug contacts



JP4 / JP6	10 pin terminal strip	external potentiometers and key-operated switches
P1 / P2	9 pin D-SUB pin-type plug	CAN 1 / CAN 2 interface
P3	9 pin D-SUB pin-type plug	RS422 or RS232 interface
J14, J15 and J27, J28, J29	Selection of Interface RS422 preset	RS422 J14 J15, J27, J28, J29 open bridge1 - 2
		RS232 J27, 28 J14, J15, J29 offen Brückr 2 - 3
JP3	8 pin socket	connection with host by RJ45


## 2.2.3 Plug contacts

Power supply		CAN interface CAN 1 / CAN 2		RS422 / RS232 interface		TCP/IP Host	
3 pin plug ST1		9 pin D-SUB pin-type plug P1 / P2		9 pin D-SUB pin-type plug P3		8 pin RJ45 JP3 Ethernet (socket)	
				RS422	RS232		
1	+24V	1	-	1	-	1	OP
2	0V	2	CAN - L	2	-	2	ON
3	screen	3	CAN - GND	3	S+	3	IP
		4	-	4	-	4	-
		5	-	5	S-	5	-
		6	-	6	-	6	IN
		7	CAN - H	7	E-	7	-
		8	-	8	E+	8	-
		9	CAN - VCC	9	-		



	10 pin terminal strip JP4	10 pin terminal strip JP6	
1	Screen	Screen	
2	Spindle GND	key-operated switch GND	
3	Spindle 5V	5V	
4	Suppl. poti slider (free)	key-operated switch	
5	Suppl. poti slider (free)	-	
6	Spindle slider	Handwheel T1	
7	Screen	Screen	
8	Feed GND	GND	
9	Feed slider	Handwheel T2	
10	Feed 5V	5V	

## 2.2.4 Connections



Grounding

Supply

RJ45


CAN 1 / CAN 2

Spindle  
Feed  
Key-oper. switch

## 2.3 Touch-Screen calibration

The Touch screen is calibrated in the factory before the distribution. Being after some time malfunctions occur, can be repeated the calibration.

For calibrating the two keys simultaneous press. Then this picture appears.




**Touch screen area** (Xmin - Xmax / Ymin - Ymax) determine:  
In addition with a pointed soft item from on the left of above close at the edge in direction of arrow around the display drive.

With key 'Save & Exit' the next picture appears.

## 2.3 Touch-Screen calibration

In this picture the **calibration points** appear. The total area actual into 16 subranges divided. The markings (crosses) of the subranges with a pointed soft item touched lightly in the order


- 1 - 2 - 7 - 6 - 1
- 2 - 3 - 8 - 7 - 2
- 3 - 4 - 9 - 8 - 3
- 4 - 5 - 10 - 9 - 4
- etc.



## 2.3 Touch-Screen calibration

It is recorded when each touching lightly on cross. This cross command as close ones as possible at the given mark point (cross) is situated.

The marking process can be repeated, in order to keep the dispersion as small as possible.



The calibration is terminated with press the keys 'Save & Exit'.

To net curtain aborted with key 'Quit' the process without saving.



## CAN bus I/O level

---

3.	CAN bus I/O level	3 - 2
3.1	I/O configuration	3 - 3
3.2	Program 'canconf'	3 - 4

### 3. CAN bus I/O level

The CAN bus I/O level of the CNC 902 / CNC 903 / CNC 904 / CNC 905 contains the following stages of development.

5 CAN nodes with in each case

64	Digital inputs	8	8 Channel digital input clips
64	Digital outputs	8	8 Channel digital output clips
2	Analog inputs	1	2 Channel analog input clips
2	Analog outputs	1	2 Channel analog output clips

### 3.1 I/O configuration

The configuration and initialization of the field bus couplers as well as the pertinent I/O level are determined by a configuration file. This has the designation ' canconf ' and finds itself in the general statement of the CNC.



Example of a CAN I/O configuration


CAN node 1:  
 5 x 8 Channel digital input clips  
 4 x 8 Channel digital output clips

CAN node 2:  
 3 x 8 Channel digital input clips  
 3 x 8 Channel digital output clips

CAN node 3:

CAN node 4:

CAN node 5:



## 3.2 Program 'canconf'

```
#####  
## CAN-Konfiguration fuer          ##  
## Knoten 1:                       ##  
## Knoten 2:                       ##  
#####  
#  
## Steckplatz-Nummer, CAN-Modul, 0=selbstsuchend ##  
[slot]  
0  
#  
## Kanal-Nummer, CAN-Modul ##  
[channel]  
2  
#  
## Baudrate 0=1000kB, 1=800kB, 2=500kB, 3=250kB, 4=125kB, 5=100kB ##  
[baudrate]  
2  
#  
## Knoten 1-5, PDO-Adressen Digitale Eingaenge ##  
[input_pdos]  
0x181  
0x182  
#0x183  
#0x184  
#0x185  
#  
## Knoten 1-5, PDO-Adressen Digitale Ausgaenge ##  
[output_pdos]  
0x201  
0x202  
#0x203  
#0x204  
#0x205  
#  
## Knoten 1-5, PDO-Adressen Analoge Eingaenge ##  
[analog_in]  
#0x281  
#0x282  
#0x283  
#0x284  
#0x285  
#
```

### 3.2 Program 'canconf' (continued))

```
## Knoten 1-5, PDO-Adressen Analoge Ausgaenge ##  
[analog_out]  
#0x301  
#0x302  
#0x303  
#0x304  
#0x305  
#  
#  
## CAN-Knoten 1, Digitale Ein- und Ausgaenge ##  
## mit Zuordnung der BWO E/A-Adressen ##  
i8  
i8  
i8  
i8  
i8  
o8  
o8  
o8  
o8  
#  
#  
## CAN-Knoten 2, Digitale Ein- und Ausgaenge ##  
## mit Zuordnung der BWO E/A-Adressen ##  
i8  
i8  
i8  
o8  
o8  
o8  
#
```



## Programming CNC

CNC 902 / CNC 903 / CNC 904 / CNC 905

---



1 Introduction



2 Operating



3 NC program (F / S)



4 Traverse conditions (G)



5 Cycles (G)



6 Additional functions (M)



7 Tool (T)



8 Parameter (P / q)



9 Messages

---



## CNC Characteristics and Functions


---

1.	Compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905	1 - 2
1.1	Introduction	1 - 2
1.2	Characteristics and functions	1 - 3
1.3	Software	1 - 7
1.4	Notes for the line-up	1 - 9

## 1 Compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905

### 1.1 Introduction

The compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905 are conceived for the application with CAN Bus. Communicate to them over the CAN Bus with the drives and the I/O bus. The CNC Control actual in the operating panel integrates. The operating panels have fully graphicable color LC displays and foil keyes with mechanical pressure point.



#### Interfaces

- CAN Bus 1000kbit for CANopen Drives
- CAN Bus 500kbit for I/O box bus system according to CANopen Specification
- Ethernet (TCP/Ip) RJ45
- Serially RS232, RS422
- PCMCIA e.g. for external hard disk (CNC 905 option)
- USB (CNC 905 option)

## 1.2 Characteristics and functions

### Functions of the control

- Operating system BWO real-time kernel
- Logs TCP/IP stack, CANopen stack
- Soft PLC
- Construction of a simple CNC controller in connection with soft PLC and soft NC
- BWO file server
- Programming of the control surface also PROMA
- Block-by-block reloading with larger programs
- Graphic cycle programming
- Free DLL for the implementation of own programs

### CPU data

Static RAM	512kB
Run-time memory DRAM	16MB
Flash-disk-memory for operating system and control surface	8MB
Flag memory	60kB
NC memory	193kB
Remanent flags	4096
Parameter	20000

### Programmable box bus coupler

I/O knot for input/outputs	5
with in each case digital inputs	64
digital outputs	64
analog inputs	2 x16bit
analog outputs	2 x16bit

## 1.2 Characteristics and functions

Versions	CNC 902	CNC 903	CNC 904	CNC 905
NC channel	1	1	1	1
Axes / Spindles	4	4	8	8
Spindle in C axes operation	1	1	1	1
Linear interpolation (Axes)	3	3	3	3
Cirkular interpolation (Axes)	2	2	3	3
Screw interpolation (Axes)	2+1	2+1	2+1	2+1
Spline interpolation	-	-	•	•
Polynomial interpolation	-	-	•	•
Polar transformation	-	-	•	•
Scara transformation	-	-	•	•

Symbols: • Functions are possible  
 - Functions are not possible

### CNC Characteristics and functions

- Tangential axis
- Axes couple, reflect and exchange
- Restarting after abort
- Feed, corners, circle and outline dynamics
- Electronic gears and Handwheel
- Polar coordinates system
- Axes simulation
- Coordinates turn, reflect and shift
- Measuring and processing cycles
- Interpolation plane selection
- Tool radius path correction
- Automatic selection of linear and circular interpol.
- Zero points / zero shift
- Outline path short programming
- Parameter calculation
- Diagnostic functions
- Graphic cycle programming
- Graphic simulation

## 1.2 Characteristics and functions

### Operating panel data

LCD display in TFT version.

Resolution 640 x 480, 256 off 4096 colours

display size with CNC 902 / CNC 904 6.4"

CNC 903 / CNC 905 10.4"

Touch screen with resolution of 1024 x1024

42 function keys, of it 15 freely shapable,

PLC keys with display on LCD display,

Operating voltage 24V

Battery buffer for the clock

### Connections

(CNC 903 / CNC 905 on separate machine operating panel)

4 Override Potentiometer

1 Handwheel (TTL level cable length 1m, +5V)



1 Key-operated switsch

1 Joystick (in place of 3 override Potentis)

1.2 Characteristics and functions

Compact controls CNC 902 / CNC 904

Dimensions (B x H in mm) 277 x 227



Compact controls CNC 903 / CNC 905 with additional machine operating panel

Dimensions (B x H in mm) 328 x 310

Machine operating panel (option) 80 x 310

### 1.3 Software

#### **Programming software XPLC**

XPLC actual a programming software for the compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905. The software actual on PC executably.

With XPLC all functions of the control with stored program (PLC) with the compact controls can be taken in operation.

Details in addition in this manual paragraph 4. and 5.

#### **Standard interface for CNC**

The standard adaption contains a list of the free, pre-allocated and reserved flag areas.

Details in addition in this manual paragraph 6.


#### **Programming software NC**

With the programming software can NC programs with the available functions in the compact controls be created. Details in addition in the NC manual.

## 1.3 Software

### Operating system management program WINBV

Software on a PC to controlling of the CNC.



The display of the CNC is illustrated on a PC. The control can be served then from the PC.


Thus can be implemented:

- Diagnosis locally
- On-line remote diagnostics
- Operating system care
- Data administration
- Data protection
- NC archiving

Details in addition in this manual paragraph 7.

### Data transfer on one SERVER

Software on a PC for data transfer with the CNC.



By the CNC can be accessed the drive assemblies of a server. Several controls can be connected at a server and load NC data from the server or save on the server.

## 1.4 Notes for the line-up

Memory resets (see the also following pages)

With the line-up and with unclear conditions in the FLASH memory the following steps should be executed:

- Passing through of the switching on check with test parameter: No Restore  
test NC memory: No Restore

Reset parameter and NC memory without store back of machine data and NC programs from the FLASH memory.


- Loading of the machine data (channel descriptors, axis definitions, axis data) over I/O traffic.
- Machine and axis configuration check.
- Memory of the characterized machine data into the FLASH memory of the CPU (see q10).
- System switch off and restart.
- In the switching on checks in the test parameter 'resetting' 'input Yes' and in the test NC memory 'resetting' 'input Yes'.

1.4 Notes for the line-up (continuation)

Test parameter

Possible internal messages with the passing through of the switching on checks with the displays of 'ok' or 'defect':

- 'far ones'
- 'resetting' with Restore
- 'resetting' without Restore



Display **Ok**

Key of 'far ones' (F1) press

- Effect:
- The parameter values remain received.
  - Machine data becomes from THE FLASH memory not loaded.
  - Channels and channel descriptor are defined in accordance with parameter value.

Display **Ok / Defect**

Key (reset) press **Reset??**

Key 'Yes' (F2) press

- Effect:
- The total parameter memory is cleared.
  - Parameter basic adjustment one executes.
  - Machine data becomes from the FLASH memory loaded (Restore) (q10).
  - Channels and channel descriptor are defined in accordance with parameter value.

display **Ok / Defect**

Key (reset) press **Reset??**

Key (picture off) press **NO Restore??**  
Key 'Yes' (F2) press


- Effect:
- The total parameter memory is cleared.
  - Parameter basic adjustment one executes.
  - Machine data becomes from the FLASH Memory not loaded (No Restore).
  - channels and channel descriptor are defined in accordance with parameter reason in position.

1.4 Notes for the line-up (continuation)

Test NC memory

Possible internal messages with the passing through of the switching on checks with the displays of 'ok' or 'defect':

- 'far ones'
- 'resetting' with Restore
- 'resetting' without Restore



display **Ok**

Key of 'far ones' (F1) press

Effect:

- the NC programs remain received.

display **Ok / Defect**

Key (reset) press  
**Reset??**

Key 'Yes' (F2) press

Effect:

- the total NC memory one resets.
- NC programs become from the FLASH memory into the NC RAM memory loaded (Restore) (see also q10).

display **Ok / Defect**

Key (reset) press  
**Reset??**

Key (picture off) press  
**NO Restore??**

Key 'Yes' (F2) press

Effect:

- the total NC memory one resets.
- NC programs become from the FLASH Memory not into the NC RAM memory loaded (NO Restore), (see q10).
- NC memory remains empty.



**2. Operating**

2.1	Compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905	2 - 3
2.1.1	Machine operating panels	2 - 4
2.1.2	Control keys	2 - 6
2.1.3	Touch screen keys	2 - 10
2.2	Power on tests	2 - 13
2.2.1	Automatic power on tests	2 - 13
2.2.2	Power on test with confirmation	2 - 14
2.2.3	Power on test with error	2 - 21
2.2.4	Company sign	2 - 28
2.3	Reference points	2 - 29
2.3.1	Approaching reference points automatically	2 - 29
2.3.2	Manual approaching of reference points	2 - 30
2.4	Screen keys and screen displays	2 - 32
2.4.1	Position of the function keys in the screen frame	2 - 32
2.4.2	Setting the screen brightness	2 - 33
2.4.3	Screen displays in the headline	2 - 34
2.5	Selection menu	2 - 36
2.5.1	Start data	2 - 40
2.5.2	Dialogue	2 - 51
2.5.3	Parameter	2 - 55
2.5.4	Machine functions	2 - 63
2.5.5	Tool data	2 - 65
2.5.6	Zero points	2 - 68
2.6	Operating modes	2 - 71
2.6.1	Manual operation	2 - 71
2.6.2	Automatic operation	2 - 74

**2. Operating**


2.7	Diagnostic	2 - 78
2.7.1	Messages	2 - 80
2.7.2	PLC	2 - 82
2.7.3	Axes	2 - 85
2.7.4	Oscilloscope	2 - 88
2.7.5	Additional information	2 - 93
2.8	NC editor and I/O circulation	2 - 94
2.8.1	Selection	2 - 96
2.8.2	I/O parameters	2 - 97
2.8.3	Program input	2 - 98
2.8.4	Copying	2 -100
2.9	Input a program according to DIN / ISO	2 -108
2.10	Preparing a NC program in Teach mode	2 -113
2.10.1	Setting zero points	2 -113
2.10.2	Enter a program with Teaching	2 -114
2.11	Program input with graphic support (outline path)	2 -115
2.11.1	General	2 -115
2.11.2	Inseting a point	2 -121
2.11.3	Inseting a straight line	2 -122
2.11.4	Inseting an arc	2 -127
2.11.5	Inseting a chamfers or roundness	2 -132
2.11.6	Editing	2 -138

2.1 Compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905

The compact controls CNC 902 / CNC 903 / CNC 904 / CNC 905 are conceived for the application with CAN Bus. Communicate to them over the CAN Bus with the drives and the I/O bus. The CNC Control actual in the operating panel integrates. The operating panels have fully graphicable color LC displays and foil keyes with mechanical pressure point.

Compact controls CNC 902 / CNC 904

Dimensions (B x H in mm) 277 x 227



Compact controls CNC 903 / CNC 905 with additional machine operating panel


Dimensions (B x H in mm) 328 x 310

Machine operating panel (option) 80 x 310

2.1.1 Machine operating panels

Machine operating panel CNC910

- 1 Feed override
- 2 Feed override
- 3 Code switch  
Program block-free
- 4 Emergency-stop key



Note:


Code switch 1 opener (21/22) freely

Emergency stop 2 openers (11/12 and 21/22) freely

2.1.1 Machine operating panels

Separate machine operating panel CNC920

- 1 Illuminated push button
- 2 Code switch  
Program block-free
- 3 Feed override
- 4 Spindle override
- 5 Emergency-stop key




Note:

Code switch 1 opener (21/22) freely


Emergency stop 2 openers (11/12 and 21/22) freely

2.1.2 Control keys

Control keys for PLC functions




- 1 Shift  
In connection with further keys special functions can be released, e.g. can with editor on / off the touch screen activated or deactivated become (to the cleaning of the screen).
- 2 to 9 8 PLC keys with LED on the display can by the user as desired be marked (with label strip e.g. T1 to T8).
- 10 additional 32 PLC keys with LED on the Touch screen  
The PLC additive keys can be designated by the user as desired, e.g.:




2.1.2 Control keys

Control keys for axis selection




- 1 bis 6     6 axis keys  
Can by the user as desired be marked (with label strip e.g. X, Y, Z, A, B, C).
- 7            12 axis keys on the Touch screen, can by the user as desired be marked  
e.g.:



2.1.2 Control keys

Control keys for modes of operation




- 1 Manual mode
- 2 Switching in automatic mode: With the 1. Pressures becomes the sequential block adjusted. Afterwards becomes when each pressing key between sequential block and single block back and forth switched.
- 3 Switching in positioning mode
- 4 Continuous traversed in the manual mode
- 5 Step by step traversed in the manual mode, incrementations freely definably
- 6 With handwheel traversed
- 7 Automatic home position and travel of point of reference
- 8 und 9 Push buttons for traversing the selected axis with manual mode
- 10 und 11 start and stop  
 The automatic program sequence is started or stopped  
 - in the positioning mode: The NC block in the indication area is processed.  
 - in the automatic mode: The selected NC program is worked on.

2.1.2 Control keys

Control keys for program input and data communication

- 1 Key function freely shapable, e.g. graphic simulator.
- 2 Key function freely shapable, e.g. cycle or info. pictures.
- 3 I/O circulation  
Selection of the I/O menu to the data communication
- 4 Block editor
- 5 Diagnosis  
Information about conditions, interfaces, parameters.
- 6 Editor on
- 7 Editor off
- 8 Menu selection
- 9 Enter
- 10 und 11 Beginning / end
- 12 und 13 Picture up / down
- 14 Additional information  
Information about lining up NC program.



2.1.3 Touch screen keys

Touch screen keys for manual mode and program input

Opening display  
Selection menu

Menu screen 1



Selection keys on the touch screen

Menu screen 2

Switching between the menu screens with key (roll function)




2.1.3 Touch screen keys

Touch screen keys for input with numeric keyboard

The cursor press and shift on a wished input field .


The numeric keyboard will during contact an input field faded in.

Input break off:  
With the finger press on not with input fields occupied place on that display.



Requires the input field hexadecimal input, will the hexadecimal keyboard faded in.


With 2 x pressures on ' - ' indication becomes between decimally and hexadecimal keyboard around switched.



2.1.3 Touch screen keys

Touch screen keys for input with ASCII keyboard

With the program input will a ASCII keyboard faded in.



Special functions with WINTERM

The ASCII keyboard can be switched by hand: on / off

The contrast of the announcement of the ASCII keyboard can be adjusted. It can be struggled so far that the keyboard appears only as background picture.

The key functions remain. However one can read now also the text, which is under the keyboard.

Contrast of the announcement: more brightly more darkly

## **2.2 Power on tests**

The display field is activated after swichting on the control. The control starts a self-test. The position of the key-operated switch 1 (P11000) determines the course.

### **2.2.1 Automatic power on tests**


If the key-operated switch is closed (position 1), the power on tests are running automatically, if no errors appear (e.g. def. parameter or def. NC memory).

Closed switch	Position 1	Automatic power on test
Open switch	Position 0	Power on test has to be activated with pressing a key.

### 2.2.2 Power on test with confirmation

Test operating panel

First, the operating panel is tested (takes some seconds).




Here the function keys “Continue” and “Yes” and “No” are used combined with the key  (Delete).

## 2.2.2 Power on test with confirmation (continued)

Test operating panel

After a successful test, the following display appears:



Meaning:


Line 1 Project name of the PROMA surface  
with date and time of making the surface (SHOW\_E).

Line 2 PLC program, from which the symbols are taken, with check sum.

2.2.2 Power on test with confirmation (continued)

Test PLC program

After a successful test, the following display appears:



Meaning:

Line 3      Actual PLC program with check sum and number of version

**Note:** Program name and check sum of the PLC program (operating panel) from which the symbols are taken, and of the actual PLC program should be the same (line 2 and 3). If the names or check sums are different, it has to be checked if the symbols used in the surface have the same position as they do in the actual NC program.

2.2.2 Power on test with confirmation (continued)

Test operating system

After a successful test, the following display appears:



Meaning:

Line 4 CNC standard operating system with version and date


Line 5 Option: DLL-software for customer-specific operating system enlargements with name and date

## 2.2.2 Power on test with confirmation (continued)

### Test parameter

After pressing the function key “Continue”, the parameter memory is checked.

The following display appears after a successful test:



Meaning:


Line 6    The parameter memory is all right.

## 2.2.2 Power on test with confirmation (continued)

### Test NC memory

After pressing the function key "Continue", the NC memory is checked.

The following display appears after a successful test:



Meaning:


Line 7 NC memory is all right  
Indicating free memory and complete memory

## 2.2.2 Power on test with confirmation (continued)

### Finish power on test

After pressing the function key "Continue" the power on test is finished and the system is loaded (takes some seconds).

The following display appears after a successful test:




Then, the company sign appears.

2.2.3 Power on test with error

PLC test


If the following display appears, the PLC program is defective. The power on test is stopped. In this case, the PLC program has to be loaded again and has to be stored in the EEPROM.



### 2.2.3 Power on test with error (continued)

#### Parameter test

The following display appears if the parameter memory is defective. The power on test is stopped.




Meaning:

Line 6 Display of the first defective parameter (q) and the number of defective parameters.

2.2.3 Power on test with error (continued)

Parameter test

The power on test is only continued if the key  (Delete) is pressed. The following display appears.



Delete ??

Key "Yes" Delete the complete parameter memory

Key "No" The parameter memory is not deleted.  
Go on to test NC memory with pressing the key "Continue"

### 2.2.3 Power on test with error (continued)

#### Parameter test

After Delete ? and pressing the key "Yes" the following functions are loaded

- BWO presettings
- customer-specific data from the EEPROM.


Test Panel	:	Ok	BW0900.PRJ	16.01.97	11:16:24
			CNC_C4A	Pz:D628	
Test PLC	:	Ok	CNC_C3E	Pz:D755	V2.0
Test BS	:	Ok	SYS 000_1050		29.11.1996
Test Parameter	:	<b>restore -</b>		1	29995
Test NC-Memory	:		free:	0	tot: 0

Go on to test NC memory with pressing the key "Continue"

### 2.2.3 Power on test with error (continued)

#### Test NC memory

The following display appears if the NC memory is defective. The power on test is stopped.



Meaning:

Line 7 Error code (33) and additional information (0)


**2.2.3 Power on test with error (continued)****Test NC memory****Meaning of the error codes**

Code	Meaning
02	Program not found
05	End of program or Write-/ Read indicator > program size
06	No free memory
07	Faulty check-sum
10	Error when reading from NC memory
11	Error when writing on NC memory
15	No program input , e.g. key-operated switch locking
16	Program should be opened for writing, but is already opened
25	Key-operated switch interlocking
30	Defective directory chain
31	Defective program chain
32	Defective list of free blocks
33	Defective check-sum of system data
35	Blocks in program system are double-chained

2.2.3 Power on test with error (continued)

Test NC memory

The power on test is only continued if the key  (Delete) is pressed. The following display appears.



Delete ??

Key "Yes" Delete complete NC memory

Power on test is finished with pressing the key "Continue" and the company sign appears.

2.2.4 Company sign



## **2.3 Reference points**

Reference points are machine-specific mechanical fixed points.

After the power on tests, you have to approach with each axis the corresponding reference point, if the machine works in the incremental measuring system.

The reference point is stored and the actual value display is set with the correct value.

In the first line of the display field, the axes of which the reference point is not stored, are shown.

Because the traverse directions for taking reference points are depend on the machine, the following explanation can only be an example.

Note: The reference point must not be identical with the machine zero point.

### **2.3.1 Approaching reference points automatically**

The reference points can be approached automatically, if a corresponding program is stored in the PLC. The key  is reserved for this program.

### 2.3.2 Manual approaching of reference points

#### Requirements


- Power on tests are ready.
- The control is switched on (key "Control on" is pressed)
- The operating mode "Manual" is set.
- The feed for manual mode is given, feed override > 0.
- The drive mode is set (e.g. "continually").

#### Approach reference point of an axis, e.g. X-axis

Press key "X"

Display: MANUAL X Cont Ref: X Y Z A B

Press key "Manual" until max. end position of the X-axis is reached.



2.3.2 Manual approaching of reference points (continued)


Approach reference point of an axis, e.g. X-axis

Then press “Manual” until the X disappears from the display.

Display: Manual X Cont REF: Y Z A B


Now the reference point for the X-axis is stored.

The same procedure is valid for the other axes.



2.4 Screen keys and screen displays

2.4.1 Position of the function keys in the screen frame



## 2.4.2 Setting the screen brightness

The brightness of the screen can be set continuously.

When pressing the function key “**F6**” and



(Page up)

the creen becomes brighter,






(Page down)

the screen becomes darker.


### 2.4.3 Screen display in the headline

#### Displays in manual mode




2.4.3 Screen display in the headline (continued)

Displays in automatic mode




2.5 Selection menu

Menu tree



2.5 Selection menu (continued)

All functions can be selected with the selection menu with the function keys F 1 to F7.  
The menu consists of two function pictures. **Selection picture 1:**




Selection of

- F1 Channel
- F2 Start data
- F3 Dialogue
- F4 -
- F5 Parameter

2.5 Selection menu (continued)

**Selection picture 2:**

Switching from selection picture 1 <—> selection picture 2 with function key F6 (roll function)




Selection of

- F1 Channel
- F2 Machine function
- F3 Tool places
- F4 Tool data
- F5 Zero points

2.5 Selection menue (continued)

Menue tree



Functions	Section
Start data	2.8
Dialogue	2.9
Parameter	2.10
Machine functions	2.11
Tool data	2.12
Zero points	2.13

2.5.1 Start data

The following menu enables setting the start data.

CNC900 /CHAN.1		MANU	
START-DATA			
Startprog.	P:	87	N: -
Approachprg	-	P: -	N: -
Dripfeed	-	C:\NCDATA\	
Rapid Feed		20000	Simulation:
%Feed		-	Grafik -
Test Feed		-	Axis -
			M-Function -
X	0.000	Y	-45.000
Z	-90.000	A	0.000
B	-45.000	C	0.000
D	0	B1	1020
Channel			
←			

F1 Channel

F2 -

F3 -

F4 -

F5 -

2.5.1 Start data (continued)

**Block**

Input block number of the starting block. If the value is 0 or deleted, the NC program is started with the 1st block.

**Rapid traverse**


The desired rapid traverse can be input. If the value is 0 or deleted, the manual feed is active.

**% Feed**

The programmed feeds in the NC program are modified with the indicated percentage.

**Test feed**


If a test feed is input the programmed feeds in the NC program are ineffective. The test feed is active. If the value for the test feed is 0 or deleted, the test feed is not active.



2.5.1 Start data (continued)

Reapproach program

In the case of the abort of a current NC program (HAND abort, message) by the system the actual NC program position in the parameters P8802, P8803 and P8807 is stored. The NC program position is displayed in the start data menu. On properly terminated NC program resets this information.



After an NC abort if the restarting mode is switched on (P8804=1) and the NC program started, then the NC program up to the restarting point is simulated, i.e. no axis movements result.

In the restarting block the simulation is switched off. The restarting position is started on direct path. With achieving the restarting position P8804=0 is settinged.

One re-starts on the initial position of the aborted block.

If the NC program in a process cycle is aborted, then becomes to cycle start started. When restarting m-functions and m-cycles are treated according to m-Funktionsdefinition (P11050..., P8250...).

## 2.5.1 Start data (continued)

### Dripfeed mode

The NC programs that should be processed are not in the NC memory of the control but in external data carriers.

The operating panel **CNC 900 C** has the NC programs on the hard disk or on a data server.

With the operating panel **CNC 900**, the NC programs have to be read in via I/O (BWO-I/O-socket, NCARC.EXE).

NC programs for dripfeed have to be linear, i.e. block skips and sub-program call-ups are not allowed.

Activating in the start-data menu:

Dripfeed	1	Dripfeed on
Dripfeed	0	Dripfeed off

### Dripfeed mode with operating panel CNC 900 C

- In the start-data menu:
  - switch on dripfeed mode,
  - input program number,
  - check DOS-path-name,
  - path-name is indicated in the start-data menu (see also CNC900X.CFG).
- Change of operating mode after AUTOMATIC.
  - Now the data transmission to the dripfeed-buffer is started.
- NC start.

### Dripfeed mode with operating panel CNC 900

- In the start data menu:
  - switch on dripfeed mode
- Check I/O parameters
- Connect external data carrier
- Change of operating mode after AUTOMATIC,
  - due to this an I/O-input-start is made automatically.
  - The CNC is now waiting on a data transfer.
- Start data transfer at the external data carrier,
- NC start

2.5.1 Start data (continued)

Dripfeed mode

with operating panel CNC 900 C

CNC900 /CHAN.1		AUTO		DF	STOP
START-DATA					
Startprog.		P:	87	N:	-
Approachprg	-	P:	1212	N:	530
Dripfeed	1	C:\NCDATA\			
Rapid Feed			20000	Simulation:	
%Feed			-	Grafik	-
Test Feed			-	Axis	-
				M-Function	-

CNC900 /CHAN.1		AUTO		DF	START
Start Prog:	87	Bloc:	-	F:	0.00
Act. Prog:	87	Bloc:	0	F:	1000.00
Dripfeed					
> Dripfeed					
Dripfeed					

## 2.5.1 Start data (continued)

### Simulation

#### Graphic

The graphic simulation can be used for controlling optically the program run. Thereby e.g. the axes and the transmission of the M-functions can be switched off for a test run. The graphic simulation is started in the start menu with '1' and switched off with '0' or 'deleted'.

With the key  you can switch from graphic to normal picture. If the graphic simulation is not switched on in the start menu, the message M4402: 'Graphic simulation not active' appears if you press the key .

#### Axes

If the simulation of the axes is activated (1), the axes do not move during program run. But the axes movements can be seen on the screen. 'ASIM' is written in the headline. The function can be switched off with '0' or 'deleted'.


#### M-functions

If the simulation of the M-functions is activated (1), the M-functions are not transmitted to the PLC. 'MSIM' is written in the headline. The function can be switched off with '0' or 'deleted'.

2.5.1 Start data (continued)

Simulation


Graphic on



The screenshot shows a CNC control interface with the following elements:

- Top bar: **CNC900 /CHAN.1** (yellow background), **AUTO** (blue button), and **STOP** (red button).
- Section: **START-DATA**
- Parameters:
  - Startprog. P: **87** N: -
  - Approachprg - P: 87 N: 0
  - Dripfeed - C:\NCDATA\
- Simulation settings:
  - Rapid Feed: 20000
  - %-Feed: -
  - Test Feed: -
  - Simulation:
    - Grafik: 1
    - Axis: -
    - M-Function: -

Axes and M-functions on



The screenshot shows the same CNC control interface as above, but with the following changes:

- Top bar: **CNC900 /CHAN.1** (yellow background), **AUTO** (blue button), **ASIM** (white button), **MSIM** (white button), and **STOP** (red button).
- Parameters:
  - Startprog. P: 87 N: -
  - Approachprg - P: 87 N: 0
  - Dripfeed - C:\NCDATA\
- Simulation settings:
  - Rapid Feed: 20000
  - %-Feed: -
  - Test Feed: -
  - Simulation:
    - Grafik: -
    - Axis: 1
    - M-Function: **1** (highlighted in blue)

**2.5.1 Start data (continued)****Graphic simulation**

**Data input (F2)**      Input with numerical keys

X, Y and Z              X, Y, and Z origin

Size                      Zoom

View      0      XY-coordinates (G17)  
            1      XZ-coordinates (G18)  
            2      YZ-coordinates (G19)  
            3      3D

A-angle                  turning around X-axis

B-angle                  turning around Z-axis

**Options**

Direction arrows    1 on, 0 off

Holes                1 on, 0 off

Circle centres      1 on, 0 off


Zero points        1 on, 0 off

Actual ways        1 on, 0 off

2.5.1 Start data (continued)

Graphic simulation

Display of the target way (turned around X and Z axis)




- F1 Channel
- F2 Data input      Input with numerical keys
- F3 Turning          Turning around the X-, Z-axis, input with cursor
- F4 Move             X, Y and Z origin, input with cursor
- F5 Zoom            Size, input with cursor

2.5.1 Start data (continued)

Graphic simulation

Display of the target and actual way (turned around X and Z axis)




- F1 Channel
- F2 Data input      Input with numerical keys
- F3 Turning          Turning around the X-, Z-axis, input with cursor
- F4 Move             X, Y and Z origin, input with cursor
- F5 Zoom            Size, input with cursor

2.5.1 Start data (continued)

Graphic simulation


Example of a complex workpiece



- F1 Channel
- F2 Data input      Input with numerical keys
- F3 Turning          Turning around the X-, Z-axis, input with cursor
- F4 Move             X, Y and Z origin, input with cursor
- F5 Zoom            Size, input with cursor

2.5.2 Dialogue


Here you get the possibility to switch on a customer-specific dialogue, e.g. programming with work sheet.



- F1 Edit
- F2 New data block
- F3 Sort
- F4 Delete data block
- F5 Generate NC program

2.5.2 Dialogue (continued)

Programming with work-sheet - Selecting the cycle mode



F1 Selecting cycle mode

F2 -


F3 -

F4 -

F5 -

2.5.2 Dialogue (continued)

Programming with work sheet - Selecting the cycle



F1 Data input

F2 -

F3 -

F4 -

F5 -

2.5.2 Dialogue (continued)

Programming with work sheet - Selecting the cycle

CNC900 /CHAN.1
MANU

Pocket roughing conventional

**G71**

P80 :Zero point	G	<b>1</b>
P81 :Plane selection	G	0
P82 :Tool	No	0
P83 :Approach pos. 1.axis	mm	100.000
P84 :Approach pos. 2.axis	mm	250.000
P85 :Approach pos. tool-axis	mm	0.000
P21 :Feed tool-axis	mm/min	0.000
P86 :Spindle speed	U/min	0.001
P11 :Pocket dimension 1.axis	mm	0.000
P12 :Pocket dimension 2.axis	mm	0.000
P13 :Pocket dimes. tool-axis	mm	0.000
P14 :Corner radius	mm	0.000
P15 :Contour allowance	mm	0.000
P16 :In-feed dimen. 1./2.axis	mm	0.000
P17 :In-feed dimen. tool-axis	mm	0.000
P18 :Pocket deep allowance	mm	0.000
P19 :Safety margin tool-axis	mm	0.001

Store

Don't Store

- F1 Store
- F2 -
- F3 -
- F4 -
- F5 Do not store

2 - 54


Edition 01.2004

**2.5.3 Parameter**

The parameter menu consists of:

- Channel changeover
- Parameter changeover P/q (Channel - / System parameter)
- Spindle parameter
- Coupling parameter
- Axis parameter

**Menu tree**



**System parameter q**

0... 99	General system configuration
100... 999	Definition channel descriptor#
1000... 1999	System settings, system overlapping data
2000... 9999	Axis data
10000...	Channel parameter


**Channel parameter P**

0... 6999	User block 1
0... 499	Reserved for BWO standard cycles
0... 299	Cycle-area for cycle interfaces
300... 399	Area reserved for cycles, area for static, modal data
400... 499	Area reserved for cycles, area for temporary data
500... 6999	Area free for the user
7000... 9999	Fix defined channel parameters
11000...11999	System overlapping data, common area of all channels
12000...18399	Axis data
20000...29999	User block 2
30000...39999	User block 3

2.5.3 Parameter

Channel parameter P:

Input addresses, displaying parameters, input values and store.



The screenshot shows a CNC control interface with the following elements:

- Top left: **CNC900 /CHAN.1** (highlighted in yellow)
- Top center: **MANU** button
- Parameter list table:

P 12200:	1	Connected axis	\$20000705
P 12201:	0	Spindle axis	\$20000505
P 12202:	-	Diameter axis	\$20000504
P 12203:	-	-	\$20000504
P 12204:	30000	Max Axis speed [mm/min]	\$20000505
P 12205:	2000	Slope speed 1 [mm/min]	\$20000505
P 12206:	-	Slope speed 2 [mm/min]	\$20000504
P 12207:	-	-	\$20000504

X	0.000	Y	-30.000	Z	319.000	A	-30.200
B	-9.757						

Bottom navigation buttons:

- Channel
- P / q
- Spindle-Parameter
- Coupling-Parameter
- Axis-Parameter

- F1 Channel
- F2 P/q Switching between channel (P) and system parameters (q)
- F3 Spindle parameter
- F4 Coupling parameter
- F5 Axis parameter

2.5.3 Parameter (continued)

System parameter q:

Input addresses, displaying parameters, input values and store.

CNC900 /CHAN.1
MANU

q	<span style="background-color: blue; color: white;">8000</span> :	-	Connected axis	\$00000400
q	8001:	-	Spindle axis	\$00000400
q	8002:	-	Diameter axis	\$00000400
q	8003:	-	-	\$00000400
q	8004:	-	Max Axis speed [mm/min]	\$00000400
q	8005:	-	Slope speed 1 [mm/min]	\$00000400
q	8006:	-	Slope speed 2 [mm/min]	\$00000400
q	8007:	-	-	\$00000400

X	0.000	Y	-30.000	Z	319.000	A	-30.200
B	-9.757						

Channel

P / q

Spindle-Parameter

Coupling-Parameter

Axis-Parameter

F1 Channel

F2 P/q Switching between channel (P) and system parameters (q)


F3 Spindle parameter

F4 Coupling parameter

F5 Axis parameter

2.5.3 Parameter (continued)


Inputing spindle data is possible in this menue.



- F1 Channel
- F2 P/q                      Switching between channel (P) and system parameters (q)
- F3 Spindle parameter
- F4 Coupling parameter
- F5 Axis parameter

2.5.3 Parameter (continued)

Inputing coupling data is possible in this menu.



- F1 Channel
- F2 P/q                      Switching between channel (P) and system parameters (q)
- F3 Spindle parameter
- F4 Coupling parameter
- F5 Axis parameter

2.5.3 Parameter (continued)

Inputing axis data is possible in this menu. Page 1

CNC900 /CHAN.1
MANU

AXE	1				Page 1(2)
Axe connected	1	KV-Factor			16
Circular Axe	0	Machine-Dynamic 1			250
Max.Axe speed	30000	Machine-Dynamic 2			-
Slope-speed	30000	Exact-stop limit fine			0.05
Meas.sys.resol.Num.	300000	Exact-stop limit rough			-
Meas.sys.resol.Denom.	1	Software limit pos.			-
Counting Dir.reversal	0	Software limit neg.			-
Output Dir.reversal	0	Groundposition absolut			545

X	0.000	Y	-30.000	Z	319.000	A	-30.200
B	-9.757						

Channel

P / q

Spindle-Parameter


Coupling-Parameter

Axis-Parameter

- F1 Channel
- F2 P/q                      Switching between channel (P) and system parameters (q)
- F3 Spindle parameter
- F4 Coupling parameter
- F5 Axis parameter

2.5.3 Parameter (continued)

Inputing axis data is possible in this menu. Page 2



F1 Channel

F2 P/q Switching between channel (P) and system parameters (q)

F3 Spindle parameter


F4 Coupling parameter

F5 Axis parameter

2.5.3 Parameter (continued)

Drive parameter


This menu permits the Input of the drive data.



- F1 Channel
- F2 -
- F3 Drive parameter
- F4 Axis parameter page 2
- F5 Axis parameter page 1

2.5.4 Machine functions


The actual function picture appears.



- F1 -
- F2 -
- F3 -
- F4 -
- F5 -

2.5.4 Machine functions (continued)

The actual function picture appears.



- F1 Performance left
- F2 Function picture forward
- F3 -
- F4 Function picture backward
- F5 Performance right


## 2.5.5 Tool data

The actual tool data can be input here.

The tool data menu consists of

- Lay down tool
- Spindle
- Magazine
- Tool change

Menu tree




The tool dates (length, radius...) can be called up with 10-digit tool numbers in the program run.

Inputs are possible in manual mode via the operating panel or external data carriers without indicating a block number. If 'delete store' is input, the tool data are deleted during power on test.

## 2.5.5 Tool data

Tool in the spindle.



F1 Channel

F2 Lay down tool


F3 Spindle

F4 Magazine

F5 Tool change

## 2.5.5 Tool data

Tool in the magazine.



F1 Channel

F2 Lay down tool

F3 Spindle

F4 Magazine

F5 Tool change


## 2.5.6 Zero points

The actual zero point data can be input here.

The zero point data menu consists of

- Set to zero
- Delete
- Calibrate

Menu tree



For each axis, a maximum of 6 zero points can be set with G54 to G59 and can be called up during program run.


Zero point shift is made ineffective with G53. The program then refers to the machine zero point.

Inputs are possible in manual mode via the operating panel or external data carriers without indicating a block number. When deleting the memory during power on test, the zero point data are also deleted.

Zero point data can be located mathematically or they can be approached (edge scanner, clock gauge).

2.5.6 Zero points (continued)

The actual zero point is displayed. The values can be input and stored.



F1 Channel

F2 Set to zero


F3 Delete

F4 -

F5 Calibrate

2.5.6 Zero points (continued)

The actual values can be set to zero.



F1 Channel

F2 Set to zero

F3 Delete

F4 -

F5 Calibrate

## 2.6 Operating modes


The following operating modes can be set:

- MANUAL
- AUTOMATIC    Sequential block
- Single block
- Positioning

### 2.6.1 Manual mode

Manual mode is switched on with key .

For traversing the axes, the axis name (X, Y, Z, ...) and travelling mode (continuously or step by step) and the feed rate have to be input first.

By pressing the keys  (Manual+) or  (Manual-) the selected axis is traversed in positive or negative direction.

The length of the actual tool is calculated when traversing the tool axis.

#### Travelling mode

During  (continuously) travelling mode, the axis is moving as long until the manual key is pressed.

When traversing with fix length, the complete length is traversed by pressing a manual key once (the step width can be selected by pressing the key  (step) again and again).

During this time, the keys for Manual+/-, axis name and travelling mode remain ineffective.

When pressing the key  (Stop), the process can be interrupted. If a manual key is pressed again, the axis moves from the new position on with the selected length.

#### Command = Actual


Desired positions can be approached in the program and they can be overtaken into the command value display with key  (Command=Actual) and can be written into the memory with

 (Input).

2.6.1 Manual mode (continued)

Traverse **continuously** in manual mode.

Switch on manual mode with key . Select continuously with key .




- F1 Channel
- F2 Start data
- F3 Dialogue
- F4 -
- F5 Parameter

2.6.1 Manual mode (continued)

Traverse **step by step** in manual mode.

Switch on manual mode with key . Select step-by-step with key .



- F1 Channel
- F2 Start data
- F3 Dialogue
- F4 -
- F5 Parameter

## 2.6.2 Automatic mode

Automatic mode is switched on with the keys:



Automatic sequential block



Automatic single block



Positioning

### Start/Stop

The selected program is started with key  (Start). It can be interrupted with key  (Stop)

and continued with key  (Start) at any time.

The keys for machine functions are dependant of the PLC. The speed can be controlled with the override.

### Skip block

When making a program, the blocks which do have a slash placed in front of them, are skipped in automatic mode if the key  (skip block) is switched on.

Switch on: Press key 

The key is only effective before program start.


The display of the operating mode is completed by the symbol '/'.

Switch off: Press key  again.

2.6.2 Automatic mode (continued)

In **automatic sequential block**, all blocks of a program are worked one after the other.

Switch on sequential block with key .




- F1 Channel
- F2 Start data
- F3 Dialogue
- F4 -
- F5 Parameter

2.6.2 Automatic mode (continued)

In automatic single block, only one block is worked after the start. Start the next block with key



. Switch on automatic single block with key .




- F1 Channel
- F2 Start data
- F3 Dialogue
- F4 -
- F5 Parameter

2.6.2 Automatic mode (continued)

With positioning, a complete NC block or parts of it can be input via the numerical keys and worked without storing.

Switch on positioning with key .



F1 Channel

F2 -


F3 -

F4 -

F5 -


2.7 Diagnostic

Menue tree



2.7 Diagnostic


Diagnostic is switched on with the key . The machine picture appears, e.g.



- F1 Channel
- F2 Messages      Display messages
- F3 PLC            PLC diagnostic
- F4 Axes            Axis drive diagnostic
- F5 Oscilloscope

2.7.1 Messages

Current messages



- F1 Channel
- F2 Messages
- F3 Message record      Display of previous messages
- F4 -
- F5 -

2.7.1 Messages

Current messages

CNC900 /CHAN.1
MANU

MESSAGES - HISTORY Page 1 (9)

	Day	Time
M3000: Connection Operating panel <---> CNC was break	28	11:18.26
M3002: Low lube level	28	11:15.14
M3001: Emergence - Stop	28	11:15.14
M3002: Low lube level	28	11:15.09
M3001: Emergence - Stop	28	11:15.09
M3002: Low lube level	28	11:14.58
M3002: Low lube level	28	11:14.55
M3001: Emergence - Stop	28	11:14.55
M3002: Low lube level	28	11:14.30
M3001: Emergence - Stop	28	11:14.30
M3002: Low lube level	28	11:14.21

X	-0.000
B	0.000

Y	-60.000

Z	278.000

A	0.000

M3001: Emergence - Stop

Channel

Messages

Message-Record

- F1 Channel
- F2 Messages
- F3 Message record      Display of previous messages
- F4 -
- F5 -

2.7.2 PLC

I/O diagnostic

CNC900 /CHAN.1
MANU

**I/O DIAGNOSIS**

Inputs	E1 <input checked="" type="checkbox"/> 1 <input type="checkbox"/> 1 <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> 0 0 0 0 1 0 0 0 0 0 0 0 0 0 0 0
Outputs	A1 <input type="checkbox"/> 1 <input type="checkbox"/> 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Markers	M <input type="checkbox"/> 1 <input type="checkbox"/> 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Register	R <input type="checkbox"/> 0 <input type="checkbox"/> 0      102045188

X	-0.000	Y	-60.000	Z	278.000	A	0.000
B	0.000						

Channel

Interface  
CNC<--->PLC

State-  
machine

System-  
Config.

Clock

- F1 Channel
- F2 Interface CNC <--> PLC
- F3 State machine
- F4 System configuration
- F5 Clock

2.7.2 PLC (continued)

I/O diagnostic

CNC900 /CHAN.1
MANU

**I/O DIAGNOSIS**

Inputs	E1 <input checked="" type="checkbox"/> 1 <input type="checkbox"/> 1 <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> <input checked="" type="checkbox"/> 0 0 0 0 1 0 0 0 0 0 0 0 0 0 0 0
Outputs	A1 <input type="checkbox"/> 1 <input type="checkbox"/> 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Markers	M <input type="checkbox"/> 1 <input type="checkbox"/> 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
Register	R <input type="checkbox"/> 0 <input type="checkbox"/> 0      102045188

X	-0.000	Y	-60.000	Z	278.000	A	0.000
B	0.000						


Channel1

PLC900

- F1 Channel
- F2 PLC 900
- F3 -
- F4 -
- F5 -

## 2.7.2 PLC (continued)

## Clock



F1 Channel

F2 I/O

F3 State machine

F4 System configuration

F5 Clock

2.7.3 Axes

Axis diagnostic 1

CNC900 /CHAN.1
MANU
X
Cont

**AXIS DIAGNOSIS (1)**

Channel-Amplif.Enable

Channel-Drive Enable

Channel-Security-Stop

Channel-Block-Enable

	X	Y	Z	A	B
Axis is moving	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive Command plus	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive Command minus	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive Limit plus	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Drive Limit minus	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
End Position plus	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
End Position minus	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

X	409.909	Y	-60.000	Z	278.000	A	0.000
B	0.000						

Channel

Axis-PLC

Axis-Output

Axis-Positions

- F1 Channel
- F2 Axis PLC
- F3 Axis output
- F4 Axis positions
- F5 -

2.7.3 Axes (continued)

Axis diagnostic 2

CNC900 /CHAN.1
MANU
X
Cont

### AXIS DIAGNOSIS (2)

	Axis-shift	Axis-korrec.	Trailing Error	Output Voltage
X	-	-	0.000	0.000
Y	-	-	0.000	0.000
Z	-	-	0.000	0.000
A	-	-	0.000	0.000
B	-	-	0.000	0.000
	-	-	-	-

X	494.761	Y	-60.000	Z	278.000	A	0.000
B	0.000						

Channel

Axis-PLC


Axis-Output

Axis-Positions

- F1 Channel
- F2 Axis PLC
- F3 Axis output
- F4 Axis positions
- F5 -

2.7.3 Axes (continued)

Axis positions



F1 Channel

F2 Axis PLC


F3 Axis output

F4 Axis positions

F5 -

2.7.4 Oscilloscope

Four-channel oscilloscope with time-, polar- and Fourier diagnostic for evaluating the mechanical settings and for recognising defective mechanical parts.



- F1 Channel
- F2 Start time diagnostic
- F3 Start polar diagnostic
- F4 Start Fourier diagnostic
- F5 -

**2.7.4 Oscilloscope (continued)**

**Qnr** Parameter number (connection)

Number Meaning

q2150	Command position	[mm, degree]
q2152	Actual position	[mm, degree]
q2160	Lag distance	[mm, degree]
q2161	Coupling correction	[mm, degree]
q2168	Actual difference (corresponds to speed)	[mm, degree]
q2169	Output voltage of positioning control	[V]

**Offset** Vertical offset

**Amplif** Amplification, vertical resolution, units per division

**Trigger St** Trigger line number

**Edge**


1	trigger at rising edge
-1	trigger at declining edge
0	trigger immediately

**Value** Value at which it is triggered.

**TB/Freq** Time basis / frequency, horizontal resolution, units per division [ms, Hz]

2.7.4 Oscilloscope (continued)


Example: Three-channel time diagnostic



Line 1	Qnr	2169	output voltage of positioning control in V
	Offset	0,7	vertical offset
	Amplif.	0,15	units per division
Line 2	Qnr	2168	actual difference in mm/degree
	Amplif.	0,1	units per division
Line 3	Qnr	2160	lag distance in mm/degree
	Amplif.	0,2	units per division
Trigger	Line number	3	
Edge		1	trigger at rising edge
Value		0,1	trigger at this value
Time basis / Frequency		40	units per division

2.7.4 Oscilloscope (continued)

Example: polar diagnostic, circle test



Line 1      Qnr                    2152 actual position 1st axis in mm/degree  
             Amplification      0,02 units per division


Line 2      Qnr                    2352 actual position 2nd axis in mm/degree

Time basis / Frequency      120 units per division  
    chose time/frequency basis so that  
    at least one full circle is run.

2.7.4 Oscilloscope (continued)

Example: Fourier diagnostic, frequency spectrum

Frequency spectrum with oscillations at 33Hz and harmonics at 99Hz and 165HZ



Line 1	Qnr	2169	output voltage of positioning control in V
	Amplification	0,01	units per division vertically
Trigger	Line number	1	
Time basis / frequency		20	units per division horizontally in Hz

2.7.5 Additional informations


Additional online informations can be called up during operating with the key .

P(act):	1000	P(eye):	-	P(err):	-							
N(act):	10	N(eye):	-	N(err):	-							
F 60 %:	500.00	M24:	0	Co-Sys:	0							
S 50 %:	0	G04:	0									
T(Spi):	1	Radius :	50	Length :	70							
		R-corr.:	0.1	L-corr.:	0.3							
T(e/s):	1	Radius :	1	Length :	1							
		R-corr.:	-	L-corr.:	-							
G(act):	1	-	-	-	11	-	13	15	17	29	40	43
	46	47	-	55	-	-	64	-	90	-	94	97
Offset (act):												
X	0.000	Y	0.000	Z	0.000	A	0.000					
B	0.000		0.01				0.000					

2.8 NC editor and I/O


Writing, changing and storing NC programs;  
Storing parameter, tool data and zero points.

Menue tree



2.8 NC editor and I/O (continued)

When pressing the key  the menu for NC programming and I/O appears.



- F1 Channel
- F2 Selection
- F3 I/O settings
- F4 Program input
- F5 Copy <->

**2.8.1 Selection**

**Selection of storing modes**

on the left side

on the right side

---

CNC:

CNC:

C:\NCDATA

C:\NCDATA

A:\

Serial I/O

2.8.2 I/O parameters

This menu can be used for inputing I/O parameters.

CNC900 /CHAN.1		MANU	
E/A-PARAMETER			
Baudrate	9600	COM 1..4 / 0=HD	1
Data Bits	8	EOF mark	4
Stopbits	2		
Parity	0		
Program Overw	0		
X-on/X-off Pr	0	Teach Ax Select	\$00000007
X	0.000	Y	0.000
Z	0.000	A	0.000
B	0.000		
Channel			

F1 Channel

F2-


F3-

F4-

F5-

### 2.8.3 Program input

Program selection appears with pressing key F4 (in screen frame). With the cursor keys an existing program can be chosen or the number of a new program can be input with the numerical keyboard.




- F1 Channel
- F2 Cycle /program
- F3 -
- F4 Input a program according to DIN / ISO
- F5 Input a program with outline

**2.8.3 Program input (continued)**

Program input	paragraph
according to DIN / ISO	2.9
also Teach in	2.10
with graphic support (outline path)	2.11

2.8.4 Copying

Parameters, tool data, zero points and NC programs can be selected with the cursor keys for copying. The selected data are activated with the key and marked with an \*.




- F1 Channel
- F2 Selection
- F3 I/O settings
- F4 Program input
- F5 Copy <->

2.8.4 Copying (continued)

Parameter

After selecting with the cursor keys and after activating with  parameters can be copied with F5 from CNC: to C:\NCDATA or A:\ . Input Pmin and Pmax, identification letter D.



F1 Channel

F2 -

F3 -

F4 -

F5 -

## 2.8.4 Copying (continued)

### Parameter

Meaning of the input fields

Pmin: first parameter of output  
Pmax: last parameter of output

Channel 0 Output of q-parameters  
1 to 8 Output of P-parameters of the corresponding channel


Flag mask Status flag mask  
0 Output of all parameters according to Pmin - Pmax  
<>0 Output of parameters in the range of Pmin - Pmax, at which the bits are set in the parameter status according to the flag mask.  
Herewith an output of all parameters in which the EEPROM bit is set, is possible.

to: DOS file name

2.8.4 Copying (continued)

Tool data

After selecting with the cursor keys and after activating with  tool data can be copied with F5 from CNC: to C:\NCDATA or A:\ . Identification letter W.



F1 Channel

F2 -

F3 -


F4 -

F5 -

2.8.4 Copying (continued)

Zero points

After selecting with the cursor keys and after activating with  zero points can be copied with F5 from CNC: to C:\NCDATA or A:\ . Identification letter N.



- F1 Channel
- F2 -
- F3 -
- F4 -
- F5 -

2.8.4 Copying (continued)

NC programs

After selecting with the cursor keys and after activating with , the selected NC program is marked with \*.

CNC900 /CHAN.1
MANU

CNC:	C:\NCDATA
PARAMETER	P100000 20-11-05 15:10 975
WERKZEUGDATEN - WUHLDATA	P100001 7-12-09 10:51 99
MULLFUNKTE - ZERUMWUNTS	P100010 19-09-06 18:17 1029
F1 20-10-04 0:25 477	P100011 22-09-06 18:51 107
F0001 20-10-04 0:25 19	P101 19-06-06 17:26 1162
F77 20-11-06 11:07 125	P111 19-06-06 18:49 76
F1000 25-10-06 10:40 2000	P112 19-06-06 17:23 97
F4711 20-10-06 15:12 12577	P121 19-06-06 17:23 1718
F0000 20-10-06 10:56 1751	P122 19-06-06 19:11 2927
*F000124 20-10-04 0:25 0400	P12095 25-06-06 13:13 390
<b>F00004 20-10-04 0:25 4719</b>	P129520 2-07-06 12:10 17
F000111 20-10-04 0:25 06	P150000 18-07-06 18:50 275

Curr. Memory : 1990990 Max. Memory : 1592050

X	D.000	Y	D.000	Z	D.000	A	D.000
B	D.000						

Channel

Select

End if insertion

Program Input

Copy <->

- F1 Channel
- F2 Selection
- F3 I/O settings
- F4 Program input
- F5 Copy <->

2.8.4 Copying (continued)

NC programs

After selecting with the cursor keys and after activating with tool daNC programs can be copied with F5 from CNC: to C:\NCDATA or A:\ . Identification letter P.

CNC900 /CHAN.1
MANU

CNC:	C:\NCDATA
PARAMETER	P000101 20-06-96 12:30 2697
WERKZEUGDATEN - TOOLDATA	M000108 20-06-96 12:37 3657
MULLPUNKTE - ZEROPOINTS	<b>P000121 20-07-99 5:12 257</b>
P1 20-10-04 0:25 477	P000122 20-07-99 5:13 257
P0001 20-10-04 0:25 19	P000123 20-07-99 5:15 257
P77 20-11-96 11:07 125	P000129 10-01-96 18:41 7591
P1000 25-10-96 16:48 2050	P000131 2-02-96 9:53 3692
P4711 20-10-96 15:32 12377	P000132 2-02-96 18:25 3936
P0000 20-10-96 16:56 1751	P000133 7-02-96 12:55 3691
P000124 20-10-04 0:25 0460	P000139 19-09-95 12:45 6461
P000104 20-10-04 0:25 4738	P000181 26-06-96 13:38 5891
P000111 20-10-04 0:25 06	P000182 25-09-95 15:12 3955

Curr Memory : 1490990 Max Memory : 1592050

X	0.000	Y	0.000	Z	0.000	A	0.000
B	0.000						

Channel

Select

Mod if insertion

Program Input

Copy <->

- F1 Channel
- F2 Selection
- F3 I/O settings
- F4 Program input
- F5 Copy <->

---

**2.8.4 Copying (continued)**

**NC programs**

**All programs mark**


F6 and inserting branch press.

**All programs off NC memory copy**  
(store total NC memory in a file)

Programs mark and Funktionstate F5 (copy) press.


## 2.9 Input a program according to DIN / ISO

Menue tree



2.9 Input a program according to DIN / ISO (continued)


After inputting the program number and after pressing the key DIN / ISO the program appears with the first blocks in the display, if a program is existing with the indicated number. If not, only the program number and >N10 appears.




- F1 -
- F2 -
- F3 -
- f4 -
- F5 -

2.9 Input a program according to DIN / ISO (continued)

Changing or inputing blocks

When pressing  the selected block and the function appear.



F1 Teach-Select

F2 -

F3 -


F4 Functions Switching on further programming functions

F5 Back

2.9 Input a program according to DIN / ISO (continued)

Functions

When pressing  the functions are activated. Selection with cursor keys.



F1 Teach-Select

F2 -

F3 -


F4 Functions Switching on further programming functions

F5 Back

2.9 Input a program according to DIN / ISO (continued)

Functions

When pressing XXX another function sieide appears.



F1 Teach-Select

F2 -

F3 -

F4 Functions Switching on further programming functions

F5 Back

## 2.10 Preparing a NC program in Teach mode

### 2.10.1 Setting zero points

The parameter P11804 (tool carrier - length) must be loaded with the right values and the tool dimension must be active.

Drive axes in the desired zero point position.

Call up function „**Command=Actual**“ and store with **‘Enter’**.  
Herewith the current actual values of the axes are transmitted to the zero point memory.

In this way different zero pointes can be set.

If these zero point shifts should be active in manual operation mode, the parameter P8758 has to be loaded with the desired value (G54 to G59).

In automatic mode, the call up is made with the functions G54...G59.

Remark:

The zero point shifts are only effective in the tool coordinate system (G48) or in the workpiece coordinate system (G49).

### 2.10.2 Enter a program with “Teaching”

It is advisable, to mark the workpiece with all known or determining „Teach-points“. This facilitates later a fast discovering of the individual NC blocks, to insert in the program certain data and/or functions.

A further help would be, if the stored „Teach-points“ would be written in a list with the corresponding block number, e.g. Point 5 = block no. 80.

The stored zero point shift, on which the NC program refers, can be activated with parameter P382.

Select mode of operation „Positioning“.  
Approach zero point position with a positioning block,  
e.g. N10 G0 G55 X0 Y0 Z0 A0 B15

The mode of coordinate, in which the command / actual data were stored (P8751), must be inserted in the block over the corresponding G - function (G48, G49).

Select manual operation mode:  
Enter and store program number and the corresponding functions and technological data in the designated NC blocks,  
e.g. N10 T1 M16  
N20 G55 G49 FOR... S .... X ... .. Y.. .... Z.....

With „continuous drive“ or „step drive“ the desired position is approached with all axes. If all axes are in their anticipated position, the position is stored with the function ‘Command=Actual’ and ‘Enter and transmitted to the indicated block.  
e.g. N30 X ... .. Y.. .... Z.. .... A.. .... C.. ....

The next Teach - points are started and stored likewise.


Subsequently the program is optimized by inserting feedrate, number of revolutions etc.

After reviewing the program and after a test run, the program is finished.

2.11 Program input with graphic support (outline path)


2.11.1 General

Menu tree



2.11.1 General (continued)

With pushing from key  the menu for NC programming seems.




- F1 Channel
- F2 Selection
- F3 Adjustments
- F4 Program input
- F5 Copy <->

2.11.1 General (continued)

Program input

With pushing of key F4 (within the display frame) seems the program selection. The paragraph of a new program can be input with the numerical keyboard.



- F1 Channel
- F2 Cycle/program
- F3 -
- F4 Program input according to DIN / ISO
- F5 Program input with outline path

2.11.1 General (continued)

With the cursor keys an existing program can be chosen or the number of a new program can be input with the numerical keyboard. After pressing the key F5, the picture with the coordinates appears.

With the keys  (page up) and , the picture can be enlarged or reduced (zoom function) for a better view.


New outlines can be inserted continuously whereby a blue point is indicating the inserting place.

With the keys  (Pos1) and  (End) NC blocks can be moved forward and backward, they do then appear in red. Those moved NC blocks can be inserted or deleted with the keys  (Change) or .


The block numbers are automatically numbered continuously (increased).

Max. 100 blocks can be programmed in a program with GPE.

Programming is finished and the program is stored with F7.




Key field operating panel



and suitable keys on the PC

## 2.11.1 General (continued)


## Basic menu 1 (switch with F6)



- F1 Insert point
- F2 Insert straight line
- F3 Arc G2 (clockwise)
- F4 Arc G3 (counter-clockwise)
- F5 Insert phase and rounding

## 2.11.1 General (continued)

## Basic menu 2 (switch with F6)



- F1 Program edit with full function range (F, G, M etc.),  
if a ASCII keyboard available actual
- F2 Processing direction turn around
- F5 Outline reflect
- F4 Horizontal zero setting
- F5 Vertically zero setting

### 2.11.2 Inserting a point

With the numerical keyboard the coordinates of one point can be input and inserted with key .




The input point is started with rapid traverse (G00).

### 2.11.3 Insert a straight line

With the numerical keyboard the coordinates of a straight line can be input and inserted with key



. One sets always at the blue point.




Selection of the different types of the straight line generation:

- F1      Linear interpolation with Input of the terminator point coordinates
- F2      Linear interpolation with Input of length and start angle relative
- F3      Linear interpolation with Input of length and start angle absolutely
- F4      Linear interpolation with Input of angle and 1/2 terminator point,  
i.e. that only one of the coordinates must be input.  
The coordinate input last is taken over.

2.11.3 Insert a straight line (continued)


linear interpolation with Input of the terminator point coordinates

The terminator point coordinates input from the start point to a linear (G1) is inserted.



Linear interpolation with the terminator point coordinates (E) Z and X

Example



2.11.3 Insert a straight line (continued)

linear interpolation with Input of length and start angle relative

A linear with length and start angle is relatively inserted by the start point.




Linear interpolation with length (l) and Start angle (SW) relative to the preceding block


Examples:

Angle relative 0°

i.e. tangential to the preceding block



Angle relative 45° to the preceding block



2.11.3 Insert a straight line (continued)

linear interpolation with Input of length and start angle absolutely


A linear with length and start angle is absolutely inserted by the start point.



Linear interpolation with length (l) and final angle (EW) absolutely

Example:


Angle absolutely 0°



2.11.3 Insert a straight line (continued)

linear interpolation with Input of final angle absolutely and 1/2 terminator point


The terminator point coordinates with 1/2 terminator point and final angle, input from the start point to, absolutely a linear is inserted.




Linear interpolation with 1/2 terminator point and final angle (EW) absolutely  
 The indicated angle actual of the final angles the programmed straight lines with that indicated direction in Z or X.

Examples:

Final angle absolutely 60° to Z




Final angle absolutely 30° to X



### 2.11.4 Inserting an arc

With the numerical keyboard the coordinates of an arc can be input and inserted with key . One sets always at the blue point.




- F1            Circular interpolation with terminator point coordinates and radius
- F2            Circular interpolation with terminator point and centre point
- F3            Circular interpolation with radius and final angle
- F4            Circular interpolation with radius and 1/2 terminator point  
i.e. that only one of the coordinates must be input.  
The coordinate input last is taken over.

2.11.4 Inserting an arc (continued)

Circular interpolation with terminator point coordinates and radius



Circular interpolation in the clockwise direction with terminator point coordinates (E) Z and X and radius (r)




2.11.4 Inserting an arc (continued)

Circular interpolation with terminator point and centre point




Circular interpolation in the clockwise direction with terminator point coordinates (E) Z and X and Mittelpunktkoordinaten (m) Z and X




2.11.4 Inserting an arc (continued)

Circular interpolation with radius and final angle



Circular interpolation in the clockwise direction with radius (r) and start angle (SW) and final angle (EW)




2.11.4 Inserting an arc (continued)


Circular interpolation with radius and 1/2 terminator point



Circular interpolation in the clockwise direction with radius (r) and 1/2 final position (Z or X)



2.11.5 Inserting a chamfers or roundness



- F1 Chamfers form with leg length
- F2 Round off with radius
- F3 Circle tangential tie up
- F4 Circle with linear tangential
- F5 Combination linear with linear

2.11.5 Inserting a chamfers or roundness (continued)

chamfers form with leg length




Chamfers at an edge with leg length and angle (w)

Selection of the length #: 0 1. Length


#: 1 2. Length

Examples:




2.11.5 Inserting a chamfers or roundness (continued)

Rounding off with radius




Corner-round off with radius (r)

Example:



2.11.5 Inserting a chamfers or roundness (continued)


Circle tangential tie up



Circular interpolation with corner point and tagentieller binding


G2 or G3 become automatically according to the position of the terminator point (E, E') selected

Example:



2.11.5 Inserting a chamfers or roundness (continued)


Circle with linear tangential



Combination circle - linear with tangential binding


The position of the transition point (p) actual unknown.

Example:



2.11.5 Inserting a chamfers or roundness (continued)


Combination linear - linear



Combination linear - linear  
 with start angle, final angle and  
 Terminator point with the coordinates Z and X  
 The start angle actual relative  
 to the preceding block.

The position of the transition point (p)  
 actual unknown.

Example:



**2.11.6 Editing**

If the processing direction determined, still the functions (F, T, G, M) know actual are inserted into the program.




- F1 Program edit with full function range (F, T, G, M, P etc.),  
if a ASCII keyboard available actual
- F2 Processing direction turn around
- F3 Mirrors (in both axes)
- F4 Horizontal zeros (settings the white point on zero)
- F5 Vertically zeros (settings the white point on zero)

2.11.6 Editing (continued)

**Program edit with full function range**

The program can with full function range (F, T, G, M, P etc..) are edited, if a ASCII keyboard available actual





## 3. Program configuration

3.1	Program	3 - 2
3.2	Block	3 - 2
3.3	Word	3 - 2
3.4	Mathematical expression	3 - 2
3.5	Block functions	3 - 3
3.6	Syntax	3 - 4
3.7	Feed	3 -13
3.8	Spindle speed	3 -14
3.9	Input / output (I/O)	3 -15

## 3. Program configuration

### 3.1 Program

Each program begins with a program number with a maximum of 7 digits (DOS - PC) and/or 9 digits. The program consists of individual blocks.

### 3.2 Block

Each block is identified by a block number with a maximum of 10 digits. A block is made up of various words, which contain all instructions for an operation. The block length is variable (maximum 200 signs).

Blocks are identified in the program with ascending block numbers. This determines the sequence when the program is running and means that identical block numbers are not acceptable.

### 3.3 Word

A word consists of an address and a data section. The word length is variable. All words which can be contained in a block are included in the following table.

### 3.4 Mathematical expression

A number can be also replaced by a mathematical expression in round brackets.

For example:  $((110 + P20) / 3)$

## 3.5 Block functions

Word	Address	No. of words per block	Data digits	Dimensional unit	Effect	Description in section
Block number	N	1	10 #			block by block
Feed	F	1	x ~	mm/min	modal	3.
Spindle speed	S	8	x ~	1/min	modal	3.
Traverse conditions	G	8 *	10 #		modal/bl.-by-bl.	4.
Circle centre point	I / J / K	1	x ~		modal	4.
Circle radius	R	1	x ~		modal	4.
Cycle	G	8 *	10 #		block-by-block	5.
Additional functions	M	8	3 #		modal/bl.-by-bl.	6.
Tool	T	1	10 #		modal	7.
Parameters	P / q	x	x		modal/bl.-by-bl.	8.

Key: ~ Floating point  
 # Integer

\* Traverse condition and cycle together 8 per block


All other letters can be used for axis terms.

### 3.6 Syntax

Fundamental construction of a NC block:

Example :

```
N10 G01 F100 T03 M100 P30:(P20+35)*3 X200.0000 Y400.550 { comment }
```



Block length = 200 signs

## 3.6 Syntax (continued)

### General functions

- / Block skip
- \ Chain blocks, i.e. several blocks are joined to one NC block.
- () Bracket functions, mathematical expressions or comment
- { } Bracket comment
- :
- \$ Signal for hexadecimal numbers  
**Hexadezimale expressions must be completed with the separating sign( ; )!**  
e.g.: N10 G01 F1000 P500 : \$1AF; X: P500

### Axes

Axes can be marked:

- with a letter X, Y, Z, U, V, W . . .  
X100, Z33
- with a letter and index 1 to 8 X1, X2, X3 . . .  
X2:100, Z1:33 . . .

### Clear parameter content

P500: - - clears the content of P500



**3.6 syntax (continued)**

**Comparison operators**

<p>= Equal &gt; Larger &lt; Smaller &lt;&gt; Unequal &gt;= =&gt; larger equal &lt;= &gt;= smaller equal</p>	<p>Example : P500=110.50 (Skip to block 50, if the content of P500 = 110)</p>
---	---

If the skip - condition is fulfilled, it is skipped to the indicated block number.

**Calculation operators**

<p>* Multiplication + Addition - Subtraction / % Division   mod Modulus</p>	<p>Example .: P500:P200*5 P500:P200+P201 P500:P200-1 P500:P200 / 2 P500:P200 10</p>
---	---

<p>sin cos tan asin acos atan</p>	<p>The trigonometrical functions use degree ! P500:sin(90) P500:acos(P10)</p>
---------------------------------------	---

<p>or and not</p>	<p>Bit operations P500:P500 or \$100;</p>
-------------------	---

<p>sqr Square root int Integer value intr Rounding on integer abs Amount ln Logarithm with basis e lay Logarithm with basis 10 exp Exponent</p>
---

<p>del test if cleared</p>	<p>P500:del(510) Feedback value : 0 parameter not cleared 1 parameter cleared</p>
----------------------------	---

Functions are always written in lower-case letters!

## 3.6 syntax (continued)

### Definition of a tool radius t

If no tool administration is existing in the system, a temporary correction radius can be defined with identification 't'. With this correction radius, the subsequently activated radius correction (G41/42) is working.

Example:

```
N10..  
N20 t:0.5  
N30 G1 X100 Y100 G42  
N40..
```

When programming 't'

- the tool radius is written and
- the tool radius correction is deleted in the active data block (P8150 ...)

The quadrant of the 't'-correction is always 0!

### 3.6 Syntax (continued)

#### Syntax of symbolic variables

Symbolic variables always do start with the sign '\_' (e.g.: \_abs, \_test5, ...), they may have a maximum length of 30 signs. Capital and small letters are allowed, but the meaning of \_karl may not be the same as \_Karl! (case-sensitive).

#### Binding a symbol to a parameter

```
_wegx ::= 500;
```

According to this definition, \_wegx is in place of P500, i.e. both expressions are equivalent according to the above mentioned example (\_wegx  $\longleftrightarrow$  P500).

```
P500 : 10  
_wegx:=10
```

Indexing is allowed at parameter variables.  
Example

```
_wegx(0) := 10; (d.h. P500:10)  
_wegx(1) := 11; (d.h. P501:11)
```

#### Internal variables

```
_wegxy := 500;
```

If a value is assigned to a variable, which is not 'bound' to a parameter, this variable is allocated as internal variable. That means that values can be stored without using a parameter.

Variables that are not initialized have the value 0.

Internal variable do only exist as long as the NC program is active.

Internal variables can not be displayed directly (e.g. at a program test).

Example

```
n10 _test1::=12 (Binding to P12)  
N20 _test2:=10 (internal variable)  
N30 G00 X:_test1 Y:_test2  
N40 ...
```

### 3.6 Syntax (continued)

#### Text output of NC programs

Arbitrary texts from NC programs can be displayed in the message line. When switching back to MANUAL, texts that are eventually standing in line, are deleted.

#### Delete syntax messages

```
N10 !  
N10 M33 P1:23 !
```

The identification '!' may also be programmed with other NC block elements in the same NC block. However, '!' has to be the last sign of the block!

#### Displaying messages with predefined colours

```
N10 ! this is a message text white letters on blue bottom  
N20 !0, this is a message text black letters on grey bottom  
N30 !1, this is a message text white letters on blue bottom
```

#### Displaying messages with colour selection that can be defined freely.

```
N40 !S8E, this is a message text (yellow on black)
```

```
N40 !code, this is a message text code = HF + VF
```

HF (background colour)	VF (Forefront colour)
80 black	0 black
90 blue	1 blue
A0 green	2 green
B0 turquoise	3 turquoise
C0 red	4 red
D0 magenta	5 magenta
E0 brown	6 brown
F0 light grey	7 light grey
	8 dark grey
	9 light blue
	A light green
	B light turquoise
	C light red
	D light magenta
	E yellow
	F white

## 3.6 Syntax (continued)

Working sequence of the block interpreter

1. Parameter calculations, Parameter allocations  
are executed in the sequence programmed in the NC block.
2. Parameter skips  
are executed in the sequence programmed in the NC block.
3. M - Function - Skips  
are executed in the sequence programmed in the NC block.
4. Sub-program call M28

### The sequence of the block elements when dispatching at PLC (real time)

1. Block number
2. Parameter (real time parameter)
3. S-value
4. T-value
5. M-function before traverses / after traverses

## 3.6 Syntax (continued)

### Enlarged syntax

The NC interpreter offers with System-Calls (sc) further possibilities, to shift the interpreter -mode or to trigger functions.

#### Syntax **sc: n**

##### Function numbers

- 0 Activating of interpreter-mode 0, standard mode.
  - Is always preset at NC program start.
  - Each block produces a block end. When switching on the interpreter to the next NC block a block change command results, with which the NC block informations are transmitted to the following modules.
- 1 Activating of interpreter-mode 1, supervision mode.
  - In mode 1 the block change command is suppressed. When switching the interpreters to the next NC block no block change command results. Because the analyzed NC block elements are only transmitted to the following modules with block change, they remain now for the time being in the block interpreter. (This does not count for the additional functions.)
  - When switching back to mode 0 a block change command is given.
- 2 Activating the interpreter mode 2
  - supervision mode at M26
  - as mode 1, however, when switching the mode, the system waits until it gets a feedback from the previous NC block. E.g. if you want to make some calculations or supervising loops while an axis is moving, the calculation and/or test loop will start at the beginning of this movement (and the pipeline of the NC control is previously deleted).
  - A block change command is sent when switching back to mode 0.

## 3.6 Syntax (continued)

Example of a supervision loop

While N10 is processed, supervision functions can be perceived in the loop (N30 . . . N50).

N10	G01 F100 X1000	
N20	sc :1	changeover in mode 1
N30	P500>P501.140	skip, if supervision loop should be left.
N40	. . .	
N50	M23.30	skip to the beginning of the loop
N140	. . .	
N150	sc :0	end of the supervision loop
N200	G00 X200	

- 100 Triggering of a block change command  
- In interpreter mode 1 a block change can be forced herewith.

### 3.7 Feed

The feed with the address letter F is programmed in mm or inch according to the set unit of measurement.

G94, G95 and G99 determine the feed modification.

- G94 Feed in mm/min
- G95 Feed in mm/r
- G99 Block end feedrate in mm/min


A programmed feed is effective modally and can only be overwritten with another feed.

Through positioning in rapid traverse (G00) the previously stored effective feed is not cleared, but becomes effective again with G01, G02 and G03.

With the feed-override-potentiometer the programmed feed can be changed in the area of 0 to 120%.

- F path feed
- f final feed, i.e. path feed, which are achieved at the end of block.

Example: N50 X400  
 N60 G1 F6000 f1000 X5600



## 3.8 Spindle speed

The spindle speed is programmed with the address letter S. With index 1 to 8 several spindles can be programmed.

Example: S1000

S1:1000

:

S8:8000

G96 and G97 determine the speed modifications.

G96 constant cutting speed in mm/min

G97 number of revolutions in 1/min

The spindle speed is effective modally and can only be overwritten through another spindle speed.

With the spindle-override-potentiometer the programmed spindle speed can be changed in the area of 0 to 120%.

## 3.9 Input / output (I/O)

### DOS data format

#### Structure of a NC program file

Blank line (CR, LF)

Identification P/Z with program number (program number with max. 9 digits)

NC block beginning with N or /N

...

...

...

NC block

Program end sign (#)

EOF-sign (default : character 04)

Blank line (CR, LF)

Example:

File name : P123456

P123456

N10 G0 X0 Y0 Z0

N20 F100 G1 X100

N30 M30

#



### 3.9 Input / output

#### Structure of a parameter file

Blank line (CR, LF)  
 Identification D (at identification D: parameter status is not overtaken  
 exception: If mantissa programs,  
 (at identification D+: parameter status is overtaken  
 Exception: If mantissa programs,  
 however in the parameter status the loading bit  
 (byte 1, bit 1) is not set, than the bit  
 ' parameter loaded ' is set!

example:  
 D+  
 K1 P1: 123 S:\$32000100  
 in this case the status becomes  
 to S:\$32000101!

q parameter number : parameter content [S: parameter status] \* \* [ ] optional

...  
 ...  
 ...

Program end sign (#)  
 EOF-sign (default : character 04)  
 Blank line (CR, LF)

### 3.9 Input / output

#### Structure of a parameter file

Example:

Filename : D123

```
D
q 0: — S:$00000000
q 1: 8 S:$00000001
q 2: 2
q 3: 30000
q 4: —
q 5: — S:$00000000
#
```

or

```
D
K1:P 10: 1 S:$00000009
K1:P 11: 100 S:$0000000D
K1:P 12: 200 S:$00000001
K1:P 13: 5
K1:P 14: —
K1:P 15: 2
#
```

#### Extensions

starting from version 080 :

With identifier D+ knows the parameter status with the function ' SET ', or with which old parameter status with the function ' OR ' is set.

Example: Parameter status with function ' SET ' :  
K1 P1: 123 S:\$32000101

Parameter status with function ' OR ' :  
K1 P1: 123 S|\$32000101



## 4. Traverse functions

4.1	G00 Positioning at rapid traverse rate	4-6
4.2	G01 Linear interpolation	4-7
4.3	G02/G03 Circular interpolation	4-8
4.4	G123 Automatic selection of linear and circular interpolation	4-12
4.5	G04 Dwell	4-13
4.6	G05/G06/G07 Driving direction of round axes	4-14
4.7	G08/G09 Precision stop block by block	4-16
4.8	G10/G11 Polar coordinate system	4-17
4.9	G12 Contour path, rapid programming	4-22
4.10	G13/G14 Tangential axis	4-25
4.11	G15/G16 Polar transformation	4-26
4.12	G17/G18/G19 Plane selection	4-30
4.13	G28/G29 Precision stop modal	4-32
4.14	G40/G41/G42 Milling cutter path correction offset	4-33
4.15	G43/G44 Axis correction	4-34
4.16	G45/G46 Turning of coordinates	4-35
4.17	GG47/G48/G49/G147 Robot transformation	4-46
4.18	G50/G51/G52 Spline interpolation	4-59
4.19	G53/G153 Machine zero point	4-62
4.20	G54 to G59 Zero points	4-63
4.21	G60/G61/G62 Mirror imaging of coordinates	4-64
4.22	G63/G64 „100% feed rate“	4-66

**4. Traverse functions**

4.23	G66 All offsets off	4-67
4.24	G90 Absolute dimension input	4-68
4.25	G91 Incremental dimension input	4-59
4.26	G92 Zero point shift	4-70
4.27	G94/G95 Feed modification	4-71
4.28	G96/G97 Number of revolution modification	4-72
4.29	G99 End feed, traverse dependant feed adaptation	4-74

## 4. Traverse functions

The traverse functions, together with the traverse information, establish the geometric part of the program. They consist of the address letter G and a 10-digit number. One block may contain 8 traverse functions.

If the traverse functions and the appropriate traverse information are programmed in different blocks, the traverse functions in the program should always precede the traverse information. Traverse functions become effective before the programmed traverse information.

The following table contains the traverse functions made available by the control.

Traverse functions within a group overwrite each other mutually (in addition G92 is overwritten by G53 to G59).

The traverse functions preset at the start of a program are identified by an \*.

The traverse functions in the program are displayed when the '?' key is pressed (except for the traverse functions which act block-by-block).

**4. Traverse functions (continued)**

Traverse functions		Effect
G00	Positioning at rapid traverse	modal
G01*	Linear interpolation	modal
G02 / G03	Circular interpolation, CW/CCW	modal
G123	Automatic selection of linear and circular interpolation	modal
G04	Dwell	block-by-block
G05 / G06 / G07	Driving direction of round axes	block-by-block
G08 / G09	Precision stop, on/off	block-by-block
G10 / G11*	Polar coordinate programming, on	modal
G12	Contour path, rapid programming	block-by-block
G13*/ G14	Tangential axis off/on	modal
G15*/ G16	Polar transformation off/on	modal
G17 / G18 / G19	Plane selection XY / XZ / YZ	modal
G28 / G29*	Switching on/off precision stop	modal
G40*/ G41 / G42	Milling cutter path correction offset, clearing / left / right	modal
G43*/ G44	Axis correction off/on	modal
G45 G46*	Turning on/off	modal
GG47/G48/G49	Robot transformation off / Tool / workpiece coordinates	modal
G147	Transformation off	modal
G50/G51/G52	Spline interpolation	modal
G53*	Machine zero point	modal
G153	Zero point shift off	modal
G54...G59	Zero points	modal
G60*/ G61 / G62	Mirror imaging, off	modal

4. Traverse functions (continued)

Traverse functions		Effect
G63 / G64*	Switching on feed rate 100%	modal
G66	Switching off all offsets	block by block
G90*	Absolute dimension input	modal
G91	Incremental dimension input	modal
G92	Zero point shift	modal
G94	Feed in mm/min	modal
G95	Feed in mm/r	modal
G96	Constant cutting speed	modal
G97	Number of revolution in 1/min	modal

4.1 G00 positioning at rapid traverse rate

Positioning at rapid traverse rate is called up by G00.

All axes can be traversed simultaneously as long as the machine tool is designed for this. Absolute and incremental dimension input are both possible.

G00 acts modally and can be overwritten by G01, G02, G03, G50, G51 and G52.

When traversing at rapid rate the programmed point is homed into via the shortest route. The axis with the longest programmed traverse distance is traversed at rapid rate and determines the positioning time. The speed of the other axes is chosen by the control system such that they reach their end point simultaneously with the fastest axis.

The feed rate override potentiometer is also operative during positioning at rapid rate.

Any feed rate stored in front of G00 again becomes operative after a rapid traverse through G01, G02, G03, G50, G51 and G52.

Example: positioning at rapid rate




Figure 4-1

4.2 G01 Linear interpolation

The programmed target position is homed into by G01 along a straight line. The programmed feed rate is the contouring rate.

G01 acts modally and can be overwritten by G00, G02 and G03. G01 is automatically preset at start of the program.

Example: linear interpolation




Figure 4-2

**4.3 G02 / G03 Circular interpolation**

When inputting G02 and G03, the programmed target position is homed into along a circle segment having a centre point determined by the interpolation parameters I, J and K and/or having a radius determined by R.

**G02 signifies clockwise circular interpolation and  
G03 signifies counter-clockwise circular interpolation**

The G02 / G03 functions act modally and overwrite each other mutually and can be cleared by G00, G01, G50, G51 and G52.

**Circle centre point**

The circle limit point and the interpolation parameters can be input simultaneously using either absolute or incremental dimensions. For complete circle programming the limit point is equal to the starting point.

Interpolation parameter

address letter            Circle centre point distance in direction

---

I	X axis
J	Y axis
K	Z axis

The speed at which the circle is started is proportional to the stored feed rate which can be adjusted between 0 and 120% by the feed rate override potentiometer.

### 4.3 G02 / G03 Circular interpolation (continued)

The interpolation parameters can be input in such a way that the deviation at A is less than or equal to 10 increments. If A is greater than 10 increments the program is still not shut down. In all cases the control system recalculates the circle centre point where  $R = (R1 + R2)/2$ .




Figure 4-3

#### Three-dimensional circular interpolation

A programmed circle is three-dimensional driven off, if in a block 3 axes (X, Y, Z) and 3 circle center points (I, J, K) are indicated.

With programmed  
G02 is executed a long arc,  
G03 is executed a short arc.

The area levels G17, G18 and G19 are here without meaning.

4.3 G02 / G03 Circular interpolation (continued)

The main planes for the circular interpolation and tool correction offsets are selected by G17, G18 and G19 (see also 4.12 Plane selection).

Main plane Parameters for circle centre point

XY	IJ
ZX	KI
YZ	JK

Example: clockwise circular interpolation

End point and circle centre point are programmed in absolute dimensions (G90).

A = Starting point  
B = End point




Figure 4-4

4.3 G02 / G03 Circular interpolation (continued)

The circle end point can be input in absolute or incremental dimensions. Full circle programming is not permitted.

The smaller and larger angular paths are described by positive and negative radius information respectively.




Figure 4-5

Radius R must be greater than or equal to the semi-chord AB/2 in order to give a centre point. If the R being input is less than the semi-chord, message 1407 is initiated and the control system selects an  $R = AB/2$  without the program being shut down.

4.4 Automatic selection of linear and circular interpolation

G123 selects automatically after analysis of the position of three points G01 / G02 / G03:

- 1st point position
- 2nd point programmed position in the actual block
- 3rd point programmed position in the next block

Example G123 -> G01

N10	G01	X20	Y50	position
N20	G123	X70	Y45	position in actual block
N30		X130	Y40	position in next block

Example G123 -> G02

N10	G01	X20	Y50	position
N20	G123	X70	Y71,5	position in actual block
N30		X130	Y63	position in next block

Example G123 -> G03

N10	G01	X20	Y50	position
N20	G123	X70	Y18	position in actual block
N30		X130	Y18	position in next block




Figure 4-6

4.4 Automatic selection of linear and circular interpolation

Program example

```

P2050
N2                                     { G123 free outline }
N10  G49 G56 G0 F3000  X:0          Y:0          Z:2
N20                                     X:21.1       Y:9.300     Z:-1   { point 1 }
N30  G123 G1          X:19.6       Y:54.3
N40                                     X:45.0       Y:61.0     { point 2 } selection G02 }
N50  G123             X:63.0       Y:46.7     { point 3 }
N60                                     X:82.9       Y:30.5     { point 4 } selection G01 }
N70  G123             X:81.2       Y:18.8     { point 5 }
N80                                     X:108.8      Y:21.6     { point 6 } selection G03 }
N90  G123             X:101.0      Y:33.0     { point 7 }
N100                                X:110.3      Y:64.4     { point 8 } selection G02 }
N110                                X:108.2      Y:40.6     { point 9 }
N120                                X:131.8      Y:25.5     { point 10 } selection G03 }
N130                                X:135.7      Y:13.8     { point 11 }
N140                                X:138.447   Y:4.4      { point 12 } selection G01 }
N150                                Z:2
N160  M30
    
```




Figure 4-7

### 4.5 G04 Dwell

A dwell is called up by G04 and can be programmed between 0 and 999.999 s. The dwell must be input in the correct format, i.e. leading and trailing zeros and the decimal point should be input.

Example: G04.001.50 (1.5 s dwell)

The G04 function is only operative in the block in which it was written. G04 is operative after the traverse information and before the M functions subsequently active.

**4.6 G05 / G06 / G07 driving direction of round axes**

**G5 driving direction positively, against clockwise direction.**

**G6 driving direction negatively, in the clockwise direction.**

**G7 driving direction neg. / pos., selection shortest path to the target position.**

Examples driving direction, if will absolutely proceed!

Function	Start pos	Target pos	Direction.	Drive	Display	
- G5	0	90	pos.	90°	90	
- G5	270	35	pos.	125°	35	
- G5	150	-45	pos.	165°	315	
- G5	350	-10	not applicable	0°	350	initial pos = target pos
- G5/G91	70	30ink.	pos.	30°	100	
- G5/G91	180	-150ink.	neg.	150°	30	

Note: With incremental the technique the functions G5/G6/G7 are ineffective.  
The driving direction certainly by the sign.

Function	Start pos	Target pos	Direction.	Drive	Display	
- G6	0	90	neg.	270°	90	
- G6	270	35	neg.	235°	35	
- G6	150	-45	neg.	195°	315	
- G6	350	-10	not applicable	0°	350	initial pos = target pos
- G6/G91	70	30ink.	pos.	30°	100	
- G6/G91	180	-150ink.	neg.	150°	30	

Function	Start pos	Target pos	Direction.	Drive	Display	
- G7	0	90	pos.	90°	90	
- G7	270	35	pos.	125°	35	
- G7	150	-45	pos.	165°	315	
- G7	350	-10	not applicable	0°	350	initial pos = target pos
- G7/G91	70	30ink.	pos.	30°	100	
- G7/G91	180	-150ink.	neg.	150°	30	

---

**4.7 G08 / G09 Precision stop block-by-block**

**G08 precision stop, block-by-block, On**  
**G08 precision stop, block-by-block, Off**

G08 initiates a precision stop at the end of a block.

The function overwrites a programmed G29 block by block. The precision stop is automatically set block by block with G00 and G81 to G85.

G09 overwrites a precision stop programmed with G28 block by block

## 4.8 G10 / G11 Polar coordinate system

### **G10 Polar coordinate system on** **G11 Polar coordinate system off**

The function G10 is used to activate the programming of target points in polar coordinates. The function G11 deactivates this function. Both functions act modally.

The coordinates programmed in the block with G10 define the pole, but not the travel of the axes (this is only valid for the two coordinates of the interpolation plane defined with G17...G19). If the coordinates are not programmed, the existing pole is kept.

At the program end or if the program is interrupted, the programmed pole as well as the polar radius (x) and polar angle (c) are cleared. Polar radius (x) and polar angle (c) act modally.

The polar coordinate system plane corresponds to the interpolation plane defined with G17...G19. The polar radius is always interpreted as a positive value!

Polar radius and polar angle can be corrected with G44.

4.8 G10 / G11 Polar coordinates (continued)

Definition of the poles in different interpolation planes




Figure 4-8

Parameters used for polar coordinate system

G10 Activating the polar coordinate input position with radius vector  $x$  and polar angle  $c$   
 G11 Deactivating the polar coordinates

G17 XY plane pole P() is in plane XY, the X axis is the polar axis  
 G18 ZX plane pole P() is in plane ZX, the Z axis is the polar axis  
 G19 YZ plane pole P() is in plane YZ, the Y axis is the polar axis

q150 Polar coordinate system: identification for radius vector (e.g. 'x')  
 Input of the ASCII-code Default: 'x'

q151 Polar coordinate system: identification for polar angle (e.g. 'c')  
 Input of the ASCII-code Default: 'c'

4.8 G10 / G11 Polar coordinates (continued)

Program example: Coordinates in X/Y

```

P656
N05 G55 G49 G00 F3000 T1 M16
N10 X:0 Y:0 Z:2 { point 1 }
N20 G01 Z:-2
N30 X:90 Y:0 { point 2 }
N40 X:60 Y:25 { point 3 }
N50 X:90 Y:60 { point 4 }
N60 G03 X:30 Y:85 R:34 { point 5 }
N70 G02 X:45 Y:55 R:18 { point 6 }
N80 G01 X:0 Y:0 Z:2 { point 1 }
N90 Z:2
N100 M30
    
```




Figure 4-9

4.8 G10 / G11 Polar coordinates (continued)

Program example: Point of pole is the null point X:0 / Y:0

```

P657
N05 G55 G49 G00 F3000 T1 M16
N10 X:0 Y:0 Z:2 { point 1 }
N20 G01 Z:-2
N30 G10 X:0 Y:0 { point 1 pole set }
N40 x:90 c:0 { point 2 }
N50 x:65 c:22.619 { point 3 }
N60 x:108.166 c:33.690 { point 4 }
N70 G03 x:90.138 c:70.559 R:34 { point 5 }
N80 G02 x:71.063 c:50.710 R:18 { point 6 }
N90 G01 x:0 c:0 { point 1 }
N100 G11 Z:2
N110 M30
    
```




Figure 4-10

4.8 G10 / G11 Polar coordinates (continued)

Program example: Point of pole are thr points 2, 3 und 6

```

P659
N05 G55 G49 G00 F3000 T1 M16
N10 X:0 Y:0 Z:2 { point 1 }
N20 G01 Z:-2
N30 X:0 Y:0 { point 2 }
N40 G10 X:90 Y:0 { point 2 pole set }
N50 x:39.05 c:140.194 { point 3 }
N60 X:60 Y:25 { point 3 pole set }
N70 x:46.09 c:49:398 { point 4 }
N80 G11 G03 X:30 Y:85 R:34 { point 5 pole reset }
N90 G02 X:45 Y:55 R:18 { point 6 }
N100 G10 X:45 Y:55 { point 6 pole set }
N110 G01 x:71.062 c:230.710 { point 1 }
N120 G11 Z:2 { point 1 pole reset }
N130 M30
    
```




Figure 4-11

4.9 G12 Rapid graphical programming environment

Contour sections can be linked by of straight lines and circles.

This function acts block-by-block.

Parameter	Leg	Radius
	P70	P71

Rapid programming is only carried out with blocks in which the distance to be traversed is unequal to zero (differences in distances are unequal to zero for straight lines, radius is not equal to zero for circles).

Blocks with distances equal to zero are carried out at the start of the chamfer or circle segment.

Linear programming

A chamfer can be inserted at the intersection of two straight lines.

The length of the chamfer is given by P70 and the intersection point SP is programmed in the selected interpolation plane.




Figure 4-12

4.9 G12 Rapid graphical programming environment (continued)

Radius programming

A circle segment can be inserted at the intersection point of

- two straight lines,
- one straight line and one circle,
- two circles.

The radius of the circle is given by P71 and the intersection point SP is programmed in the selected interpolation plane.




Figure 4-13

4.9 G12 Rapid graphical programming environment (continued)

Program example: Outline path short programming with radius and leg

```

P391
N10 G55 G29 G48 G00 F2000 T1 M16 X0 Y0 Z2
N20 G01 Z:-1
N30 G12 P71:8 X:40 Y:0 { point 1 radius }
N40 G12 G02 R65 P71:28 X62.5 Y:91 { point 2 radius }
N50 G12 G02 R65 P71:15 X95 Y:35 { point 3 leg }
N60 G12 G01 P71:8 X120 Y:35 { point 4 radius }
N70 G12 G02 P71:12 I95 J35 X95 Y:10 { point 5 radius }
N80 G12 G03 P71:10 I70 J10 X45 Y:10 { point 6 radius }
N90 G01 X34.5 Y:10 { point 7 radius }
N100 G00 Z:2
N110 M30
    
```




Figure 4-14

## 4.10 G13 / G14 tangential axis

**G13 tangential axis off**  
**G14 tangential axis on**

G13 switches the tangential axis off.

G14 switches the tangential axis on.

With this function it is possible to control a round axis so that it is always in a certain position (tangential) to the path of the main axes.  
For example for band saws, glass cutting, moist collectors.




Figure 4-15

#### 4.11 G15 / G16 Polar transformation

**G15 Polar transformation off**  
**G16 Polar transformation on**

G15 switches the polar transformation off.

G16 switches the polar transformation on.

The polar transformation is applied for example for programming of uneven parts on a grinding machine or lathe with polar coordinate system. Usually the workpiece can be described more easily in the cartesian coordinate system. With the polar transformation G16 the control converts the cartesian coordinates (X/Y/Z) into polar coordinates (radius vector  $x$  and polar angle  $c$ ). This method is very advantageous, because it requires less time for contour featuring.

##### Definition of the polar coordinate system

With the polar coordinates each point of the coordinates are determined by the two values radius vector ' $x$ ' and polar angle ' $c$ '.




Figure 4-16 Polar coordinates with G 17 (XY - plane )

The radius vector  $x$  is the distance of point  $p(x,c)$  to the origin  $P(X_0,Y_0)$ .

The polar angle  $c$  is between the X-axis and the connecting straight line from the origin  $P(X_0,Y_0)$  to point  $p(x,c)$ .

The X - axis is marked as polar axis and the origin  $P(X_0,Y_0)$  as pole. The polar angle is positive, if it is measured from the pole axis X counter-clockwise direction. The angle is negative in clockwise direction.

**4.11 G15 / G16 Polar transformation (continued)**

Utilized parameter for polar coordinate system

G15 Selecting the polar coordinate transformation

G16 Call up of the polar coordinate transformation, input position with X, Y

G17 XY plane pole P() lies in XY Plane, X axis is polar axis

G18 ZX Plane pole P() lies in ZX Plane, Z axis is polar axis

G19 YZ Plane pole P() lies in YZ Plane, Y axis is polar axis

P11820 Polar coordinate axis (physical axis number)

e.g.

Byte 3, 2, 1: the first 2 axes (x, y) 00 02 01 Hex

Byte 4 : change of direction (Bit 2, 1)

P11821 Radius vector offset (ro) for polar coordinate transformation [mm ]

P11822 Polar angle offset (wo) for polar coordinate transformation [degrees]

P11823 Pole offset (po) for polar coordinate transformation [mm ]

4.11 G15 / G16 Polar transformation (continued)

Example: Polar transformation G16 for square contour




Figure 4-17 Square contour

```

N10 G17 G1 F1000 ; Definition of coordinate plane
...
N150 G16 X10 Y0 ; Call up polar transformation and X,Y
; are transformed accord. equation 2 into polar coorinates
; here: Xo = Yo = 0;
N160 X10 Y 20 ; Position X= 10 and Y= 20 are transformed into
; polar coordinates. Approach to transformed position
N170 X - 20 Y 20 ; X= -20 and Y= 20 are transformed into polar coordinates.
; Approach to transformed position
N180 X - 20 Y-10 ; X= -20 and Y= -10 are transformed into polar coordinates.
; Approach to transformed position
N190 X10 Y-10 ; X= 10 and Y= -10 are transformed into polar coordinates.
; Approach to transformed position
N200 X10 Y 0 G15 ; X= 10 and Y= 0 are transformed into polar coordinates.
; Approach to transformed position
; Switch off polar transformation.
N220 ...
N230 M30 ; Program end
    
```

4.11 G15 / G16 Polar transformation (continued)

Example: Polar transformation G16 for cam contour




Figure 4-14 Cam contour

```

N10 G17 G1 F1000 ; Definition coordinate plane
...
N150 G16 X20 Y0 ; Call up polar transformation and X,Y
; are transformed accord. equation 2 into polar coorinates
; here: Xo = Yo = 0;
N160 X10 Y 20 ; Position X= 10 and Y= 20 are transformed into
; polar coordinates. Approach to transformed position
N170 G2 X -10 Y 20 R11 ; X= -10 and Y= 20 are transformed into
; polar coordinates. Approach to G2 until transformed pos. N180
G1 X -20 Y0 ; X= -20 and Y= 0 are transformed into polar coordinates
; Approach to transformed position
N190 G2 X20 Y0 R22 ; X=20 and Y= 0 are transformed into polar coordinates
; Approach to G2 until transformed position
N200 G15 ; Switch off polar transformation.
N220 ...
N230 M30 ; Program end
    
```

4.12 G17 / G18 / G19 Plane selection

The main planes for circle interpolation and tool correction offsets are selected using G17, G18 and G19.

Traverse functions	Main plane	Parameters for circle centre point
G17	XY	IJ
G18	ZX	KI
G19	YZ	JK

These functions act modally and overwrite each other mutually. The plane preset is controlled by the PLC parameter „WZ“ tool axis.

The tool correction offset takes place in the given interpolation plane. The correction offset should be cancelled using G40 before changing the interpolation plane.




Figure 4-19

4.12 G17 / G18 / G19 Plane selection (continued)




Figure 4-20

### 4.13 G28 / G29 Precision stop modal

#### **G28 Switching on modal precision stop**

G28 initiates a precision stop at the end of a block. The tool traverses to the end point programmed in the block and stops.

Subsequently it traverses to the end point programmed in the next block and stops again.

The function acts modally and can be cleared by G29.

#### **G29 Switching off modal precision stop**

G29 switches off a precision stop programmed with G28.

The function acts modally and can be cleared by G28.

G29 is automatically set when the program starts.

### 4.14 G40 / G41 / G42 Milling cutter path correction offsets

#### G40 Clearing milling cutter path correction offsets

The milling cutter path correction offset programmed using G41 or G42 is cleared using G40.

G40 acts modally and can be cleared by G41 and G42. G40 is automatically set when the program starts.

#### G41 / G42 Actuating milling cutter path correction offset

A milling cutter path correction offset can be switched on using G41 and G42.

G41 effects a correction to the left of the programmed path.

G42 effects a correction to the right of the programmed path.

The reference direction is in the feed direction in each case.

The functions act modally, overwrite each other mutually and can be cleared by G40.

The feed rate is proportional to the milling cutter centre point path when the tool correction offset is switched on.

Further details on this subject appear in the section „Tool correction offset“.

## 4.15 G43 / G44 Axis correction

With G43 / G44 an axis correction can be programmed.

**G43 axis correction off**

**G44 axis correction on**

The programmed traverse informations in the block with G44 determine the axis correction, whereby no traverse is driven.

These corrections remain modally.

At program end or program abort these corrections are cleared, or switched off with G43.

A programmed G44 correction is a component, which is added on all further traverse information.

With G44 polar angles and polar radius can also be corrected.

Input: e.g.:

```
N100 G44 X10 Y20 Z30 axes do not drive !
```

```
N120 G01 F1000 X100 Y100 Z100 axes drive to X: 110, Y: 120; Z: 130
```

```
N130 G43
```

4.16 G45 / G46 Turning of coordinates

The „Turn“ function initiates the turning of a coordinate pair about a given angle E.  
 The traverse function G45 switches turning on, G46 switches the function off. G45 and G46 act modally.

G45 / G46 Geometric definition turning




Figure 4-21

X, Y Machine coordinate system

U, V Coordinate axes of the turned coordinate system

E Angle about which the machine system X axis is to be turned in the direction of the machine system Y axis in order to retain the UV coordinate system orientation.  
 Angle E is positive if measured counter-clockwise to the X axis and negative in the clockwise direction.

Uo, Vo Original UV coordinate system coordinates, referred to the machine XY coordinate system zero point.

Ub, Vb Point B coordinates in UV coordinate system.

Xb, Yb Point B coordinates in XY coordinate system, referred to the effective shift (NP and G92).

Converting the UV system coordinates into those of the XY system

$$Xb = (U \cdot \cos E - V \cdot \sin E) + Uo$$

$$Yb = (U \cdot \sin E + V \cdot \cos E) + Vo$$



**4.16 G45 / G46 Turning of coordinates (continued)**

Programming the coordinate origins U0, V0 (referred to the machine system zero point) and the turning angle E take place via parameters.

Parameter	Characteristic	Significance
P160	Uo	UV system original coordinate
P161	Vo	UV system original coordinate
P163	E	Turning angle

The parameters act modally.

The parameters P160, P161 and the reference axis for the turning angle are dependant on the plane set.

Plane set	P160	P161	Reference axis for turning angle
G17 (XY)	Xo	Yo	X axis
G18 (ZX)	Zo	Xo	Z axis
G19 (YZ)	Yo	Zo	Y axis

**Shifts with additive effect**

In addition to the adjustment values P160, P161, P163, shifts can be programmed which act additively with respect to the direction.

Parameter	Characteristic	Significance
P165	U	Shift in U
P166	V	Shift in V
P168	E	Turning angle incrementation

When one of these parameters is called up, it's value is added to the former value of the corresponding shift. The value obtained in this way acts modally. The original parameters are retained.

Cancellation of the additive shifts is by re-calling up the adjustment values P160, P161 or P163 (or by switching G45 off with G46).

The additive shifts are plane-dependent, as are the adjustment values.

**4.16 G45 / G46 Turning of coordinates (continued)****Mirror imaging of the turned coordinate system**

The mirror functions G61 and G62 are referred to the UV coordinate system:

G61 mirror images the U axis

G62 mirror images the V axis

The mirror imaged coordinates are expressed in the machine system XY in the following manner:

$$X_b = - (U \cdot \cos E - V \cdot \sin E) + U_0$$

$$Y_b = - (U \cdot \sin E + V \cdot \cos E) + V_0$$

**The effect on G92**

The shifts programmed using G92 are carried out.

**The effect on G66 on the turning function**

G66 initiates the block-by-block switching off (G46) of turning G45.

**Turning the circle centre point coordinates I, J, K**

Turning the circle centre point coordinates I, J, K takes place according to the turning of coordinates as described above.

4.16 G45 / G46 Turning of coordinates (continued)

Example 1 Repeated machining with turning




Figure 4-22

```

P1 N10 G45 G00 G54 Z2 P160:0 P161:0 P163:0 F2000 M24.4
N20 G00 X10 Y0
N30 G01 Z-1,5
N40 X40
N50 Y15
N60 X10 Y0
N70 Z2 P168:90 M25
N80 M30
    
```

The triangular shape ABC is to be machined four times with appropriate orientation of the +X, +Y, -X, -Y coordinate axes.

The machining sequence on the triangle is:

- 1st. Traverse A to B
- 2nd. Traverse B to C
- 3rd. Traverse C to A

## 4.16 G45 / G46 Turning of coordinates (continued)

### Program run, example 1

- Block 10 Switching on the coordinate turning function (G45)  
Input set-up data U0=10 (P160) Vo=0 (P161) E=0 (P163)  
Uo, Vo coincide with point A  
Approach to Z safety dimension, Loop input
- Block 20 Positioning to point A = Uo, Vo
- Block 30 Tool axis in-feed to machining depth
- Block 40 Machining along line AB
- Block 50 Machining along line BC
- Block 60 Machining along line CA
- Block 70 Traversing tool axis away for positioning, incrementing the turning angle to +90 deg., skip back to Block 20
- Block 20 Positioning to point „A“
- Block 30 In-feed to machining depth  
.  
.  
Block 70
- Block 20 Point „A“ Machining, x-orientated  
.  
.  
Block 70
- Block 20 Point „A“ Machining, y-orientated  
.  
.  
Block 70
- Block 80 End of machining operations
- The final machine position is at point „A“.

4.16 G45 / G46 Turning of coordinates (continued)

Example 2 Repeated machining with shift




Figure 4-23

```

P2  N10 G45 G0 Z0 P160:0 P161:0 P163:45 F2000 M24.2
     N20 G00 X10 Y0
     N30 G01 Z50
     N40 X40
     N50 Y15
     N60 X10 Y0
     N70 Z70 P165:55 M25
     N80 M30
    
```

The basic triangular shape ABC is to be machined twice along line OL. Line OL makes an angle E to the axis. The distance between the two triangles A', B', C' and A'', B'', C'' is 55mm (distance A'-A'').

The machining sequence on the triangle is:

- 1st. Traverse A to B
- 2nd. Traverse B to C
- 3rd. Traverse C to A

**4.16 G45 / G46 Turning of coordinates (continued)**

**Program run, example 2**

- Block 10 Switching the coordinate turning function on (G45)  
Set-up data input Uo=10 (P160) Vo=0 (P161) E=45 (P163)  
Approach to Z safety margin, Loop input
- Block 20 Positioning to point A'
- Block 30 Tool axis in-feed to machining depth
- Block 40 Machining along line A' - B'
- Block 50 Machining along line B' - C'
- Block 60 Machining along line C' - A'
- Block 70 tool axis retraction for positioning, shifting the Uo-value P165:55,  
skip back to Block 20  
. . .
- Block 20 Positioning to point A''
- Block 30 Tool axis in-feed to machining depth
- Block 40 Machining along line A'' - B''
- Block 50 Machining along line B'' - C''
- Block 60 Machining along line C'' - A''
- Block 70 Tool axis retraction
- Block 80 End of program

## 4.16 G45 / G46 Turning of coordinates (continued)

### General data for the examples 3, 4 and 5

#### Program rectangle figure process

```
P452  
N10 G0 F3000 Z1.5  
N20 G1 G91 X0 Y0 Z-2.5  
N30 X30  
N40 Y20  
N50 X-30  
N60 Y-20  
N70 Z2.5  
N80 G90 M02  
#
```

#### Parameter P8859

the parameter P8859 influences the order of rotation and shift.

P8859:0	with G92, G147, G48 and G49	first turned, then shifted
P8859:1	with G92, G48 and G49, NP:A>0	first turned, then shifted
P8859:2	with G92, G147, G48 and G49	first shifted, then turned
P8859:3	with G92, G48 and G49, NP:A>0	first shifted, then turned

4.16 G45 / G46 Turning of coordinates (continued)

**Example 3** rectangle figure turn with different brackets, absolutely and incremental

```

P451
N10      T1 M16 G0
N20      G55 G49 G60 G0 F3000 X0 Y0 Z2 M28.452      {W 1}
N30  G45 P160:50 P161:10 P163:30 X0 Y0 Z2 M28.452      {W 2 turning}
N40      P165:50 P166:10 P168:30 X0 Y0 Z2 M28.452      {W 3 incremental turning}
N50  G46 G90
N60      M30
#
    
```




Fig. 4-24

4.16 G45 / G46 Turning of coordinates (continued)

Example 4 rectangle figure shift and turn

P8859:2 first shift by G92 and then turn by G45

```

P451
N10 T1 M16 G0
N20 G55 G147 G0 F3000 X0 Y0 Z2 M28.452 {W 1}
N30 G45 P160:50 P161:10 P163:30 X0 Y0 Z2 M28.452 {W 2 turning}
N40 P165:50 P166:10 P168:30 X0 Y0 Z2 M28.452 {W 3 incremental turning}
N50 G92 X60 Y0 {shift}
N60 G45 P160:50 P161:10 P163:30 X10 Y5 Z2 M28.452 {W 2' turning}
N70 P165:50 P166:10 P168:30 X0 Y0 Z2 M28.452 {W 3' incremental turning}
N80 G46 G90 X0 Y0 Z5
N90 M30
#
    
```




Fig. 4-25

4.16 G45 / G46 Turning of coordinates (continued)

**Example 5** rectangle figure turn with different brackets and shift by G92

P8859:0 first turn by G45 and then shift by G92

```

P451
N10 T1 M16 G0
N20 G55 G147 G0 F3000 X0 Y0 Z2 M28.452 {W 1}
N30 G45 P160:50 P161:10 P163:30 X0 Y0 Z2 M28.452 {W 2 turning}
N40 P165:50 P166:10 P168:30 X0 Y0 Z2 M28.452 {W 3 incremental turning}
N58 G92 X60 Y0 {shift}
N60 G45 P160:50 P161:10 P163:30 X10 Y5 Z2 M28.452 {W 2" turning}
N70 P165:50 P166:10 P168:30 X0 Y0 Z2 M28.452 {W 3" incremental turning}
N80 G46 G90 X0 Y0 Z5
N90 M30
#
    
```




Fig. 4-26

**4.17 G47 / G48 / G49 / 147 Robot transformation**

It is advantageous for different applications, if the user can select the movements in different mode of coordinates when installing the machine (e.g. machine tool or handling system). With the BWO-ROBOT-system three modes of coordinates can be chosen.

**Machine coordinates G47**

The general and most frequent case is, that the movement is referred to a machine coordinate system, thereby the coordinate axes and an origin of coordinates are determined. The cartesian coordinates are used.

**Tool coordinates G48**

If the movement is referred to the tool or a grip, infed movements can be executed very simple for machining - or assembling tasks. In this case, the coordinates are oriented at the tool peak.

**Workpiece coordinates G49**

Programming is facilitated for many machining functions, if the movement is referred to a coordinate system oriented at the workpiece.

Switching between the above named modes of coordinates (G47 / G48 / G49) is an essential help for the user at programming with Teach-in, because e.g. for establishing a NC-program the contours of a workpiece only have to be touched and stored (taught). If equal workpieces are processed in different positions, the same NC program can be used through a single transformation of the coordinates.

**Transformation off by G147**

G147 switches the transformation off.

4.17 G47 / G48 / G49 / 147 Robot transformation (continued)

The coordinate system demands the following axis configuration:

- The A - axis turns around an axis parallel to the X - axis.
- The C - axis turns around an axis parallel to the Z - axis.
- The spindle axis stands vertically on the A - axis.
- The intersection of all three rotation axes is the center point M.
- The positive rotating direction of C is seen from positive Z-direction in counter-clockwise direction.
- The positive rotating direction of A is seen from positive X - direction in counter-clockwise direction.
- The reference point offsets are to be determined, so that in position  $A = C = 0$  the tool system is axis parallel to the basic coordinate system.




Figure 4-27 Axis configuration

**4.17 G47 / G48 / G49 / 147 Robot transformation (continued)****Machine coordinate system (G47)**

At the machine coordinate system the coordinates refer to the machine origin. Thereby the machine axes are defined in cartesian coordinates. The axis movements orientate to the axis coordinates.




Figure 4-28 Axis movements in the machine coordinate system

#### 4.17 G47 / G48 / G49 / 147 Robot transformation (continued)

##### Tool coordinate system (G48)

At the tool coordinate system the coordinates refer to the tool. The cartesian coordinate system is only used with a firm unit of length (e.g. mm).

If the tool system is arbitrarily shifted and rotated through the NC program, the system must fulfill the following conditions.

The coordinate source is the point, around which the tool is turned, if its orientation is changed. This point is named tool peak.

At rotating tools the Z-axis is the rotation-axis and indicates from the tool peak into the direction of the chuck.




Figure 4-29 Axes movements in tool coordinate system

The speed of the tool peak is interpreted as actual working feed.

When activating the tool dimensions the control shifts the tool coordinate system in the Z-direction for an amount corresponding to the tool length.

If the X -, Y - or Z- traverse direction is selected, the X -, Y - or Z - axis traverse according to the position of the rotating angle of the C-axis and the position of the tumbler angle of the A-axis, so that the tool stands always vertically on the X- Y- plane.

#### 4.17 G47 / G48 / G49 / 147 Robot transformation (continued)

##### Workpiece coordinate system (G49)

At the workpiece coordinate system the coordinates refer to the workpiece.

Only the cartesian coordinate system with a firm unit of length (e.g. mm) is used. The advantage of the workpiece system is, that it can be shifted and turned arbitrarily with the NC program.

For each point a coordinate vector can be allocated in reference to the workpiece system, for example:

- If for the linear axis the X -, Y - or Z- traverse direction is selected, the X -, Y - or Z - movement is parallel to the axes coordinates (independently of the position of the rotating angle of the C-axis and the tumbler angle of the A-axis).
- If only axis C is traversed, X and Y are relocated so that the tool peak is always at the same point. The X - and Y - axis describe a circle around this point. The orbit proceeds vertically under the center point.
- If axis A is traversed, additionally the Z - axis is moved in plus - or minus direction according to the tumbler angle position of A.




Figure 4-30 Axes movements in workpiece coordinate system

Appearing coordinate transformation when switching over between G47, G48, G49 determines the position and orientation of the tool relative to the workpiece reversable definitely.

4.17 G47 / G48 / G49 / 147 Robot transformation (continued)

Offset functions

Sometimes it is necessary, that at the construction of the machine the point of balance does not correspond to the center point M. In this case, a function for compensating this deviation is necessary.

The system offers three offset functions. By using this function, the mechanical offset is corrected automatically.

Offset in X - direction




Figure 4-31 Offset in X - direction

Parameter P11802 is offset value [mm].

Offset in Y - direction




Figure 4-32 Offset in Y - direction

Parameter P11803 is offset value [mm].

4.17 G47 / G48 / G49 / 147 Robot transformation (continued)

Offset in Z - direction




Figure 4-33 Offset in Z - direction

Parameter P11804 is offset value [mm].

**4.17 G47 / G48 / G49 / 147 Robot transformation (continued)****Tool carrier with oblique angled axes**

The configuration of the tool carrier with oblique angled axes (in zero position) is shown in figure 4.24. The A - axis turns around an axis, which does not stand vertically on the rotation axis Z. That means, that the tilt is not parallel to the X - axis. The parameter P11806 is the tilt angle.




Figure 4-34 Tool carrier with oblique angled axes

**Value areas and handling**

The parameter values used are limited in the following areas.

For the parameters P11802, P11804 and P11806 positive or negative values are possible.

The amount of P11806 must be smaller than 180 degrees.

If P11806 is = 0, the presetting is 90 degrees, namely  $\xi = 90[\text{degree}]$

If  $\xi = 90[\text{degree}]$ ,  $\alpha - \alpha_{12} = 0$ ,  $\beta - \beta_{12} = 0$  and  $\theta = 0$

The amount ( $\beta$ ) is dependent on the areas of  $\xi$ .

**4.17 G47 / G48 / G49 / 147 Robot transformation (continued)**

P8759	Coordinate mode in Manual	
	0	Transformation off
	15	Polar transformation off
	16	Polar transformation on
	47	Robot transformaton off
	48	Tool coordinate system
	49	Workpiece coordinate system
P11800	Robot linear axes (physical axis number) e.g. the first 3 axes (X, Y, Z)	
	Byte 3,2,1	03 02 01 Hex
	Byte 4	reverse (Bit 3, 2, 1)
P11801	Robot rotation axes (physical axis number) e.g. the 4th and 5th axis (A, C)	
	Byte 3, 2, 1	00 05 04 Hex
	Byte 4	reverse (Bit 3, 2, 1)
P11802	Offset X, rotation axis - tool axis	[mm]
P11803	Offset Y, rotation axis - tilt	[mm]
P11804	Offset Z, length of tool carrier	[mm]
P11805	Angle between tilt - tool axis	[degree]
P11806	Angle between rotation axis - tilt	[degree]
P11807	Angle where the tool shows downwards	[degree]

**4.17 G47 / G48 / G49 / 147 Robot transformation (continued)**

**Zero points**

The Robot system is given through a block of coordinates, which indicates its position in reference to the machine system. The zero point system G54 to G59 is analogously valid in the Robot system. The zero point indicates the position in reference to the machine system, i.e. the position of the tool is in reference to the workpiece. It can be filed in a zero point memory and is activated by calling up G54 to G59.

The functions G54 to G59 overwrite mutually. Besides they overwrite a shift effective through G92.

**Zero point shift**

The Robot system can be shifted and turned again in the NC program. The position of the shifted system relative to the old one is given through a block of coordinates. Calling up results through the zero point shift G92. This position of G92 is the reference to the actual zero point coordinates. In manual mode this zero point shift is not disposable.

The position of the tool in the machine system is given through 3 blocks of coordinates

- Zero point coordinates
- Zero point shift
- Coordinates of the position

4.17 G47 / G48 / G49 / 147 Robot transformation (continued)




Figure 4-35 Zero point shift

4.17 G47 / G48 / G49 / 147 Robot transformation (continued)

Denomination of the 3 axes, e.g. tilt B, linear axes X and Z.

With 3-axes-tool machines, G49 is controlling the axes so that when moving the tilt B, the axes X and Z are always so that the tool peak is always at the same position.

**Configuration and definition for the 3-axes-coordinate system**

The 3-axes-coordinate system demands the following axis layout:

- X and Z axis are the basic coordinates.
- The B axis is rotating around an axis that is positioned vertically to the plane XZ.
- The positive rotating direction of B is seen from positive X direction counter-clockwise.
- The reference measures are terminated so that the tool system is axis-parallel to the basic coordinates in position B=0.
- The offset between the tool peak and the rotating point is determined by the parameters P11802 (offset radius) and P11803 (offset angle).




Figure 4-36

4.17 G47 / G48 / G49 / 147 Robot transformation (continued)

Used parameters

P11800 Linear axes(physical axis number)

e.g. the first 2 axes (X,Z)

Byte 3, 2, 1 00 02 01 Hex

Byte 4 reverse (Bit 2, 1)

P11801 Rotation axes (physical axis number)

e.g. the 3rd axis (B)

Byte 3, 2, 1 00 00 03 Hex

Byte 4 reverse (Bit 1)

P11802 Offset radius, tilt - tool peak [mm]

P11803 Offset angle, tilt - tool peak [degree]

4.18 G50 / G51 / G52 Spline interpolation


- G50 Spline interpolation
- G51 Spline interpolation with feed adaptation at the contour
- G52 Polynom interpolation

G50 / G51 Spline interpolation

A sequence of points can be joined tangentially with a smooth curve trace with the spline interpolation. The points can be entered both as NC program as well as in the manual operation mode through „Teaching“ with command=target.

The spline curve is started through a traverse, which is run with G00 or G01. The start can also be with G02 or G03, if the starting position is in a main plane (G17, G18, G19).

The spline interpolation is activated in the subsequent block through G50 / G51. There results a tangential transition, whereby the starting tangent of the spline curve is determined through the starting segment.



- PA Starting point
- PE End point
- P1...P5 Spline points

Figure 4-37

**4.18 G50 / G51 / G52 Spline interpolation (continued)**

In the corresponding way the spline curve is finished through programming the @@Ausleitungssegment with G00, G01, G02 or G03.

The traverse conditions G00, G01, G02, G03 and G50 overwrite themselves mutually.

If the starting segment or the finishing segment are not programmed, the NC program stands still, because the spline interpolation can not be started or finished duly. In this case, the key 'Manual' has to be pressed and the error has to be cleared.

**G52 Polynom interpolation**

The path a is described with the formula 
$$\vec{P} = V_3 t^3 + V_2 t^2 + V_1 t + V_0,$$

whereby the variable t can have a value between 0 and 1.

The vectors  $V_3, V_2, V_1$  are programmed in components in the following form:

$$X : [V_{3X}, V_{2X}, V_{1X}] \quad Y : [V_{3Y}, V_{2Y}, V_{1Y}] \quad Z : [V_{3Z}, V_{2Z}, V_{1Z}]$$

$V_0$  is not programmed, since it is the location of the machine at the beginning of the block.

Starting point  $\vec{P}_S = V_0$

Final point  $\vec{P}_E = V_3 + V_2 + V_1 + V_0$





Figure 4-38

4.18 G50 / G51 / G52 Programming examples

Spline contour

N5	G54 G49 G00 F2000	X - 8	Y0	Z5		Starting point
N10	G01	X0	Y0	Z0	point 1	
N20	G50	X6,8	Y-0,5		point 2	Spline on
N30		X15,5	Y-6,7		point 3	
N40		X22	Y-20,6		point 4	
N50		X36,3	Y-27,1		point 5	
N60		X54,3	Y-20,7		point 6	
N70		X63,8	Y-1,5		point 7	
N80		X67,124	Y8,749		point 8	
N90		X72,7	Y18		point 9	
N100		X88,1	Y22		point 10	
N110		X102,5	Y11,1		point 11	
N120		X104,9	Y-2,8		point 12	
N130		X106,7	Y-8,1		point 13	
N140		X111	Y-10,7		point 14	
N150	G01	X115,2	Y-10,9		point 15	Spline off
N160	M30			Z5		



- Point 1            Zero point
- Point 2            Switching on spline interpolation
- Points 3 - 14        Spline points
- Point 15            Switching off of spline interpolation

Figure 4-39

### 4.19 G53 Machine zero point

With the input of G53 with G54 to G59 as well as with G92 programmed zero point shifts become ineffective. The program refers then to the machine zero point.

The function is effective modal and can be overwritten by G54 to G59.  
With the program start G53 is automatically adjusted.

G153 switches the zero shift off G53 as well as G54 to G59.

4.20 G 54 to G59 Zero points

With G54 to G59 points of zero can be called within the program.

The functions are effective modal and overwrite themselves opposite-acting. Additionally one is reset by G92 programmed shift.

The points of zero are called in the program with G54 to G59 in the null point memory. The size of the zero shift is determined by the stored values in the null point table.

Example: programming zero points




Figure 4-40

4.21 G60 / G61 / G62 Mirror imaging of coordinates

The mirror imaging function inverts the sign of programmed coordinates.  
 The G61 function inverts the sign of the 1st main axis program values.  
 The G62 function inverts the sign of the 2nd main axis program values.

Set plane	G61	G62
G17 (XY)	X becomes -X	Y becomes -Y
G18 (ZX)	Z becomes -Z	X becomes -X
G19 (YZ)	Y becomes -Y	Z becomes -Z

G60 cancels the mirror imaging functions G61 and G62 out. G60, G61 and G62 act modally.

Geometric definition




Figure 4-33

The programmed coordinates for point A are  $X_a$  and  $Y_a$ .

When G61 is switched on point A becomes point A1 with  $-X_a$  and  $Y_a$ .

When G62 is switched on point A becomes point A2 with  $X_a$  and  $-Y_a$ .

When G61 and G62 are switched on point A becomes point A3 with  $-X_a$  and  $-Y_a$ .

## 4.21 G60 / G61 / G62 Mirror imaging of coordinates (continued)

### Circle centre point coordinates I, J, K

The circle centre point coordinates are mirror imaged according to the plane and functions set.

### Zero points G53 to G59

Zero points G53 to G59 are not mirror-imaged.

### Shift G92

The values of shift G92 are mirror imaged according to the appropriate plane and functions set.

### Circular interpolation G02 and G03

When circular interpolation is switched on and G61 and G62 are active, G02 becomes G03 and G03 becomes G02. The direction of rotation remains unchanged when G61 and G62 are switched on.

### Tool correction offset G41 and G42

When the tool correction offset is switched on and G61 and G62 are active, G41 becomes G42 and G42 becomes G41. The selected correction offset remains unchanged when G61 and G62 are switched on.

### Effect of G66

G66 effects the block by block switching off of the mirror-imaging functions G61 and G62.

### Incremental dimension programming G91

Using G91, the target point in the system that has not been mirror-imaged is firstly determined and is then mirror-imaged according to the appropriate plane and mirror-imaging functions set.

### 4.22 G63 / G64 „Feed rate 100%“

#### **G63 Override 100% switch on**

With G63 the Override value is set firmly to 100%, i.e. the override is not active any longer. NC program processing runs with the programmed feed.

The function is modal effectively and can by G64 again be switched off.

#### **G64 Override 100% switch off**

G64 switches G63 out

The function is modal effectively and can by G63 be overwritten.

With the program start G64 is preset.

### 4.23 G66 Switching off all correction offsets

When programming G66, the machine zero point is taken as the reference point. All dimension inputs then refer to the machine zero point.

The G66 function is effective only in the block in which it was written.

In this particular block the zero points set by G54 to G59 and shift G92 are inoperative, as are any tool length and tool radius correction offsets.

They remain stored, however, and are effective in the next block again.

4.24 G90 Absolute dimension input

When G90 is being programmed absolute dimension input is chosen, i.e. all dimensions are referred to the program zero point (programmable using G54 to G59 and G92).

G90 operates modally and can be overwritten by G91. G90 is automatically set when the control system is switched on.

Example: Absolute dimension input




Figure 4-34

4.25 G91 Incremental dimension input

With the programming of G91 the chain measure input is selected. It always refers to the location of the axes started last.

G91 is modal effectively and can by G90 be overwritten.

Example: Incremental dimension input




Figure 4-35

4.26 G92 Zero point shift

Zero point shifts programmed by G92 are a fixed part of the NC program and therefore independent of the clamping of the workpiece. In contrast, zero points are programmed outside the NC program by G54 to G59 and activated in the NC program.

Traverse information in the block with G92 determines the zero point shift, but no traverse is activated.

Input: G92 X... Y... Z...

The zero point is shifted by the programmed amounts.

The zero point shift programmed by G92 operates modally and is always referred absolutely to the machine zero point (G53) or to a set zero point (G54 to G59).

G92 can be cleared by G53 to G59 or overwritten by a new G92.

Example: Zero point shift




Figure 4-36

**4.27 G94 / G95 Feed modification**

The functions determine the feed modifications:

**G94 Feed in mm/min**

**G95 Feed in mm/r (revolution)**

**4.28 G96 / G97 Number of revolution modification**

The functions define the speed modifications:

**G96**      **constant cutting velocity in mm/min**

**G97**      **speed in U/min**

In order to activate G96 / G97, the following parameters must be set:

P11640	spindle affects axis (example round axis C corresponds the 6. Axis	(physical axis)	Input P11640:6)
P11641	datum axis for G96 (example procedure axis Y corresponds the 2. Axis If P11641 = 0 applies, then the reference position in P11642.	(physical axis)	Input P11641:2)
P11642	reference position for G96 (e.g.: disk diameters)		[ mm ]
P11643	reference factor for G96 0 or —      mm/min 1000      m/min		[ mm/min ]
P11644	max. speed for G96		
P11645	max. speed for G97		
P11646	reference factor for G97 0 or —      U/min 1      degree/min		[ U/min ]
P11647	speed definition G96 / G97 Presetting    0 = G97 96 = G96		

## 4.28 G96 / G97 Number of revolution modification (continuation)

In the display selection menu the inputs under „ spindle parameters „ can be input.

Spindle axis: 6

Datum axis: 2

Example NC Progr.:

N10 G0 Y:50

N20 G96 G1 F50 S100 Y:0

The speed of the round axis increases the more,  
the more near processing toward the position Y:0 comes.

N10 G0 Y:0

N20 G96 G1 F50 S100 Y:50

The speed of the round axis decreases itself the more,  
the more near processing toward the position Y:50 comes.

### 4.29 G99 End feed, traverse dependant feed adaptation

The starting feed is the value programmed under 'F', the end feed is written in P608.  
This parameter has to be programmed at the latest in the block in which G99 is to be found.

**5. Cycles**

5.1	G69 Measuring cycles	5 - 2
5.2	G71/G72/G73/G74/G75 Milling cycles	5 -16
5.2.1	G71 Rectangular pocket roughing, conventional	5 -17
5.2.2	G72 Rectangular pocket roughing, climb and conventional	5 -21
5.2.3	G73 Rectangular pocket roughing and finishing	5 -25
5.2.4	G74 circular pocket roughing	5 -29
5.2.5	G75 circular pocket roughing and finishing	5 -33
5.3	G80/G81/G83/G84/G85 Drilling cycles	5 -36
5.3.1	G81 Drilling with return at rapid travers	5 -40
5.3.2	G83 Deep-hole drilling	5 -42
5.3.3	G83 Deep-hole drilling with degressive in-feed	5 -44
5.3.4	G84 Tapping	5 -46
5.3.5	G85 Drilling with retraction at feed rate	5 -48
5.4	G86/G87/G88/G89 Drilling patterns	5 -50
5.4.1	G86 Vector programming	5 -54
5.4.2	G87 Parallelogram cycle	5 -60
5.4.3	G88 Grid machining	5 -66
5.4.4	G89 Machining of full circle and circular segment	5 -72
5.5	Customer specific cycles	5 -80

## 5.1 G69 measuring cycles

### General

The measuring cycle is a NC program with the term Z69. This cycle must like all other cycles into the NC memory be loaded. The measuring cycle is called with G69.

Measuring cycles use the parameters P140 to P160 for programming. These parameters contain two types of information:

- Data, e.g.. P141 safety margin
- Parameter numbers, which indicate, where the data are stored,  
e.g.. P149: 500 (P149 is a pointer on another parameter).

Measuring cycles use the parameters P200 to P299 for internal calculations. Parts it safely that only free parameters are used for the addressing of data fields. Measuring cycles activate G40 (tool radius path correction out).

## 5.1 G69 measuring cycles (continued)

### Measuring preparation

- Connecting it the sensor with the measuring input on the AAZ module (15pol. HD Sub Socket).  
If the measuring axes are distributed on several modules, all interconnect you Measuring inputs together (MT+ / MT-).
- Checking it the measuring logic for each measuring axis (P12045: \$xxxx1010...).
- Checking it the tool data of the used sensor. G69 requires tool length and tool radius of the sensor.

5.1 G69 measuring cycles (continued)

Compilation of the cycle parameters

Parameter	meaning
P140	cycle selection
P141 [ mm ]	safety margin
P143 [ mm/min ]	measuring speed
P144 [ n ]	number of measurements at the same point (> 0)
P147 (P147)+4 [ mm ]	pointer on the measuring tolerance data confidence range
P148	measuring axis in plane system (1... 3)
P149 (P149)+0 [ mm ] (P149)+1 [ mm ] (P149)+2 [ mm ] (P149)+3 [ mm ] (P149)+4 [ mm ] (P149)+5 [ mm ]	pointer on the data of point of trigger XN, point of trigger in negative direction 1. axis XP, point of trigger in positive direction 1. axis YN, point of trigger in negative direction 2. axis YP, point of trigger in positive direction 2. axis ZN, point of trigger in negative direction 3. axis ZP, point of trigger in positive direction 3. axis
P150 (P150)+0 [ mm ] (P150)+1 [ mm ] (P150)+2 [ mm ] (P150)+3 [ mm ]	pointer on the calibration drilling data position of the calibration drilling focal point 1. axis (I) position of the calibration drilling focal point 2. axis (J) position of the calibration drilling focal point 3. axis (K) calibration drilling diameter
P152 [ mm ]	expected drilling diameter
P154 (P154)+0 [ mm ] (P154)+1 [ mm ] (P154)+2 [ mm ]	pointer on the measuring data measuring position 1. axis measuring position 2. axis measuring position 3. axis

## 5.1 G69 measuring cycles (continued)

Cycle	Parameter	Calibrate of the sensor in drilling	Calibrate of the sensor at area	Determining of centre a drilling	Determining of positions at area
Cycle selection	P140	1	2	60	40
Safety margin	P141	x	x	x	x
Measuring speed	P143	x	x	x	x
Number of measurem.	P144	x	x	x	x
Measuring tolerance	P147	x	x	x	x
Confidence range	(P147)+4	x	x	x	x
Measuring axis in plane	P148				x
Data of point of trigger	P149	x	x	x	x
Point of trigger XN	(P149)+0	o		x	x
Point of trigger XP	(P149)+1	o		x	x
Point of trigger YN	(P149)+2	o		x	x
Point of trigger YP	(P149)+3	o		x	x
Point of trigger ZN	(P149)+4				
Point of trigger ZP	(P149)+5		o		x
Calibration drilling data	P150	x			
Centre position 1.axis I	(P150)+0	x**	x*		
Centre position 1.axis J	(P150)+1	x**	x*		
Centre position 1.axis K	(P150)+2	x**	x*		
Drilling diameter	(P150)+3	x			
Expected diameter	P152			x	
Output data of the pos.	P154			x	x
Measuring pos. 1. axis	(P154)+0			o**	o*
Measuring pos. 2. axis	(P154)+1			o**	o*
Measuring pos. 3. axis	(P154)+2			o**	o*

x: Parameter must be programmed

o: cycle edition

\* : one of these

\*\* : two of these

**5.1 G69 measuring cycles (continued)**

Message	Meaning
8130	uppersize
8131	undersize
8132	permissible measure difference exceeded
8133	confidence range exceeded
8134	reference drilling smaller than sensor
8135	boring axis is measuring axis
8136	sensor cannot be initiated
8137	P140 incorrectly programs
8138	P141 incorrectly programs
8139	P142 incorrectly programs
8140	P143 incorrectly programs
8141	P144 incorrectly programs
8142	P145/147/149/150 incorrectly programs
8143	empirical value incorrectly programs
8144	P146 incorrectly programs
8145	measuring tolerance 1 incorrectly programs
8146	measuring tolerance 2 incorrectly programs
8147	measuring tolerance 3 incorrectly programs
8148	measuring tolerance 4 incorrectly programs
8149	measuring tolerance 5 incorrectly programs
8150	P148 incorrectly programs
8151	point of trigger XN incorrectly programs
8152	point of trigger XP incorrectly programs
8153	point of trigger YN incorrectly programs
8154	point of trigger YP incorrectly programs
8155	point of trigger ZN incorrectly programs
8156	point of trigger ZP incorrectly programs

**5.1 G69 measuring cycles (continued)**

Message	Meaning
8157	point of drilling I incorrectly programs
8158	point of drilling J incorrectly programs
8159	point of drilling K incorrectly programs
8160	point of drilling R incorrectly programs
8161	P151 incorrectly programs
8162	P152 incorrectly programs
8163	P153 incorrectly programs
8164	tool not called
8165	G53 not actively
8166	G54 to G59 not actively
8167	sensor actively outside of the safety area
8168	P154 incorrectly programs

## 5.1 G69 measuring cycles (continued)

### Calibration of the sensor in drilling G69 P140:1

The cycle requires a calibration drilling and a sensor. Measuring is executed with the two axes of the selected interpolation plane.

The sensor must be pre-positioned first on the drilling centre point in the selected interpolation plane and the sensor ball within the drilling.

If for example G17 is defined, the centre point of the calibration drilling must in (P150)+0 and (P150)+1 and the diameter in (P150)+3 to be defined.

The cycle positions first the 1. and 2. axis in the interpolation plane to the programmed centre point of the drilling. Now the cycle moves the 1. axis in positive direction to the drilling edge. The axis starts with the feed of the NC program and reduces the feed to F:p143 at the distance of P141 (safety margin) before the expected drilling edge. If a measuring signal before the safety margin occurs, a message is output (M8167).

From the safety margin the cycle moves the axis to the expected drilling edge plus confidence interval. If there is still no signal, a message (M8136) appears.

If there is a signal of the sensor, immediately the axis movement stops and the cycle calculates the point of trigger of the sensor and writes it in (P149)+n (axis movement positively: Point of trigger negatively).

If P144 is > 1, the cycle returns to the safety margin. From here the cycle starts a new measuring movement to the same drilling edge. Afterwards the cycle looks the other side up of the drilling. Become subsequently, the movements with the 2. Axis executed.

If the cycle is finished, then is the data field (P149)+n with the points of trigger of the sensor described. Following measuring cycles can operate with these data. The position of the moved axes now is in the center of the drilling.

Parts it safely,

- that the tool radius of the sensor is correct (P8160).
- to operate in the null point, in which the parameter data (P150) apply.

5.1 G69 measuring cycles (continued)

Example: The calibration of the sensor in drilling G69 P140:1

```

N20      T1  M16
N30      G17 G53 G0  X600.000 Y300.000 Z280.000 A0  B0
N40      G1  Z270    F3000

N100                                {Cycle G69 / 1 initialize }
N110      P140:1                      {Cycle type}
N120      P141:3                      {Safety margin }
N130      P143:100                   {Measuring speed }
N140      P144:2                      {Number of the measurements }
N150      P147:500                   {Pointer on tolerance data }
N160      P504:5                      {Confidence range }
N170      P149:510                   {Pointer on trigger data }
N180      P150:520                   {Pointer on measuring data }
N182      P520:624.96  P521:324.3    P523:54    {I, J, D }
N230      G69                        {Cycle call }

N240      G0  Z280    M30
    
```




Figure 5-1

## 5.1 G69 measuring cycles (continued)

### Calibration of the sensor at area G69 P140:2

The cycle requires a calibrating area and a sensor. Measuring becomes with the 3. axis of the selected interpolation plane executed (definition of G17...).

The sensor must be pre-positioned on the calibrating area.

If for example G17 is defined, the position on the calibrating area must in (P150)+2 to be defined.

The cycle moves now 3. axis toward the calibrating area. The axis starts with the feed of the NC program and reduces the feed to F:p143 at the distance of P141 (safety margin) before the expected area. If a measuring signal before the safety margin occurs, a message is output (M8167).

From the safety margin the cycle moves the axis to the expected area plus confidence interval. If there is still no signal, a message (M8136) appears.

If there is a signal of the sensor, immediately the axis movement stops and the cycle calculates the point of trigger of the sensor and writes it in (P149)+n (axis movement positively: Point of trigger negatively).

If P144 is > 1, the cycle turns back to the safety margin. From here the cycle starts a new measuring movement to the same area.

If the cycle is finished, then is the data field (P149)+n with the points of trigger of the sensor described. Following measuring cycles can operate with these data. The position of the moved axis now is in the safety margin.

Parts it safely,

- that the tool radius of the sensor is correct (P8160, P8162).
- to operate in the null point, in which the parameter data (P150) apply.

5.1 G69 measuring cycles (continued)

Example: The calibration of the sensor in drilling G69 P140:2

```

N20      T1  M16
N30      G17 G53 G0  X600.000 Y300.000 Z280.000 A0  B0
N40      G1  Z270    F3000

N100                                {Cycle G69 / 2 initialize }
N110      P140:2                      {Cycle type}
N120      P141:3                      {Safety margin }
N130      P143:100                   {Measuring speed }
N140      P144:2                      {Number of the measurements }
N150      P147:500                   {Pointer on tolerance data }
N160      P504:5                     {Confidence range }
N170      P149:510                   {Pointer on trigger data }
N180      P150:520                   {Pointer on measuring data }
N182      P522:260.20                {K }
N230      G69                        {Cycle call }

N240      G0  Z280    M30
    
```




Figure 5-2

## 5.1 G69 measuring cycles (continued)

### Determining the center of a drilling G69 P140:60

The measurement is executed with both axes of the selected interpolation plane (see G17...). The sensor should be at the beginning approximately on the drilling centre point in the selected interpolation plane and the sensor ball within the drilling pre-positioned.

The cycle moves the 1. axis in positive direction to the drilling edge. The axis starts with the feed of the NC program and reduces the feed to F:p143 at the distance  $(\text{diameters} / 2 - \text{safety margin}) = (P152 / 2 - P141)$ .

If a measuring signal before this point occurs, a message is output (M8167).

From here the cycle moves the axis to the expected drilling edge plus confidence interval. If there is still no signal, a message (M8136) appears.

If there is a signal of the sensor, immediately the axis movement stops and the cycle calculates the edge position.

If P144 is  $> 1$ , the cycle turns back to the safety margin. From here the cycle starts a new measuring movement to the same drilling edge. Afterwards the cycle looks the other side up of the drilling. Now become the movements with the 2. axis made.

If the cycle is finished, then is the data field (P154)+n with the drilling centre point described. The position of the moved axes now is in the center of the drilling.

Parts it safely that the tool radius of the sensor is correct (P8161, P8163).

5.1 G69 measuring cycles (continued)

Example: The calibration of the sensor in drilling G69 P140:60

```

N20      T1  M16
N30      G17 G53 G0  X600.000 Y300.000 Z280.000 A0  B0
N40      G1  Z270    F3000

N100                                {Cycle G69 / 60 initialize }
N110      P140:60                    {Cycle type}
N120      P141:3                      {Safety margin }
N130      P143:100                   {Measuring speed }
N140      P144:2                      {Number of the measurements }
N150      P147:500                   {Pointer on tolerance data }
N160      P504:5                     {Confidence range }
N170      P149:510                   {Pointer on trigger data }
N180      P150:520                   {Pointer on measuring data }
N182      P154:530                   {Pointer on output }
N230      G69                        {Cycle call }

N240      G0  Z280    M30
    
```




Figure 5-3

**5.1 G69 measuring cycles (continued)**

**determining an individual item in the area G69 P140:40**

The sensor must be pre-positioned at the beginning over the contact surface.  
The measurement is executed with the axis defined in P148.

The cycle starts into negative direction with measuring speed (P143)  
If there is still no signal of the sensor, the axes in the position (initial position - confidence interval (P147)+4) stop and a message (M8136) appears.

If there is a signal of the sensor, immediately the axis movement stops and the cycle calculates the position on the area and writes the data in (P154)+n.

Example G17	with P148:3	writes after cycle	P(154)+2
	with P148:2	writes after cycle	P(154)+1
	with P148:1	writes after cycle	P(154)+0

If P144 is > 1, the cycle turns back to the safety margin. From here the cycle starts a new measuring movement to the same area.

The position of the moved axes is in the safety margin.

Parts it safely,

- that the tool length of the sensor is correct (P8161, P8163),  
if 3. axis is selected
- that the tool radius of the sensor is correct (P8160, P8162),  
if 1. or 2. axis is selected

5.1 G69 measuring cycles (continued)

Example: The calibration of the sensor in drilling G69 P140:40

```

N20      T1  M16
N30      G17 G53 G0  X600.000 Y300.000 Z280.000 A0  B0
N40      G1  Z270      F3000

N100                                {Cycle G69 / 40 initialize }
N110      P140:40                    {Cycle type}
N120      P141:3                      {Safety margin }
N130      P143:100                    {Measuring speed }
N140      P144:2                      {Number of the measurements }
N150      P147:500                    {Pointer on tolerance data }
N160      P504:5                      {Confidence range }
N170      P144:3                      {Measuring axes }
N180      P149:510                    {Pointer on trigger data }
N182      P150:520                    {Pointer on measuring data }
N230      G69                        {Cycle call }

N240      G0  Z280      M30
    
```




Figure 5-4

## 5.2 G71 / G72 / G73 / G74 / G75 Milling cycles

### List of canned milling cycles

- G71 Rectangular pocket roughing, conventional
- G72 Rectangular pocket roughing, conventional and climb
- G73 Rectangular pocket roughing and finishing
- G74 Circular pocket roughing
- G75 Circular pocket roughing and finishing

The millinging cycles are block by block effective.  
The parameter inputs remain against it modal effectively.

In order to avoid over regulation, all parameters are to be reset,  
with a programming type not to be used.

### Messages

The numbers for cycle messages start with 8xxx.  
A list can be found in section messages

## 5.2.1 G71 Rectangular pocket roughing, conventional

### Starting point definition

Before starting any machining cycles, the milling cutter should be above the workpiece by the safety margin and at the centre of the pocket.

Whether the starting point S1 or S2 is homed into depends on the sign of the programmed in-feed P16.

Positive sign: starting point S1

Negative sign: starting point S2

The milling direction is established by the CNC and always in the direction of the longer pocket side. If the pocket sides are the same, milling takes place in the X direction.

### Parameter input

All parameters except for P16 should have positive sign when inputting.

Parameter	Significance
P11	Pocket dimension in X direction
P12	Pocket dimension in Y direction
P13	Pocket depth in Z direction
P14	Corner radius
P15	Contour allowance in X and Y directions
P16	In-feed dimension in X or Y directions (prefix + or -)
P17	In-feed dimension in Z direction
P18	Pocket depth allowance in Z direction
P19	Safety margin in Z direction
P21	Feed rate in Z direction (when plunging into material)

During cycle processing a possibly programmed correction becomes G41 / G42 switched off, since the tool radius correction in the cycle is considered.

Feed in z-direction (only when immersing into the material) is programmable with P21.

Is P21 programmed, does not become immersing into the material with under F programmed feed executed.



5.2.1 G71 Rectangular pocket roughing, conventional (continued)

G 71 Example 1: Pocket dimensions X=71mm, Y=41mm, Z=5mm; Tool-radius=3mm

```

N10    G00    G54    G90    F2500    S900    T02    M06 M03 M07
N20    G71    X55,5  Y40,5  Z2     P11:71  P12:41  P13:5
        P14:--  P15:0   P16:4   P17:3   P19:2   P21:100
                                           M30
    
```




Figure 5-6

- Parameters:
- P11, P12, P13 Pocket dimensions in X, Y, Z direction
  - P16, P17 In-feed in Y, Z direction
  - P19 Safety margin in Z direction
  - P21 Feed rate in Z direction

Run: Block 10 Zero point, absolute dimension, feed rate, spindle, tool  
 Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z, pocket dimensions P11, P12, P13, in-feed dimensions P16, P17, safety margin P19

Remarks: Since the corner radius P14 is not programmed, it becomes with the programmed tool radius equated.

5.2.1 G71 Rectangular pocket roughing, conventional (continued)

**G71 Example 2:** Pocket dimensions X=46mm, Y=81mm, Z=30mm;  
Tool-radius=3mm, corner radius=13mm

```

N10      G00      G54      G90      F1000    S750      T02 M06 M03 M07
N20      G71      X43      Y60,5    Z1        P11:46    P12:81    P13:30
          P14:13    P16:-4    P17:7     P19:1     P21:400   M30
    
```




Figure 5-7

- Parameters:
- P11, P12, P13 Pocket dimensions in X, Y, Z direction
  - P14 Corner radius
  - P16, P17 In-feed in X, Z direction
  - P19 Safety margin in Z direction
  - P21 Feed rate in Z direction

- Run:
- Block 10 Zero point, absolute dimension, feed rate, spindle, tool
  - Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z; pocket dimensions P11, P12, P13, in-feed dimensions P16, P17, corner radius P14, safety margin P19

Remarks: If P14 = 0 is or smaller than the tool radius, then becomes after that start clearing the program execution stopped and message 8001 indicated.

## 5.2.2 G72 Rectangular pocket roughing, climb and conventional

### Starting point definition

Before the start of the machining cycles the milling cutter should be above the workpiece by the safety margin and in the middle of the pocket.

Whether the starting point S1 or S2 is homed into depends on the sign of the programmed in-feed P16.

Sign, positive: starting point S1

Sign, negative: starting point S2

The determination of the milling direction takes place in the CNC and always in the direction of the longer pocket side. If the pocket sides are the same, milling takes place along the X direction.

### Parameter input

All parameters except for P16 should have a positive sign during inputting.

Parameter	Significance
P11	Pocket dimension in X direction
P12	Pocket dimension in Y direction
P13	Pocket depth in Z direction
P14	Corner radius
P15	Contour allowance in X and Y directions
P16	In-feed dimension in X or Y directions (sign +/-)
P17	In-feed dimension in Z direction
P18	Pocket depth allowance in Z direction
P19	Safety margin in Z direction
P21	Feed rate in Z direction (when plunging into material)

5.2.2 G72 Rectangular pocket roughing, climb and conventional (continued)

Machining sequence

- Home in on starting point S1 or S2 (each according to sign of P16)
- In-feed in Z direction at feed rate P21 (if programmed)
- Conventional milling to pocket dimension less the allowance P15 in X and Y direction
- In-feed in X or Y direction
- Milling in conventional direction
- In-feed in X or Y direction
- In-feed repetition until pocket dimension less allowance P15 is reached
- Milling over burrs along edge
- Retraction in Z direction to safety margin
- Retraction to starting position in XY plane
- In-feed in Z direction to previous dimension
- Milling over burrs along other edge
- Retraction in Z direction to safety margin
- Retraction to starting position in XY plane
- Repetition of in-feeds until pocket depth less allowance P18 is reached
- Retraction to starting position (centre of pocket)




Figure 5-8

5.2.2 G72 Rectangular pocket roughing, climb and conventional milling (cont.)

G72 Example 1: Pocket dimensions X=66mm, Y=31mm, Z=5mm; Tool-radius=3mm

```

N10 G00 G54 G90      F2000      S850      T02      M06 M03 M07
N20 G72 X53 Y35,5    Z1         P11:66    P12:31    P13:5     P14:--    P15:0
      P16:5,1 P17:3    P19:1     M30
    
```




Figure 5-9

Parameters:  
P11, P12, P13 Pocket dimensions in X, Y, Z direction  
P16, P17 In-feed in Y, Z direction  
P19 Safety margin in Z direction

Run: Block 10 Zero point, absolute dimension, feed rate, spindle, tool  
Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z; pocket dimensions P11, P12, P13, in-feed dimensions P16, P17, safety margin P19

Remarks: As the corner radius P14 is not programmed it is identified along with the programmed tool radius.

5.2.2 G72 Rectangular pocket roughing, climb and conventional milling (cont.)

**G72 Example 2:** Pocket dimensions X=44mm, Y=69mm, Z=3mm; Tool radius=3mm, corner radius=15mm

```

N10 G00 G54 G90      F2000    S950    T02      M06      M03      M07
N20 G72 X42 Y54,5    Z1       P11:44  P12:69  P13:3    P14:15  P15=0
      P16:5,5  P17:3    P19:1    P21:100 M30
    
```




Figure 5-110

- Parameters:
- P11, P12, P13 Pocket dimensions in X, Y, Z direction
  - P14 Corner radius
  - P16, P17 In-feed in X, Z direction
  - P19 Safety margin in Z direction
  - P21 Feed rate in Z direction

- Run:
- Block 10 Zero point, absolute dimension, feed rate, spindle, tool
  - Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z; pocket dimensions P11, P12, P13, in-feed dimensions P16, P17, corner radius P14, safety margin P19

Remarks: If P14=0 or is smaller than the tool radius the program run is shut down after the start and fault feed-back 1301 (geometry fault) is displayed.

### 5.2.3 G73 Rectangular pocket roughing and finishing

#### Starting point definition

Before the start of the machining cycles, the milling cutter should be above the workpiece at the safety margin and in the middle of the pocket.

Whether the starting point S1 or S2 is homed into depends on the sign of the programmed in-feed P16.

Sign, positive: starting point S1

Sign, negative: starting point S2

The milling direction is established in the CNC and is always in the direction of the longer pocket side. If the pocket sides are the same, milling takes place along the X direction.

#### Parameter input

All parameters except for P16 should have a positive sign when inputting.

Parameter	Significance
P11	Pocket dimension in X direction
P12	Pocket dimension in Y direction
P13	Pocket depth in Z direction
P14	Corner radius
P15	Contour allowance in X and Y direction
P16	In-feed dimension in X or Y direction (sign +/-)
P17	In-feed dimension in Z direction
P18	Pocket depth allowance in Z direction
P19	Safety margin in Z direction
P20	In-feed dimension when finishing, to remove allowance P15; In-feed direction as for P16
P21	Feed rate in Z direction (when plunging into material)

5.2.3 G73 Rectangular pocket roughing and finishing (continued)

Machining

- Home in on starting point S1 or S2 (each according to sign of P16)
- In-feed in Z direction at feed rate P21 (if programmed)
- Milling pocket contour (less allowance P15) to starting point
- In-feed repetition until pocket depth P13 less allowance P18 is reached
- Retraction to starting plane
- In-feed in X or Y direction
- In-feed in Z direction at feed rate P21 (if programmed)
- Conventional and climb milling of remaining material
- Retraction in Z direction and to starting position and in-feed
- In-feed repetition until pocket dimension less allowance P18 is reached.
- Retraction in Z direction to starting plane
- In-feed for finishing
- In-feed in Z direction at 0.5 of the programmed feed rate F to pocket depth less P18
- Finishing contour to starting point at 0.5 of the programmed feed rate
- In-feed repetition until finished contour is reached
- Retraction to starting position at programmed feed rate




Figure 5-11

5.2.3 G73 Rectangular pocket roughing and finishing (continued)

**G73 Example 1:** Pocket dimensions X=64mm, Y=35mm, Z=5mm; Tool radius=3mm

```

N10 G00 G54      G90      F1500      S950      T02      M06      M03      M07
N20 G73 X52,5    Y37,5    Z1          P11:64    P12:35    P13:5    P14=0
      P15:1      P16:4,5    P17:2    P19:1    P20:1    M30
    
```




Figure 5-12

Parameters:  
P11, P12, P13 Pocket dimensions in X, Y, Z direction  
P15 Allowance in X and Y direction  
P16, P17 In-feed in Y, Z direction  
P19 Safety margin in Z direction  
P20 Allowance during finishing

Run: Block 10 Zero point, absolute dimension, feed rate, spindle, tool  
Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z; pocket dimensions P11, P12, P13, in-feed dimensions P16, P17, allowance P15, safety margin P19, in-feed dimension when finishing P20

Remarks: As the corner radius P14 is not programmed it is made equal to the programmed tool radius.

5.2.3 G73 Rectangular pocket roughing and finishing (continued)

**G73 Example 2:** Pocket dimensions X=65mm, Y=35mm, Z=5mm; Tool radius=3mm, corner radius=11mm

```

N10 G00 G54      G90      F1500    S950      T02      M06      M03      M07
N20 G73 X52,5    Y37,5    Z1       P11:65    P12:35    P13:5    P14:11
      P15:1,5    P16:4,2    P17:2    P19:1    P20:1    M30
    
```




Figure 5-13

Parameters:  
P11, P12, P13 Pocket dimensions in X, Y, Z direction  
P14 Corner radius  
P15 Allowance in X and Y direction  
P16, P17 In-feed in Y, Z direction  
P19 Safety margin in Z direction  
P20 Allowance during finishing

Run:  
Block 10 Zero point, absolute dimension, feed rate, spindle, tool  
Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z; pocket dimensions P11, P12, P13, in-feed dimensions P16, P17, corner radius P14, safety margin P19, allowance P15, infeed dimension during finishing P20

Remarks: If P14=0 or is smaller than the tool radius the program run is shut down after the start and message 1301 (geometry fault) is displayed.

## 5.2.4 G74 circular pocket roughing

### Starting point definition

Before the start of the machining cycles the milling cutter should be above the workpiece at the safety margin and at the centre of the pocket.

### Parameter input

All parameters except for P16 should have a positive sign when inputting. The sign of P16 determines the direction of milling, i.e.:

Milling direction G02, the sign of P16 is positive

Milling direction G03, the sign of P16 is negative

Parameter	Significance
P11	Internal radius (if core drilled)
P12	Depth of pocket
P14	Pocket radius
P15	Allowance at circumference
P16	In-feed dimension in X direction
P17	In-feed dimension in Z direction
P18	Pocket depth allowance in Z direction
P19	Safety margin
P21	Feed rate in Z direction (when plunging into material)

When specifying the internal radius P11, the first in-feed in the X direction is corrected by the appropriate amount: 1st in-feed = P11 + P16.

5.2.4 G74 circular pocket roughing (continued)

Machining

- In-feed in Z direction at feed rate P21 (if programmed)
- In-feed in X direction
- Spiral milling
- Milling circular pocket to finished size less allowance P15
- Retraction along the semicircle with R=2.5mm max.
- Retraction in Z direction by 2mm
- Retraction to centre of pocket
- In-feed repetition until pocket dimension less allowance P18 in Z direction is reached
- Retraction to starting position




Figure 5-14

5.2.4 G74 Circular pocket roughing (continued)

**G74 Example 1:** Pocket radius R=33mm, pocket depth Z=27mm; Tool radius=3mm

```
N10 G00 G54 G90 F1500 S950 T02 M06 M03 M07
N20 G74 X53 Y53 Z1 P13:27 P14:33 P16:5,1 P17:5 P19:1 M30
```




Figure 5-15

Parameters:

- P13 Pocket depth in Z direction
- P16, P17 In-feed in X, Z direction
- P14 Pocket radius
- P19 Safety margin in Z direction

- Run: Block 10 Zero point, absolute dimension, feed rate, spindle, tool
- Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z, pocket depth P13, in-feed dimensions P16, P17, pocket radius P14, safety margin P19

5.2.4 G74 circular pocket roughing (continued)

**G74 Example 2:** Pocket radius R=30mm, pocket depth Z=31mm; Tool radius=3mm, core bore drilling at 20mm dia.

```

N10 G00 G54 G90 F1500 S950 T02 M06 M03 M07
N20 G74 X50 Y50 Z1 P11:10 P13:31 P14:30 P16:4 P17:8
    P19:1 M30
    
```




Figure 5-16

Parameters:

- P11 Internal radius (if core drilled)
- P13 Pocket depth in Z direction
- P16, P17 In-feed in X, Z direction
- P14 Pocket radius
- P19 Safety margin in Z direction

- Run: Block 10 Zero point, absolute dimension, feed rate, spindle, tool
- Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z, pocket depth P13, in-feed dimensions P16, P17, pocket radius P14, safety margin P19

## 5.2.5 G75 circular pocket roughing and finishing

### Starting point definition

Before the start of the machining cycles the milling cutter should be above the workpiece at the safety margin and at the centre of the pocket.

### Parameter input

All parameters except for P16 should have a positive sign when inputting. The sign of P16 determines the direction of milling, i.e.:

Milling direction G02, the sign of P16 is positive

Milling direction G03, the sign of P16 is negative

Parameter	Significance
P11	Internal radius (if drilled)
P13	Depth of pocket
P14	Pocket radius
P15	Allowance at circumference
P16	In-feed dimension in X direction
P17	In-feed dimension in Z direction
P18	Pocket depth allowance in Z direction
P19	Safety margin
P20	In-feed dimension when finishing, to remove P15, in-feed direction as with P16
P21	Feed rate in Z direction (when plunging into material)

With specification of the internal radius P11 the first feed in x-direction becomes around the suitable amount corrects: 1.  $\text{Feed} = \text{P11} + \text{P16}$ .

5.2.5 G75 circular pocket roughing and finishing (continued)

Machining

- In-feed in Z direction at feed rate P21 (if programmed)
- In-feed in X direction
- Spiral milling
- Milling circular pocket to finished size less allowance P15
- Retraction along the semicircle with R=2.5mm max.
- Retraction in Z direction
- Retraction to centre of pocket
- In-feed repetition until pocket dimension less allowance P18 in Z direction is reached
- Retraction along the semicircle with R=2.5mm max.
- In-feed at half feed rate for finishing along the semicircle
- Milling along the circle at half of the programmed feed rate
- Retraction along the semicircle
- In-feed repetition until finished dimension is reached
- Retraction along the semicircle
- Retraction to starting position at programmed feed rate




Figure 5-17

5.2.5 G75 circular pocket roughing and finishing (continued)

**G75 Example 1:** Pocket radius R=28mm, pocket depth Z=35mm; Tool radius=3mm

```
N10 G00 G54 G90 F1500 S950 T02 M06 M03 M07
N20 G75 X48 Y48 Z1 P13:35 P14:28 P15:2 P16:4,1 P17:8
      P19:1 P20:2 M30
```




Figure 5-18

Parameters:

- P13 Pocket depth in Z direction
- P14 Pocket radius
- P15 Allowance at circumference
- P16, P17 In-feed in X, Z direction
- P19 Safety margin in Z direction
- P20 In-feed dimension during finishing

Run: Block 10 Zero point, absolute dimension, feed rate, spindle, tool  
 Block 20 Cycle call-up, positioning on centre of pocket X, Y, Z, pocket depth P13, in-feed dimensions P16, P17, pocket radius P14, safety margin P19, in-feed dimension during finishing P20

**5.3 G80 / G81 / G83 / G84 / G85 Drilling cycles**

the drilling cycle functions G81 / G83 / G84 / G85 operate modally and overwrite each other mutually. G80 clears all drilling cycles resulting in G00 (rapid traverse) and G64 (clearing feed rate 100%) becoming effective automatically.

G80 is automatically set at the program start.

**List of drilling cycles**

Drilling cycle according to DIN 66025	Programming in CNC900
G81 Drilling with rapid return	G81
G82 Drilling with rapid return and	G81, G04. Free cutting time free-cutting
G83 Deep hole drilling	G83
G84 Tapping	G84, G04. Spindle turnaround time
G85 Drilling with return at feed rate	G85
G86 Drilling with rapid return, free cutting and spindle „off“	G81, G04. Free cutting time, M05
G87 Drilling with manual return	-
G88 Drilling with manual return and free cutting	-
G89 Drilling with return at feed rate and	G85, G04. Free cutting time
	Further possibilities with the CNC900, e.g.:
	G83, G04. Free cutting time
	G83, G04. Free cutting time, M05

5.3 G80 / G81 / G83 / G84 / G85 Drilling cycles

Programming of characteristics

for the programming of the drill cycles only parameters can be used.

Parameter Meaning

P30	Free cutting time	Turn back time of the spindle after achieving the drilling depth	
P31	Compensating chuck	G84 P31 : 3 = thread cutting without compensating chuck right P31 : 4 = thread cutting without compensating chuck left P31 : 0 or - = G84 standard cycle (with compensating chuck)	
P32	Drilling feed		
P32	Thread pitch	bei G84	
P33	Drilling depth		absolute
P33	Thread depth	bei G84	absolute
P34	Anticipation plane	Safety margin of the processing upper edge	absolute
P35	Retreat plane	To run around of obstacles in the setting axis	absolute
P36	No. of strokes	G83, constant setting depth = $(P33 - P34) / P36$	
P36	Setting depth	G83, degressive setting depth	
P37	1st Stroke	G83, degressive setting depth	
P38	Safety margin	G83, presetting = 1mm	incremental
P39	Gradual decrease	G83, degressive setting depth P39 : 1 = on P39 : 0 or - = off	

Drilling depth P33, anticipation plane P34 and retreat plane P35 are dependant of the planes set over G17, G18 or G19. In the following examples, G17 is activated with the axis names X (1st axis), Y (2nd axis) and Z (3rd axis).

5.3 G80 / G81 / G83 / G84 / G85 Drilling cycles (continued)

Parameters for drilling cycles

Drilling cycle	Parameter									
	Free cutting time	Drilling feed	Drilling depth	Anticipation plane	Retreat plane	Number of strokes	1st stroke	Safety margin	Gradual decrease	Drilling speed
	P30	P32	P33	P43	P35	P36	P37	P38	P39	S
G81	*	*	*	*	*	-	-	-	-	*
G83 constant	*	*	*	*	*	*	-	*	-	*
G83 degressiv	*	*	*	*	*	*	*	*	*	*
G84	*	*	*	*	*	-	-	-	-	*
G85	*	*	*	*	*	-	-	-	-	*

When calling up a drilling cycle, a direction of spindle rotation and spindle speed should be active. If these two values have already been set when the cycle is called up they are taken as the preset values for the drilling cycles.

Programming of a safety margin (P38) is optional. If this characteristic is not input a safety margin of 1 mm is preset.

When calling up a drilling cycle, the fields marked \* should have been programmed in one way or another.

Messages

The numbers for cycle messages start with 8xxx. A list can be found in section messages

Activation conditions

For a drilling cycle to be carried out, at least one of the X, Y or Z coordinates should be programmed per main block. This also applies to parameter P33 for the drilling depth Z.

---

**5.3 G80 / G81 / G83 / G84 / G85 Drilling cycles (continued)****Positioning speed**

The pre-positioning of the axes takes place at rapid traverse. When using polar coordinates programming with interpolation mode G02 or G03 set, positioning is at the programmed feed rate. It is therefore good policy to specify the feed rate with parameter P32.

**Effect of G91 incremental dimensions**

Using incremental dimensions, the positioning axes (XY with G17, ZX with G18, YZ with G19) are traversed in incremental mode. The specified coordinates are always taken as absolute for the characteristics (Z, R, K).

**Effect of G66**

A programmed G66 is effective throughout the complete drilling cycle.

**Effect of G63/G64**

The function, when set, is retained throughout the complete drilling cycle. The tapping cycle G84 automatically sets G63 for period of the in-feed traverse.

**Effect of other additional functions**

Other additional functions are effective in a block with travel information (cycle is executed) before or after the travels that are defined in the cycle.

5.3.1 G81 Drilling with return at rapid travers




Figure 5-19

**Meaning of the parameters**

P30	Free cutting time	Turn back time of the spindle after achieving the drilling depth
P32	Drilling feed	
P33	Drilling depth	
P34	Anticipation plane	Safety margin of the processing upper edge
P35	Retreat plane	To go around of obstacles in the setting axis

**5.3.1 G81 Drilling with return at rapid travers (continued)****Example**

```
N20 G56 G00      X0  Y0  Z100      S1200      F1500      M03      T01  M16
N30 G81 Z80      P30:1      P32:800  P33:0      P34:32      P35:60
N40 M05 ...
```

**Sequence plan**

- 1 Switch on spindle (M03, M04) and position X and Y axis in rapid traverse.
- 2 After reaching the X and Y position, position the Z axis to the anticipation plane (P34) in rapid traverse.
- 3 After reaching the anticipation plane the Z axis is traversed at working feed rate (P32) to the drilling depth (P33).
- 4 After reaching the drilling depth any possibly programmed free cutting time (P30) is awaited.
- 5 After it the Z-axis in rapid traverse moves on the retreat plane (P35) and afterwards the spindle is switched off (M05).

### 5.3.2 G83 Deep-hole drilling with constant setting depth

If the parameter P39:0 or is not programmed, the programmed drilling depth (P33) by repeated constant setting depth of the active drilling depth is achieved.

The active drilling depth is  $(P33 - P34) * n / P36$ , however  $n = 1, 2, ..$  (settin depth = stroke) is.




Figure 5-20

#### Meaning of the parameters

P30	Free cutting time	Turn back time of the spindle after achieving the drilling depth
P32	Drilling feed	
P33	Drilling depth	
P34	Anticipation plane	Safety margin of the processing upper edge
P35	Retreat plane	To go around of obstacles in the setting axis
P36	No. of strokes	constant setting depth = $(P33 - P34) / P36$
P38	Safety margin	presetting = 1mm
P39	Gradual decrease	0 or - = off

### 5.3.2 G83 Deep-hole drilling with constant setting depth (continued)

#### Example

```
N20 G56 G00      X0  Y0  Z100      S1200   F1500   M03      T01  M16
N30 G83 Z80 P30:1 P32:800 P33:0 P34:48 P35:60 P36:3 P38:1 P39:0
N40 M05 ...
```

#### Sequence plan

- 1 Switch spindle on (M03, M04) and X and Y axis in rapid traverse position.
- 2 After achieving the X and Y position the Z-axis runs in rapid traverse on those anticipation plane (P34).
- 3 After achieving the anticipation plane (P34) the Z axis with working feed moves (P32) to the 1. drilling depth ( $P34 + ((P33 - P34) * 1 / P36)$ ).
- 4 After achieving the 1. drilling path the Z axis drives back in rapid traverse up to the anticipation plane.
- 5 From the anticipation plane the Z axis drives afterwards in rapid traverse up to the 1. drilling depth plus safety margin ( $P34 + ((P33 - P34) * 1 / P36) + P38$ ).
- 6 The Z axis induces itself with working feed (P32) to 2. drilling depth ( $P34 + ((P33 - P34) * 2 / P36)$ ).
- 7 After achieving the 2. drilling depth the Z axis drives back in rapid traverse up to the anticipation plane.
- 8 From the anticipation plane the Z-axis drives afterwards in rapid traverse up to the 2. drilling depth plus safety margin ( $P34 + ((P33 - P34) * 2 / P36) + P38$ ).
- 9 The Z axis induces itself with working feed (P32) to the 3. drilling depth etc. to P33.
- 10 With the achieving of the drilling depth (P33) a programmed free cutting time (P30) becomes been waiting.
- 11 Afterwards the Z axis in rapid traverse moves back on the retreat plane (P35) and afterwards the spindle is switched off (M05).

### 5.3.3 G83 Deep-hole drilling with degressive setting depth

If the parameter P39:1 is programmed (the input value is not determining), the programmed drilling depth (P33) by repeated, reduced setting depth (gradual decrease) of the active drilling depth is achieved.

The active drilling depth is  $P37 - (n-1) * P36$ , whereby  $n=1, 2, \dots$  is (nth setting depth = stroke).  
 If  $P37 - (n-1) * P36 \leq P36$ , the active drilling depth = P36 is set.

Before each setting depth checked, whether two setting depths (drilling depth calculated + P36 (gradual decrease measure)) still feasible are. If not, then the new drilling depth calculated by remainder path / 2 and executed the final two setting depths with this value.




Figure 5-21

#### Meaning of the parameters

P32	drilling feed	
P33	drilling depth	
P34	anticipation plane	safety margin of the processing upper edge
P35	retreat plane	to the run around of obstacles in the setting axis
P36	setting depth	degressive setting depth
P37	1. stroke	degressive setting depth
P38	safety margin	presetting = 1mm
P39	gradual decrease	degressive setting depth
		1 = on

### 5.3.3 G83 Deep-hole drilling with degressive setting depth (continued)

#### Example

```

N20 G56 G00      X0  Y0  Z100      S1200   F1500   M03      T01  M16
N30 G83 Z80 P32:800 P33:0   P34:52  P36:4   P37:15  P38:1   P39:1
N40 M05 ...

```

#### Sequence plan

- 1 Switch spindle on (M03, M04) and X and Y axis in rapid traverse position.
- 2 After achieving the X and Y position the Z axis runs on the anticipation plane (P34).
- 3 After achieving the anticipation plane the Z axis with working feed induces itself to  
1. drilling depth (P37) on the Z position:  $P34 - P37 = 52 - 15 = 37$ .
- 4 After achieving 1.drilling depth returns the Z axis in rapid traverse to the anticipation plane.
- 5 Of the anticipation plane in rapid traverse up to the 1. drilling depth plus safety margin (P38).
- 6 With working feed to 2. drilling depth on the Z position:  $37 - 11 = 26$  ( $11 = 15 - 4$ ).
- 7 After achieving the 2. drilling depth to the anticipation plane back.
- 8 Of the anticipation plane in rapid traverse up to 2. drilling depth plus safety margin (P38).
- 9 With working feed to the 3. drilling depth on the Z position:  $26 - 7 = 19$  ( $7 = 11 - 4$ ).
- 10 After achieving the 3. drilling depth to the anticipation plane back.
- 11 Of the anticipation plane in rapid traverse up to the 3. drilling depth plus safety margin (P38).
- 12 With working feed to 4. drilling depth on the Z position:  $19 - 4 = 15$  (P36:4).
- 13 After achieving the 4. drilling depth to the anticipation plane back.
- 14 Of the anticipation plane in rapid traverse up to 4. drilling depth plus safety margin (P38).
- 15 With working feed to 5. drilling depth on the Z position:  $15 - 4 = 11$  (P36:4).
- 16 After achieving the 5. drilling depth to the anticipation plane back.
- 17 Of the anticipation plane in rapid traverse up to 5. drilling depth plus safety margin (P38).
- 18 With working feed to 6. drilling depth on the z-position:  $11 - 4 = 7$  (P36:4).
- 19 After achieving the 6. drilling depth to the anticipation plane back.
- 20 Of the anticipation plane in rapid traverse up to 6. drilling depth plus safety margin (P38).
- 21 With working feed to 7. drilling depth on the Z position:  $7 / 2 = 3,5$ .
- 22 After achieving the 7. drilling depth to the anticipation plane back.
- 23 Of the anticipation plane in rapid traverse up to 7. drilling depth plus safety margin (P38).
- 24 With working feed to 8. drilling depth on the Z position:  $3.5 - 3.5 = 0$ .
- 25 After achieving 8. drilling depth returns the Z axis in rapid traverse to the anticipation plane.



### 5.3.4 G84 Thread cutting (continued)

#### Example

N10 ...

N20 G56 G00 X0 Y0 Z100 S1200 F1500 M03 T01 M16

N30 **G84** Z80 **P32:10 P33:20 P34:52** P35:60

N40 M05 ...

#### Sequence plan

- 1 Switch spindle on (M03, M04) and X and Y axis in rapid traverse position.
- 2 After achieving the X and Y positions the Z axis runs on the anticipation plane.
- 3 After achieving the anticipation plane the Z axis is joined with the spindle axis and the Z axis moves to the drilling depth (P33).
- 4 With the achieving of the drilling depth the spindle rotation is turned around and the spindle reversal time (P30) recalled.
- 5 At process of the retention time the Z axis returns to the anticipation plane (P34).
- 6 With the achieving of the anticipation plane the Z-axis in rapid traverse becomes on the retreat plane (P35) driven and afterwards the spindle switched off (M05).

5.3.5 G85 Drilling with retraction at feed rate




Figure 5-23

**Meaning of the parameters**

- P30 free cutting time
- P32 drilling feed
- P33 drilling depth
- P34 anticipation plane
- P35 retreat plane

safety margin of the processing upper edge to running around obstacles in the setting axis

### 5.3.5 G85 Drilling with retraction at feed rate (continued)

#### Example

N10 ...

N20 G56 G00 X0 Y0 Z100 S1200 F1500 M03 T01 M16

N30 **G85** Z80 P30:1 P32:800 **P33:0** **P34:32**

N40 M05 ...

#### Sequence plan

- 1 Switch spindle on (M03, M04) and X and Y axis in rapid traverse position.
- 2 After achieving the X and Y positions the Z axis runs in rapid traverse on those anticipation plane (P34).
- 3 After achieving the anticipation plane the Z axis with working feed becomes the drilling depth (P33) moves.
- 4 With the achieving of the drilling depth a programmed free cutting time (P30) is waited for.
- 5 Afterwards retreat in the working feed to anticipation plane and becomes following spindle switched off (M05).

## 5.4 G86 / G87 / G88 / G89 cycle patterns

The cycle patterns serve for the repeated version of process cycles (boring and milling cycles). Over the programming of certain parameters the points of positioning are described, in which the process cycles are to be executed.

The parameters cover the definition of a target as well as the number of points of positioning. For definition of the target and the points of positioning different programming types can be used.

The partitioning of the cycle patterns takes place on the basis of geometrical criteria:

G86	vector type processing
G87	parallelogram type processing
G88	grid type processing
G89	circle type processing

**The cycle patterns are block by block effective.**

**The parameter inputs remain against it modal effectively.**

In order to avoid over regulation, all parameters are to be reset, which are not used with a programming type.

A compilation of the parameters is listed on the next side.

**5.4 G86 / G87 / G88 / G89 cycle patterns (continued)**

**Parameter for G86 vector type processing**

P100	coordinate of the 1. axis (X)
P101	coordinate of the 2. axis (Y)
P103	vector bracket related to the 1. axis (X)
P104	vector length
P105	vector splitting
P106	number of points of positioning

**Parameter for G87 periphery processing of a parallelogram**

Vector 1	Vector2	
P100	P110	coordinate of the 1. axis (X)
P101	P111	coordinate of the 2. axis (Y)
P103	P113	vector bracket related to the 1. axis (X)
P104	P114	vector length
P105	P115	vector splitting
P106	P116	number of points of positioning

**Parameter for G88 grid processing**

Vector 1	Vector 2	
P100	P110	coordinate of the 1. Axis @@@(x)
P101	P111	coordinate of the 2. Axis @@@(y)
P103	P113	vector bracket related to the @@@1.Achse (x)
P104	P114	vector length
P105	P115	vector splitting
P106	P116	number of points of positioning

**Parameter for G89 circle processing**

P120	coordinate of the 1. axis (X) of the pitch diameter focal point
P121	coordinate of the 2. axis (Y) of the pitch diameter focal point
P122	circle diameter
P123	start bracket
P124	travel bracket
P125	vector part
P126	number of points of positioning

## 5.4 G86 / G87 / G88 G89 cycle patterns (continued)

### Messages

Messages to the cycles have numbers, which start with 8xxx.  
A listing is to be found in the paragraph ' 9,9 messages of cycles '.

Messages appear, if

- the target with a programming type by programming of additional parameters multiple is defined and no agreement is achieved.
- the target is not sufficiently determined.

In these cases the program is interrupted.

Therefore all parameters are to be reset, which are not used with a programming type for the definition of the target.

## 5.4 G86 / G87 / G88 G89 cycle patterns (continued)

### Call of process cycles with cycle patterns

Together with a cycle pattern call a process cycle (boring or milling cycle) can be activated, which is then called after each positioning step in the cycle pattern.

### Effectiveness of M functions

Pre path M functions are executed in the starting point A, after path M functions in the target B.

M functions, which are effective within cycles (e.g. M03, M05,..), become for each cycle call pre path or after path actively.

### Start the points of positioning

Starting the respective points of positioning effected with G00. Contains the theorem a cycle call, in each point of positioning the cycle is executed. Otherwise an accurate stop (G08) is activated

### 5.4.1 Vector type processing

#### Start point and target point with G86




Figure 5-24 A = Start point, B = Target point

#### Meaning of the parameters

- P100 AB coordinate of the 1. axis (X)
- P101 AB coordinate of the 2. axis (Y)
- P103 vector bracket related to the 1. axis (X)
- P104 vector length
- P105 vector splitting
- P106 number of positioning points

5.4.1 Vector type processing (continued)

**Example 1: Programming with AB coordinates P100 and P101 and number of points of positioning**

```

N10    G00    X20    Y20    Z100    S500    M03    T01    M16
N20    P100:90 P101:30 P103:– P104:– P105:– P106:4
N30    P32:800 P33:0    P34:32
N40    G86    G81
    
```

**Example 2: Programming with vector brackets P103 and vector length P104 and number of points of positioning**

```

N10    G00    X20    Y20    Z100    S500    M03    T01    M16
N20    P100:– P101:– P103:20 P104:96 P105:– P106:4
N30    P32:800 P33:0    P34:32
N40    G86    G81
    
```

**Example 3: Programming with vector brackets P103 and vector splitting P105 and number of points of positioning**

```

N10    G00    X20    Y20    Z100    S500    M03    T01    M16
N20    P100:– P101:– P103:20 P104:– P105:32 P106:4
N30    P32:800 P33:0    P34:32
N40    G86    G81
    
```

**5.4.1 Vector type processing (continued)**

**Process**

- N10 programming of the start point with X and Y
- N20 programming of the target point with the parameters P100 and P101 or P103 and P104 or P103 and P105
- N30 programming of the parameters of the process cycle
- N40 calls of the cycle pattern and the process cycle

Sequence of the operation: position first and then process.

Note: not used parameters are to be reset.

### 5.4.1 Vector type processing (continued)

#### Programming the start point A

The start point is established by programming the X, Y.. coordinates. If these coordinates have not been programmed the machine stop location coordinates are used as the starting coordinates.

#### Programming the target point B

##### Programming mode 1

The target point B is established by programming the X (AB) P100 and Y (AB) P101 coordinates.

$$B_x = A_x + X(AB)$$

$$B_y = A_y + Y(AB)$$

##### Programming mode 2

The target point B is established by programming the angle P103 and the length of vector P104.

$$X(AB) = P104 * \cos P103$$

$$Y(AB) = P104 * \sin P103$$

##### Programming mode 3

The target point B is established by programming the angle P103, the vector part P105 and the number of positioning points P106.

For P106 equal to or greater than 2 the following applies:

$$X(AB) = P105 * (P106-1) * \cos P103$$

$$Y(AB) = P105 * (P106-1) * \sin P103$$

For P106=0 and P106=1:

$$X(AB) = P105 * P106 * \cos P103$$

$$Y(AB) = P105 * P106 * \sin P103$$

**5.4.1 Vector type processing (continued)**

**Data analysis**

**Angel P103**

- ≥ 0°: angle in positive mathematical sense (left-handed rotation) referred on the positive vector of the 1. axis (X)
- < 0°: angle in negative mathematical sense (right-handed rotation) referred on the positive vector of the 1. axis (X)
- ≥ 360°: reduction of the angle on smaller 360°

**Influence of the planes that are switched on**

The sizes X and Y and the angle P103 are plane-oriented.

Plane	Axis	P103 referred on the positive vector of the axis
G17 (XY)	X Y	X
G18 (ZX)	Z X	Z
G19 (YZ)	Y Z	Y

**Vector length P104 and vector part P105**

Negative values are changed into positive values without indication.

### 5.4.1 Vector type processing (continued)

#### Number of positioning points P106

Negative values are changed into positive values.  
Non-integer values are round down to the next smaller integer value.

Number of positioning points P106=0

The target point B (from A to B) is approached directly; eventually activated cycles are not executed.

Number of positioning points P106=1

The target point B (from A to B) is approached directly and an eventually activated cycle is executed in the target point.

#### Number of positioning points P106 and vector part P105

Further identifications for the programming modes 1 and 2 could be the number of positioning points P106 or the vector part P105.

When indicating the vector part P105, the number of positioning points is determined:

$$N = (AB / P105) + 1$$

After this, the vector part is calculated:

$$T' = AB / (P106 - 1)$$

If the calculated number N is an integer number:

$$P105' = P105$$

If the calculated number N is not an integer number:

$$P105' \text{ unequal to } P105$$

The positioning points is executed with the value T'.

5.4.2 G87 Parallelogram type processing

Start and target point with G87




Figure 5-25

Meaning of the parameters

Vector 1    Vector 2

P100	P110	coordinate of the 1. axis (X)
P101	P111	coordinate of the 2. axis (Y)
P103	P113	ector bracket related to the 1. axis (X)
P104	P114	vector length
P105	P115	vector part
P106	P116	number of positioning points

### 5.4.2 G87 Parallelogram type processing (continued)

**Example 1: Programming with AB coordinates P100, P101 and P110, P111 and number of positioning points**

```

N10    G00    X20    Y20    Z100    S500    M03    T01    M16
N20    P100:90 P101:30 P110:20 P111:40 P103:-- P113:-- P104:--
        P114:-- P105:-- P115:-- P106:4  P116:3
N30    P32:800 P33:0    P34:32
N40    G87    G81

```

**Example 2: Programming with vector brackets P103, P113 and vector length P104, P114 and number of positioning points**

```

N10    G00    X20    Y20    Z100    S500    M03    T01    M16
N20    P100:-- P101:-- P110:-- P111:-- P103:20 P113:60 P104:96
        P114:46 P105:-- P115:-- P106:4  P116:3
N30    P32:800 P33:0    P34:32
N40    G87    G81

```

**Example 3: Programming with vector brackets P103, P113 and vector splitting P105, P115 and number of positioning points**

```

N10    G00    X20    Y20    Z100    S500    M03    T01    M16
N20    P100:-- P101:-- P110:-- P111:-- P103:20 P113:60 P104:--
        P114:-- P105:32 P115:23 P106:4  P116:3
N30    P32:800 P33:0    P34:32
N40    G87    G81

```

---

**5.4.2 G87 Parallelogram type processing (continued)**

**Process**

- N10 programming of the start point with X and Y
- N20 programming of the target point with the parameters  
P100, P110 and P101, P111 or P103, P113 and P104, P114 or P103, P113 and  
P105, P115
- N30 programming of the parameters of the process cycle
- N40 calls of the cycle pattern and the process cycle

Sequence of the operation: first position and then process.

Sequence of processing: for and return trip always  
first vector 1 and then vector 2

Note: not used parameters are to be reset

## 5.4.2 G87 Parallelogram type processing (continued)

### Programming of the start point A

The start point A is determined by programming the coordinates X, Y..

If the coordinates are not programmed, the coordinates of the machine location are used as start coordinates.

### Programming of the target points B and C

#### Programming mode 1

The target points B and C are determined by programming the coordinates X (AB) P100 / Y (AB) P101 and X (AC) P110 / Y (AC) P111.

$$\begin{aligned} \text{Target point B} \quad B_x &= A_x + X(AB) \\ B_y &= A_y + Y(AB) \end{aligned}$$

$$\begin{aligned} \text{Target point C} \quad C_x &= A_x + X(AC) \\ C_y &= A_y + Y(AC) \end{aligned}$$

#### Programming mode 2

The target points B and C are determined by programming the angles P103 / P113 and vector length P104 / P114.

$$\begin{aligned} \text{Target point B} \quad X(AB) &= P104 * \cos P103 \\ Y(AB) &= P104 * \sin P103 \end{aligned}$$

$$\begin{aligned} \text{Target point C} \quad X(AC) &= P114 * \cos P113 \\ Y(AC) &= P114 * \sin P113 \end{aligned}$$

#### Programming mode 3

The target points B and C are determined by programming the angles P103 / P113, the vector parts P105 / P115 and number of positioning points P106 / P116.

For P106 / P116 >= 2:

$$\begin{aligned} \text{Point B} \quad X(AB) &= P105 * (P106-1) * \cos P103 \\ Y(AB) &= P105 * (P106-1) * \sin P103 \end{aligned}$$

$$\begin{aligned} \text{Point C} \quad X(AC) &= P115 * (P116-1) * \cos P113 \\ Y(AC) &= P115 * (P116-1) * \sin P113 \end{aligned}$$

For P106 / P116 = 0 and P106 / P116 = 1 :

$$\begin{aligned} \text{Point B} \quad X(AB) &= P105 * P106 * \cos P103 \\ Y(AB) &= P105 * P106 * \sin P103 \end{aligned}$$

$$\begin{aligned} \text{Point C} \quad X(AC) &= P115 * P116 * \cos P113 \\ Y(AC) &= P115 * P116 * \sin P113 \end{aligned}$$

## 5.4.2 G87 Parallelogram type processing (continued)

### Data evaluation

#### Angle P103, P113

- ≥ 0°: angle in positive mathematical sense (left-handed rotation)  
referred on the positive vector of the x-axis
- < 0°: angle in negative mathematical sense (right-handed rotation)  
referred on the positive vector of the x-axis
- ≥ 360°: reduction of the angle on smaller 360°

#### Influence of the plane that is switched on:

The sizes X and Y and the angle P103, P113 are plane-oriented.

Plane	Axis	P103, P113 referred on the positive vector of the axis
G17 (XY)	X Y	X
G18 (ZX)	Z X	Z
G19 (YZ)	Y Z	Y

#### Vector length P104, P114 and vector part P105, P115

Negative values are changed into positive values without indication.

**5.4.2 G87 Parallelogram type processing (continued)****Number of positioning points P106, P116**

Negative values are changed into positive values.

Non-integer values are round down to the next smaller integer value.

Number of positioning points P106, P116 = 0

The target point B / C (from A to B / C) are approached directly; eventually activated cycles are not executed.

Number of positioning points P106, P116 = 1

The target points B / C (from A to B / C) are approached directly and an eventually activated cycle is executed in the target point.

**Number of positioning points P106, P116 and vector part P105, P115**

Further identifications for the programming modes 1 and 2 could be the number of drilling holes P106, P116 or the vector part P105, P115.

When indicating the vector part P105, P115, the number of drilling holes is determined:

$$P106, P116 = (AB / P105, P115) + 1$$

After this, the vector part is calculated:

$$P105', P115' = AB / (P106, P116 - 1)$$

If the calculated number P106, P116 is an integer number:

$$P105', P115' = P105, P115$$

If the calculated number P106, P116 is not an integer number:

$$P105', P115' \text{ unequal to } P105, P115$$

The drilling pattern is executed with the value P105', P115'.

5.4.3 G88 Grid type processing

Start and target point at G88




Figure 5-26

Meaning of the parameters

Vector 1    Vector 2

P100	P110	coordinate of the 1. axis (X)
P101	P111	coordinate of the 2. axis (Y)
P103	P113	vector bracket related to the 1. axis (X)
P104	P114	vector length
P105	P115	vector part
P106	P116	number of positioning points

### 5.4.3 G88 Grid type processing (continued)

**Example 1: Programming with AB coordinates P100, P110 und P101, P111 and number of positioning points**

N10	G00	<b>X20</b>	<b>Y20</b>	Z100	S500	M03	T01	M16
N20	<b>P100:90</b> P114:–	<b>P101:30</b> P105:–	<b>P110:20</b> P115:–	<b>P111:40</b> <b>P106:4</b>	P103:– <b>P116:3</b>	P113:–	P104:–	
N30	P32:800	P33:0	P34:32					
N40	<b>G88</b>	G81						

**Example 2: Programming with vector brackets P103, P113 and vector length P104, P114 and number of positioning points**

N10	G00	<b>X20</b>	<b>Y20</b>	Z100	S500	M03	T01	M16
N20	P100:– <b>P114:46</b>	P101:– P105:–	P110:– P115:–	P111:– <b>P106:4</b>	<b>P103:20</b> <b>P116:3</b>	<b>P113:60</b>	<b>P104:96</b>	
N30	P32:800	P33:0	P34:32					
N40	<b>G88</b>	G81						

**Example 3: Programming with vector brackets P103, P113 and vector splitting P105, P115 and number of positioning points**

N10	G00	<b>X20</b>	<b>Y20</b>	Z100	S500	M03	T01	M16
N20	P100:– P114:–	P101:– <b>P105:32</b>	P110:– <b>P115:23</b>	P111:– <b>P106:4</b>	<b>P103:20</b> <b>P116:3</b>	<b>P113:60</b>	P104:–	
N30	P32:800	P33:0	P34:32					
N40	<b>G88</b>	G81						

5.4.3 G88 Grid type processing (continued)

**Process**

N10 programming of the start point with X and Y

N20 programming of the target point with the parameters P100, P110 and P101, P111 or P103, P113 and P104, P114 or P103, P113 and P105, P115

N30 programming of the parameters of the process cycle

N40 calls of the cycle pattern and the process cycle

Sequence of the operation: first position and then process.

Sequence of processing: first with journey there first vector 1 completely and afterwards the first position on vector 2,  
  
then with return trip vector 1 completely and afterwards the next position on vector 2,  
  
then again with journey there vector 1 completely etc. until the final position on vector 2 achieves and the processing of vector 1 is executed  
  
thereafter the initial position is started.

Note: not used parameters are to be reset

### 5.4.3 G88 Grid type processing (continued)

#### Programming the start point A

The start point A is determined by programming the coordinates X, Y...  
 If the coordinates are not programmed, the coordinates of the machine location are used as starting coordinates.

#### Programming of the target points B and C

##### Programming mode 1

The target points B and C are determined by programming the coordinates X (AB) P100, Y (AB) P101 and X (AC) P110, Y (AC) P111.

<u>Target point B</u>	$B_x = A_x + X(AB)$	<u>Target point C</u>	$C_x = A_x + X(AC)$
	$B_y = A_y + Y(AB)$		$C_y = A_y + Y(AC)$

##### Programming mode 2

The target points B and C are determined by programming the angles P103, P113 and vector length P104, P114.

<u>Target point B</u>	$X(AB) = P104 * \cos P103$	<u>Target point C</u>	$X(AC) = P114 * \cos P113$
	$Y(AB) = P104 * \sin P103$		$Y(AC) = P114 * \sin P113$

##### Programming mode 3

The target points B and C are determined by programming the angles E1 / E2, the vector parts T1 / T2 and number of drilling holes N1 / N2.

For  $N \geq 2$ :

<u>Point B</u>	$X(AB) = P105 * (P106-1) * \cos P103$	<u>Point C</u>	$X(AC) = P115 * (P116-1) * \cos P113$
	$Y(AB) = P105 * (P106-1) * \sin P103$		$Y(AC) = P115 * (P116-1) * \sin P113$

For  $P106, P116 = 0$  and  $P106, P116 = 1$ :

<u>Point B</u>	$X(AB) = P105 * P106 * \cos P103$	<u>Point C</u>	$X(AC) = P115 * P116 * \cos P113$
	$Y(AB) = P105 * P106 * \sin P103$		$Y(AC) = P115 * P116 * \sin P113$

### 5.4.3 G88 Grid type processing (continued)

#### Data evaluation

#### Angle P103, P113

- $\geq 0^\circ$ : angle in positive mathematical sense (left-handed rotation)  
referred on the positive vector of the x-axis
- $< 0^\circ$ : angle in negative mathematical sense (right-handed rotation)  
referred on the positive vector of the x-axis
- $\geq 360^\circ$ : reduction of the angle on smaller  $360^\circ$

#### Influence of the plane that is switched on:

The sizes X and Y and the angle P103, P113 are plane-oriented.

Plane	Axis	P103, P113 referred on the positive vector of the axis
G17 (XY)	X Y	X
G18 (ZX)	Z X	Z
G19 (YZ)	Y Z	Y

#### Vector length P104, P114 and vector part P105, P115

Negative values are changed into positive values without indication.

**5.4.3 G88 Grid type processing (continued)****Number of drilling holes P106, P116**

Negative values are changed into positive values.  
Non-integer values are round down to the next smaller integer value.

Number of drilling holes P106, P116 = 0

The target points B / C (from A to B / C) are approached directly; eventually activated cycles are not executed.

Number of drilling holes P106, P116 = 1

The target points B / C (from A to B / C) are approached directly and an eventually activated cycle is executed in the target point.

**Number of drilling holes P106, P116 and vector part P105, P115**

Further identifications for the programming modes 1 and 2 could be the number of drilling holes P106, P116 or the vector part P105, P115.

When indicating the vector part P105, P115, the number of drilling holes is determined:

$$P106, P116 = (AB / P105, P115) + 1$$

After this, the vector part P105, P115 is calculated:

$$P105', P115' = AB / (P106, P116 - 1)$$

If the calculated number P106, P116 is an integer number:

$$P105', P115' = P105, P115$$

If the calculated number P106, P116 is not an integer number:

$$P105', P115' \text{ unequal to } P105, P115$$

The drilling pattern is executed with the value P105', P115'.

5.4.4 G89 Circle type processing

Start and target point at G88




Figure 5-27

Meaning of the parameters

P120	Coordinate of the 1. axis (X) of the positioning points
P121	Coordinate of the 2. axis (Y) of the positioning points
P122	Pitch circle diameter
P123	Start angle
P124	Travel angle
P125	Vector part
P126	Number of positioning points

#### 5.4.4 G89 Circle type processing (continued)

**Example 1:** Programming with centre coordinates P120, P121, circle diameter P122, start brackets P123 and travel bracket P124 and number of positioning points

```
N10    G00    Z100    S500
        M03    T01     M16

N20    P120:70 P121:20 P122:100 P123:18 P124:120 P125:-- P126:5

N30    P32:800 P33:0    P34:32

N40    G89    G81
```

**Example 2:** Programming with centre coordinates P120, P121, circle diameter P122, start brackets P123 and vector part P125 and number of positioning points

```
N10    G00    Z100    S500
        M03    T01     M16

N20    P120:70 P121:20 P122:100 P123:18 P124:-- P125:30 P126:--

N30    P32:800 P33:0    P34:32

N40    G89    G81
```

**5.4.4 G89 Circle type processing (continued)**

**process**

- N10 programming of the start point with P120, P121, P122 and P123
- N20 programming of the target point with the parameters P120, P121, P122, P123 and P124 or P120, P121, P122, P123 and P125
- N30 programming of the parameters of the process cycle
- N40 calls of the cycle pattern and the process cycle

Sequence of the operation: first position and then process.

Sequence of processing: dependent on the programmed type of interpolation  
G00, G01 or G02, G03 become the particulars  
positions straight linear or circular interpolates started.

Note: not used parameters are to be reset

#### 5.4.4 G89 Circle type processing (continued)

##### Programming the start point A

The starting point A always has to be determined by programming identifications at G89, i.e. the pitch circle centre point P120, P121, the pitch circle radius P122/2 and the starting angle P123.

##### Programming the target point B

###### Programming mode 1

The target point B is determined by programming the travel angle P124.

$$B_x = P120 + (P122/2) * \cos(P123+P124)$$

$$B_y = P121 + (P122/2) * \sin(P123+P124)$$

###### Programming mode 2

The target point is determined by programming the number of positioning points P126 and the vector part P125.

$$B_x = P120 + (P122/2) * \cos(P123 + (P126-1) * P125)$$

$$B_y = P121 + (P122/2) * \sin(P123 + (P126-1) * P125)$$

$$P124 = (P126-1) * P125$$

**5.4.4 G89 Circle type processing (continued)**

**Data evaluation**

**Angle P123**

≥ 0°: angle in positive mathematical sense (left-handed rotation)  
referred on the positive vector of the x-axis

< 0°: angle in negative mathematical sense (right-handed rotation)  
referred on the positive vector of the x-axis

≥ 360°: reduction of the angle on smaller 360°

**Influence of the plane that is switched on:**

The sizes X and Y and the angle P123 are plane-oriented.

Plane	Axis	P123 referred on the positive vector of the axis
G17 (XY)	X Y	X
G18 (ZX)	Z X	Z
G19 (YZ)	Y Z	Y

**Vector part P125**

Negative values are changed into positive values without indication.

**5.4.4 G89 Circle type processing (continued)****Number of positioning points P126**

Negative values are changed into positive values.  
Non-integer values are round down to the next smaller integer value.

Number of positioning points P126 = 0

The target point B (from A to B) is approached directly; eventually activated cycles are not executed.

Number of positioning points P126 = 1

The target point B (from A to B) is approached directly and an eventually activated cycle is executed in the target point.

**Number of positioning points P126 and vector part P125**

Further identifications for the programming modes 1 and 2 could be the number of positioning points P126 or the vector part P125.

When indicating the vector part P125, the number of positioning points P126 is determined:

$$P126 = (P124 / P125) + 1$$

After this, the vector part is calculated:

$$P125' = P124 / (P126-1)$$

If the calculated number P126 is an integer number:

$$P125' = P125$$

If the calculated number N is not an integer number:

$$P125' \text{ unequal to } P125$$

The drilling pattern is executed with the value P125'.



5.4.4 G89 Circle type processing (continued)

G02 or G03 actively




Figure 5-29

The positioning points are started with G02 or G03 and max. programmable feed speed.

Two cases are to be differentiated:

**The travel bracket is positive (anti-clockwise rotating)**

With G03 also the positioning direction is positive.

With G02 the positioning direction is negative (moving in opposite directions to the travel bracket).

**The travel bracket is negative (clockwise rotatingly)**

With G02 also the positioning direction is positive.

With G03 the positioning direction is negative (moving in opposite directions to the travel bracket).

## 5.5 Customer specific cycles

A cycle is a program that generates certain repeated sequences.

For user-specific cycles, these sequences are defined in a Z-program.

Example: Z1001  
N10 ...  
.  
.  
N40 P500 : P500+1  
.  
.  
N60 M30

The defined cycle can be started then in a machining program with a G-function.  
The G-function must have the same number as the Z-program.

Example: P2000  
  
N10 ...  
.  
.  
N60 P500 : 2 G1001  
.  
.  
N90 M30

The G-function numbers can be selected arbitrarily except those numbers that are already reserved for other functions.

Input variables can be transmitted to the Z-program with parameters. The parameter numbers P500 to P4999 are free for the user. P0 to P499 is reserved for BWO-cycles. If the BWO-cycles are not used, they are also free for the user.

Additional functions to the operating system

Additional functions could be implemented with a DLL (Dynamic Link Library) that is written in programming language C.

**6. Supplementary functions**

6.1	Program-controlling supplementary functions	6 - 2
6.1.1	M00 Measuring stop	6 - 3
6.1.2	M01 Synchronization	6 - 4
6.1.3	M02 Sub-routine skip back	6 - 5
6.1.4	M06 / M16 Tool functions	6 - 6
6.1.5	M23 Unconditional skip with statement of block number	6 - 7
6.1.6	M24 / M25 Program loops	6 - 8
6.1.7	M26 Supervision 'clear remaining travel'	6 - 9
6.1.8	M28 Unconditional skip in sub-routine with statement of block number	6 -10
6.1.9	M29 End of program with automatic program repetition	6 -11
6.1.10	M30 End of program	6 -12
6.2	Machine controlling supplementary functions	6 -13

**6.1 Program controlling supplementary functions**

M00 Measuring stop

M01 Synchronization

M02 Sub-routine skip back

M06 / M16 Tool functions

M23 Unconditional skip with statement of block number

M24 / M25 Program loops

M26 Supervision 'clear remaining travel'

M28 Unconditional skip in sub-routine

M29 End of program with program repetition

M30 End of program

If parameter skips are programmed in the NC block, they are treated with priority!

### 6.1.1 M00 Measuring stop

Program run is shut down and spindle stop becomes effective after completion of the block in which M00 is programmed. Automatic mode is possible after Auto-Stop.

With pressing the key 'Start' the NC program continues and the spindle is switched on.

Example: X37,95 Y12,76 M00

After approaching the coordinates X and Y the program sequence is interrupted.

The function operates block by block.

M00 may only be programmed when the tool-radius-contour correction (G40) is switched off.

## 6.1.2 M01 Synchronization

The function M01 causes a synchronization of program analysis and real time machining. M01 operates block by block and is executed after the path machining.

When processing a program the block analysis of the real time runs some blocks ahead.

Example:

```
N10 G01 F1000 X10 Y10  
N20 X20  
N30 X100  
N40 X50  
N50 P100:20
```

In this NC program the axes traverse in the current block N10, while the block analysis is already executing the parameter instruction of block N50.

This running ahead of the block analysis can be stopped through programming M01. IF M01 is programmed in a block, the block analysis at the block end is waiting until this block is really worked.

**6.1.3 M02 Sub-routine skip back**

After processing the block in which M02 is programmed, a skip back into the calling program is executed in a sub-routine in the calling program (after traverses, without stop).

**6.1.4 M06 / M16 Tool functions**

**M06** Tool change

see paragraph 7.1 Tool functions

**M16** Tool data call

### 6.1.5 M23 Unconditional skip

With M23 the program is continued at the indicated program - and block number.

The function operates block-by-block.

The skip is programmed with M23 and indicating program - and block number, e.g.

M23.110          skip to block 110 or

M23.10.110      skip in program 10 to block 110 .

## 6.1.6 M24 / M25 Program loop

### M24 Program loop start

With loop programming program parts of the same kind can be repeated.

The program loop start is programmed with M24 and indicating the runs, e.g. M24.07 (7 runs of the loop). The loop number is to be found in P8840.

It has to be considered, that the block, in which the program loop start is to be found (M24..), does not belong to the program loop.

The function M24 operates block-by-block.

### M25 Program loop end

This function marks the end the program loop. After processing the block in which M25 is programmed, the program skips back to the loop start. If all runs are worked, the program is continued with the block following on M25.

The function operates block-by-block.

**6.1.7 M26 Supervision 'Clear remaining travel'**

The supervision 'clear remaining travel' is active.

The function operates block-by-block and effective before axes movements.

From M26 on the interpolator supervises the signal 'clear remaining travel' from the PLC and executes the command. If the signal lines up already, the travel is cleared immediately.

### 6.1.8 M28 Unconditional skip in sub-routine

Program parts, which are repeated in a program, can be written as sub-routine. Also each arbitrary program can be called up as sub-routine, e.g.

M28.300            starts program 300 .

The control remembers the skip address and continues the calling program at the block following on M28, if the sub-routine is finished.

The sub-routine skip back can be programmed with M02.

A nesting of the sub-routines is possible four times.

The function M28 operates block-by-block.

**6.1.9 M29 End of program and program repetition**

After processing the block in which M29 is programmed, the program is finished, executed a skip at the beginning of the program and the program is restarted automatically.  
The preset G - functions become effective again.

IF M29 stands at the end of a program, which was called up as sub-routine, a sub-routine skip back is executed.

The function operates block-by-block.

### 6.1.10 M30 End of program and skip to program start

After processing the block in which M30 is programmed, the program is finished and a skip to the beginning of the program is executed (after traverse, with stop).

The preset G - functions become effective again. Besides that Spindle Stop and Coolants off become active.

The function operates block-by-block.

## 6.2 Machine controlling supplementary functions

Area : 0 .. 999

There may be programmed 8 M-functions per NC block.

The M-functions can be defined as

- before traverse
- after traverse
- with stop
- with skip

(Skip-M-functions are always before traverse with stop, see q1050 .. 1099.)

At M-functions with skip, the skip target can exist either only of the block number or of program number and block number

e.g.:

M41.2.10        If M-function confirmed, skip to program 2 block number 10

M41.10         If M-function confirmed, skip to block number 10

If the M-function is confirmed, it is skipped to the indicated block number and/or in the indicated program with indicated block number.

At a skip impending ways are deleted and the NC block buffer is cleared.

With no confirmation the NC block interpreter switches over to the next NC block.

**CNC TOOL**

---

**7. Tool**

7.1	Tool functions	7 - 2
7.2	Tool correction	7 -11
7.3	Principle of correction	7 -15
7.4	Change of tool radius	7 -18
7.5	Swichting on the correction	7 -19
7.6	Switching off the correction	7 -21
7.7	Special cases at inner contours	7 -23

## 7.1 Tool functions

### General to the tool data

- The tool length in the offsetting record is always taken into consideration in autooperation (according to G17 / G18 / G19 in 3. defined axis).
- In the case of NC program end or NC program abort the spindle tool data becomes theorem into the offsetting record copies.  
Thus tool offset compensations of the NC program (M16) become ineffective.  
When starting of the next NC program is immediately the length of the spindle tool actively (offsetting data).
- The tool length works as shift.  
The indicator position is the programmed position from the NC program.  
The tool length adds itself in the sum shift parameter (P12155).
- The who things radius works as correction.  
The indicator position is smaller or larger than the programmed position from that NC program.

## 7.1 Tool functions (continued)

### T Selection of the group of tools in the NC program

The tool number T is identified and treated with in the analysis. In the tool data array a browsing is started after the suitable group of tools.

When finding the programmed group of tools this record is copied into the PLC tool data array (P8050) and transferred thus to the PLC.

A transfer to the PLC finds however only,

- the first T call in the NC program or
- a modification of the T number.

#### Special case

If a tool is called, which already is in the spindle (P8100), then the PLC tool data array is filled not from the tool data pool, but the spindle tool record is only copied into the PLC tool record.

Example            N10        T5

#### T extension

For special customer adaptations the T function permits a covered subroutine reference. With each analyzed T, the NC memory is scanned for a Z5. If Z5 exists, then this cycle is covered called. With the call of Z5 the PLC Interface (P8050...) with the new data is described.

## 7.1 Tool functions (continued)

### Tool definitions t...

Existed in the system no tool tools, then can over the identifier, 't:', 'tr:', 'tq:', 'tl:' tool data to be set, with which a radius correction (G41/42) activated afterwards operates. These tool definition can be combined at will in a NC block.

With all functions the tool offsetting record is described (P8150...); i.e. there is temporary tool datas, which are overwritten at a Tx M6 or Tx M1 or at the program end.

For activating everything of these tool tools is not necessary M16.

#### ' t: ' - Tool radius correction

With the programming of ' t: ' in the offsetting record only the radius correction of the tool (P8162) is described and activated.

A G41/42 programmed afterwards uses the total of P8160 and P8162 as correction radius!

The quadrant and other tool datas remain unchanged!

This function is practical, in order to correct past tool radius.

Example:

```
N10 ...  
N20 t:0.5 {modification of the past tool radius }  
N30 G1 X100 Y100 G42  
N40 ...
```

#### ' tr: ' - Tool radius

With the programming of ' tr: ' in the offsetting record the radius correction of the tool (P8162) is set to zero and the tool radius (P8160) with the programmed value is described.

The quadrant and other tool data remain unchanged!

Example:

```
N10 ...  
N20 tr:50 { setting the tool radius }  
N30 G1 X100 Y100 G42  
N40 ...
```

**7.1 Tool functions (continued)****Tool definitions t...****'tl:' - Tool length**

With the programming of 'tl:' in the offsetting record the length correction of the tool (P8163) is set to zero and the tool length (P8161) with the programmed value is described. The quadrant and other tool datas remain unchanged!

Example:

```
N10 ...  
N20 tl:80 { setting the tool length }  
N30 G1 X100 Y100  
N40 ...
```

**'tq:' - Tool quadrant**

With the programming of 'tq:' in the offsetting record the tool quadrant (P8164) is set or modified. Other tool datas remain unchanged!

Example:

```
N10 ...  
N20 tr:5 tq:4 {setting a tool radius with quadrant }  
N30 G1 X100 Y100 G42  
N40 ...
```

**7.1 Tool functions (continued)****M06 Tool change**

With M06 the tool change is started up. M06 with synchronisation and stop must be defined (see P11051 or P8351).

2 possibilities the tool change consist to execute:

- 1. Tool change in the cycle
- 2. Tool change completely in the PLC implements.

- to 1. If the theorem analysis a M06 identifies, it is checked whether the cycle 6 (Z6) exists. There is Z6, then this sub-routine is called, in that the tool change one handles. The actual tool change may not then in the PLC any more with M06 to be executed. But other M function numbers must be used. At the program end of Z6 from the system synchronized and following will become the tool datas taken into consideration (M16).
- to 2. If Z6 does not exist, then this means that the PLC with the reception of M06 that Tool change executes. After acknowledgement of M06 the tool datas become taken into consideration (M16).

## 7.1 Tool functions (continued)

**Process of a tool change over PLC** (M06 with stop and synchronisation defines):

PLC receives M06

- If a tool is in the spindle, old tools placing.  
This is closed, as P8047 with the tool place is described.
- Subsequently, the tool (T) is changed.  
(tool number and tool place were transferred in the tool data theorem).  
If the change is final, this is acknowledged with the M function-acknowledgement.  
Beforehand P8045 must be however still described.

**7.1 Tool functions (continued)****Course of a tool change with Z6**

Z6 is called up as sub-routine with M06.

Example: Z6  
N10 P8047:1           store tool data  
N20 P8045:1           activate tool data  
N30 M30

N10 P8047:1   Store tool data

The tool data theorem in the spindle tool data theorem (P8100) is retransferred into the tool data array. If the spindle tool datas are from T0, one does not retransfer.

N20 P8045:1   Activate tool data

The tool data theorem (P8050...) becomes into the spindle tool data theorem (P8100...) and the offsetting record (P8150...) copies.

N30 M30

With the program end of Z6 the tool data are activated (M16).

**7.1 Tool functions****Example for course of a tool change with Z6**

```
NC main program
N...
N...
N100 T3 M6    Call up tool change
N..
N...
```

When calling up Z6, the parameter area P8050..8099 is actualized with the new tool data of T3.

**Z6**

```
N10 _wzwxl_x_pos := 1000; _wzwxl_y_pos:= 300; Definition of the position for laying down /
picking up

N30 P8100=P8050.200 Check if tool-old = tool-new

N40 P8100=0.100 Check if a tool is in the spindle
If not: do not store tool data

N50 G00 X:_wzwxl_x_pos Y:_wzwxl_y_pos M01 Approach position for lay down P8120:

N60 P8047:1 Store tool data (Trigger)

N100 P8050=0.200 Check if tool should be picked up.
No tool picking up at T0.

N120 G00 X:_wzwxl_x_pos Y:_wzwxl_y_pos M01 Approach position for picking up

N140 P8045:1 Activate tool data

N200 M30

#
```

**7.1 Tool functions (continued)**

**M16 Tool data call up**

M16 with T in the NC block e.g.: N10 T1 M16

During pre-analysis time the corresponding tool data block from the tool data block array is loaded into the actual settlement data block with M16 according to the programmed T-number. At T0 the settlement data block is cleared.

M16 without T in the NC block e.g.: N10 M16

The settlement data block is activated with M16.

The current spindle tool data block is not changed through M16. M16 can be transmitted to the PLC, if desired. This is not necessary for the function of the tool data call up. The tool radius is activated with calling up G41 / G42 (tool radius path correction left / right). The tool - length becomes active at the block end.

e.g.: N100 T2 M16	tool data call up
:	
N120 X100 Y100 G42	call up tool radius path correction

7.2 Tool correction

The workpiece programming with tool correction enables the application of tools with different dimensions (example: regrinding of tools).

The dimensions of the tools are indicated with the corresponding T-address. The tool data are calculated by the control on the target path.

This enables the programming of graphically determined workpiece correction and results that the time-costly calculation of base for the cutter center point path is discontinued.

The correction method used for the BWO-control is composed of a combination between intersection - and blending radius correction.

The tool correction is only accomplished in blocks, in which the traverse to be proceeded is unequal to zero (travel differences unequal to zero at straights, radius unequal to zero at circles). The blocks with travels equal to zero are executed at the intersection point or at the end of the inserted transition circle. The amount of one after another lying blocks with travels equal to zero is limited on 12.

Outer contour

Inner contour

Completion of the tool correction at the beginning of the transition circle

completion of the tool correction at the intersection point




Figure 7-1 Completion of the tool correction

## **7.2 Tool correction (continued)**

### **Tool dimensions**

With M06 / M16 the stored tool dimensions are activated and the tool correction is accomplished.

The tool dimensions of the active tool data are calculated into the position display. Thereby the position display of the tool axis is the same like the programmed target position, if the axis is driven in position.

The tool axis is determined by the active plane selection of the interpolation main plane. See also G17, G18, G19.

### **Tool radius**

With the traverse conditions G40, G41 and G42 is determined, whether and how the tool radius correction has to be calculated.

Any correction is stopped with G40.  
A preceded G41 or G42 is cancelled.

G41 means, that the tool is found on the left side of the programmed path (seen in feed direction).  
G42 means, that the tool is found on the right side of the programmed path (seen in feed direction).

The tool radius can be entered positive or negative.  
At a positive tool radius the programmed tool correction is calculated.  
At a negative tool radius the programmed tool correction is changed: G41 becomes G42 and G42 becomes G41.

The tool radius correction is executed in the indicated interpolation plane. Before changing the interpolation plane correction must be cancelled with G40.

The tool correction can calculate different tool radius, which can be called up with different T-functions.

7.2 Tool correction (continued)

Position of the tool

The relative position (quadrant) between tool and workpiece is indicated in P8164.

Definition of the quadrants

- P8164 = 1 to 8      quadrant 1 to 8
- P8164 = 0 = 9      no quadrant correction  
SP = SM
- SP                  theoretical tool peak
- SM                  radius center point of the tool





Figure 7-2

7.2 Tool correction (continued)

**Special case: Switch off the correction with changing the plane**

The switching off of the correction (G40) in a block with travel equal to zero followed by a block with changing plane (G17, G18, G19) leads to wrong positioning of the axes.

Example: N200 G40 Z100

G18 X20 Y50

switching off of the correction in plane G17 and travel equal to zero. position is approached wrong.

Solution: N200 G40 X40 Y100 Z100

N210 G18 X20 Y50

switching off of the correction in plane G17 and travel unequal to zero. position is approached right.




Figure 7-3 Definition of G41 and G42

### 7.3 Correction principle

If the correction is switched on, the path correction is always accomplished with the same principle:

The corrected path is displaced for the amount of the indicated radius value in reference to the programmed path. The thereby emerging path end points are determined by the cutting of the corrected path elements.

At the outer contour and at changing the correction a transition radius is inserted. At the inner contour the intersection is calculated.

The principle of the correction is explained in the following sketches:

Transition straight - straight







Figure 7-4

7.3 Correction principle (continued)

Transition straight - circle (also for circle - straight)

outer contour

inner contour



Tangential transitions






Figure 7-5


### 7.3 Correction principle (continued)

Transition circle - circle

outer contour



inner contour



Tangential transition





Figure 7-6

7.4 Change of the tool radius

When changing the tool radius, the intersections and transition circles are calculated first with the old radius.

The starting point (old radius) and the end point (new radius) of the corrected path do no more have the same distance to the programmed path. This is valid for straights and circles.




Figure 7-7

### 7.5 Switching on the correction

The programmed correction is calculated in each block.




Figure 7-8

7.5 Switching on the correction (continued)

outer contour

inner contour





Figure 7-9

7.6 Switching off the correction

outer contour

inner contour



take off tangentially




Figure 7-10

7.6 Switching off the correction (continued)




Figure 7-11


### 7.7 Special cases at inner contours

At inner contours undesirable contour errors can appear. In these cases the messages 1416 and 1420 are given out. The program is not interrupted.

The causes of these errors are:


- 1416 Too short travels in comparison with the dimension of the tool radius.
- 1420 Intersection not possible.

In the following figures the response of the control is illustrated for different cases.



Message 1223

Contour error




Message 1223

Contour error


Figure 7-12

7.7 Special cases (continued)




Message 1223

Contour error



Message 1223

Contour error



Message 1223

Contour error

Figure 7-13



## 8. Parameters

8.1	General		8 - 3
8.2	System initialisation	q1...	8 - 12
8.3	Channel descriptor	q100...	8 - 20
8.4	Operating mode network	q903...	8 - 32
8.5	Fixed defined channel parameters		8 - 34
	Milling cycles }	only if the cycles	P11... 8 - 34
	Drill cycle }	to be used,	P30... 8 - 35
	Cycle patterns }	otherwise are the parameters	P100 ... 8 - 36
	Measuring cycle }	freely available.	P140 ... 8 - 37
	Channel parameter	P7000...	8 - 38
	Tool data interface	P8040...	8 - 44
	Definition of the M functions	P8250...	8 - 51
	Messages	P8500...	8 - 56
	Channel barriers	P8510...	8 - 57
	Channel information	P8540...	8 - 58
	Defaults	P8600...	8 - 63
	Channel command at PLC	P8681...	8 - 65
	Channel command by PLC	P8700...	8 - 68
	Manual operation	P8747...	8 - 72
	Step-by-step operation	P8760...	8 - 74
	Handwheel	P8770...	8 - 75
	Sections	P8780...	8 - 76
	Home	P8790...	8 - 77
	Start data	P8800...	8 - 78
	Program-controlling parameters	P8848...	8 - 83
	Real time information theorem analysis	P8900...	8 - 94
	Preanalysis information block of the theorem interpreter	P9300...	8 - 97
	Preanalysis of records	P9500...	8 - 100
	Preanalysis NC block information block	P9700...	8 - 101

**8. Parameters**

8.6	System parameter		8 -102
	Key switch	P11000...	8 -102
	Active barriers	P11020...	8 -105
	Definition of the m-functions	P11050...	8 -106
	Internal oscilloscope	P11100...	8 -109
	Graphic parameter	P11120...	8 -110
	System command / information	P11130...	8 -111
	System memory / information	P11140...	8 -114
	System clock	P11160...	8 -115
	I/O circulation	P11170...	8 -116
	Event logging for diagnostic purposes	P11270...	8 -121
	System diagnosis	P11280...	8 -125
	System data for Interpolator	P11300...	8 -126
	Override	P11310...	8 -128
	Handwheels	P11400...	8 -130
	Couplings	P11480...	8 -131
	Spindle	P11640...	8 -133
	Robot system	P11800...	8 -135
8.7	Axis parameter		8 -142
	Machine data	P12000...	8 -143
	Drive data for SERCOS	P12070...	8 -158
	Area monitoring Axes	P12100...	8 -162
	Axis command / functions	P12110...	8 -165
	Parameter block by PLC	P12130...	8 -170
	Axis acknowledgements / information	P12150...	8 -177
	Parameter block to the PLC	P12180...	8 -181

## 8.1 General

The **System 900** puts 10000 to 50000 parameters at the users disposal, depending on the system size.

It is distinguished between two kinds of parameters:

System - Parameter q

Channel - Parameter P

### System - Parameter q

This is a linear array, which is generally accessible, from q0 .. q (max. parameter).

The area of q is subdivided in function blocks:

0 ... 99	General system-configuration
100 ... 999	Definition channel-descriptor
1000 ... 1999	System-setups, system overlapping data
2000 ... 9999	Axis data
10000 ...	Channel - Parameter

Notes:

Input 0 or — means 0 or reset

Counting method byte 1... 4

Counting method bit 0... 7

**8.1 General (continued)**

**Channel - Parameter P**

When programming a channel - parameter, a system parameter is always accessed in dependence on the channel - descriptor.

That means channel - parameters are actually system - parameters, whereby the channel - descriptor defines, which channel - parameter accesses on which system - parameter.

The assignment between channel - parameter and system - parameter is not linear. This assignment is defined in the channel - descriptor.

Channel - Parameter are virtual parameters, which show on a system - parameter. Therefore, the channel-parameter-number can be bigger than the maximum number of the parameters.

The area of P is subdivided into function - blocks:

0 ... 6999	User block 1 free user - parameter, real number definable in q103 Standard setup: 5000 parameters, subdivided in
0 ... 499	Reserved for BWO standard - cycles
0 ... 299	Cycles - transmission - area for (cycles - interface)
300 ... 399	Area reserved for cycles
400 ... 499	Area reserved for cycles Temporary data area Calculation fields, Scratch etc.
500 ... 6999	Free area for the user
7000 ... 9999	Fixed defined channel - parameter
11000 ... 11999	System - setup, system overlapping data, common area of all channels
12000 ... 18399	Axis data
20000 ... 29999	User block 2
30000 ... 39999	User block 3

8.1 General (continued)

Each physical axis occupies a parameter block of 200 parameters.

In the system has physical axis	the area	in the channel has logical axis	the area
1.	q2000 ... q2199,	1.	P12000 ... P12199,
2.	q2200 ... q2399,	2.	P12200 ... P12399,
3.	q2400 ... q2599,	3.	P12400 ... P12599,
4.	q2600 ... q2799,	4.	P12600 ... P12799,
5.	q2800 ... q2999,	5.	P12800 ... P12999,
6.	q3000 ... q3199,	6.	P13000 ... P13199,
7.	q3200 ... q3399,	7.	P13200 ... P13399,
8.	q3400 ... q3599,	8.	P13400 ... P13599,
9.	q3600 ... q3799,	9.	P13600 ... P13799,
10.	q3800 ... q3999,	10.	P13800 ... P13999,
11.	q4000 ... q4199,	11.	P14000 ... P14199,
12.	q4200 ... q4399,	12.	P14200 ... P14399,
13.	q4400 ... q4599,	13.	P14400 ... P14599,
14.	q4600 ... q4799,	14.	P14600 ... P14799,
15.	q4800 ... q4999,	15.	P14800 ... P14999,
16.	q5000 ... q5199,	16.	P15000 ... P15199,
17.	q5200 ... q5399,	17.	P15200 ... P15399,
18.	q5400 ... q5599,	18.	P15400 ... P15599,
19.	q5600 ... q5799,	19.	P15600 ... P15799,
20.	q5800 ... q5999,	20.	P15800 ... P15999,
21.	q6000 ... q6199,	21.	P16000 ... P16199,
22.	q6200 ... q6399,	22.	P16200 ... P16399,
23.	q6400 ... q6599,	23.	P16400 ... P16599,
24.	q6600 ... q6799,	24.	P16600 ... P16799,
25.	q6800 ... q6999,	25.	P16800 ... P16999,
26.	q7000 ... q7199,	26.	P17000 ... P17199,
27.	q7200 ... q7399,	27.	P17200 ... P17399,
28.	q7400 ... q7599,	28.	P17400 ... P17599,
29.	q7600 ... q7799,	29.	P17600 ... P17799,
30.	q7800 ... q7999,	30.	P17800 ... P17999,
31.	q8000 ... q8199,	31.	P18000 ... P18199,
32.	q8200 ... q8399	32.	P18200 ... P18399

In the channel descriptor physical axes are assigned to the channel axes (q110 ... q141, Byte 3).


8.1 General (continued)

Configuration example for system with one channel (q2:1)

Definition Channel 1

- q101 : 1 Channel no. 1
- q102 : 10000 Start 1. block
- q103 : 5000 Number parameter in the 1. user block
- q104 : 18000 Start 2. block
- q105 : 2000 Number parameter in the 2. user block

System parameter list






8.1 General (continued)

Configuration example for system with two channels (q2:2)

Definition Channel 1

- q101 : 1 Channel no. 1
- q102 : 10000 Start 1. block
- q103 : 5000 Number parameter in the 1. user block
- q104 : 18000 Start 2. block
- q105 : 2000 Number parameter in the 2. user block


System parameter list




Definition Channel 2

- q201 : 2 Channel no. 2
- q202 : 20000 Start 1. block
- q203 : 2000 Number parameter in the 1. user block
- q204 : 25000 Start 2. block
- q205 : 2000 Number parameter in the 2. user block

Parameter list Channel 1



Parameter list Channel 2





8.1 General (continued)

General to the Decimal / Hexadecimal and Binary format


display and input in the controller		allocation of the Byte's and Bit's	
Representation in <b>Decimal / Hexa</b> format		Representation in <b>Binary</b> format (half byte format)	
0	\$0	0 0 0 0	0 0 0 0
1	\$1	0 0 0 1	0 0 0 1
2	\$2	0 0 1 0	0 0 1 0
3	\$3	0 0 1 1	0 0 1 1
4	\$4	0 1 0 0	0 1 0 0
5	\$5	0 1 0 1	0 1 0 1
6	\$6	0 1 1 0	0 1 1 0
7	\$7	0 1 1 1	0 1 1 1
8	\$8	1 0 0 0	1 0 0 0
9	\$9	1 0 0 1	1 0 0 1
10	\$A	1 0 1 0	1 0 1 0
11	\$B	1 0 1 1	1 0 1 1
12	\$C	1 1 0 0	1 1 0 0
13	\$D	1 1 0 1	1 1 0 1
14	\$E	1 1 1 0	1 1 1 0
15	\$F	1 1 1 1	1 1 1 1

input in the **Hexa** format

with key ± clocks to \$ in display appears.

Now the digits know A, B, C, D, E, F over the following keys to be input :

- A key ' modifying '
  - B key ' pos 1 '
    - C key ' picture up '
      - D key ' resetting '
        - E key ' end '
          - F key ' picture down '
            - With the operate of the input key ↓ those become original functions modifying, pos 1 etc. again adjusted.



To meaning see display and input with parameter status, M functions etc.


8.1 General (continued)

Parameter status

Each parameter possesses 4 status bytes, in which additional information is contained. The parameter status is displayed in the menu parameter editor.

Example:

Parameter NR.    Status indication                      Meaning

P1000	\$ 30 02 04 01	
		<p>byte 1 parameter loaded</p> <p>byte 2 parameter is transferred to the operating panel</p> <p>byte 3 parameter closed, if barrier 2 is settinged</p> <p>byte 4 hexadecimal format / parameter in the EEPROM store</p>

Status byte 1	bit 0	0 1	Parameter is reset. Parameter is loaded.
	bit 1	-	
	bit 2	1	Parameter is loaded to the real time. This identifier works only in the AUTOMATIK operation when processing a NC program. Real time parameters do not become with an interpreting of the NC block (advance) described, but only if this NC block is actually processed. Real time parameters become from the Interpoator before the pre path M functional module described.
	bit 3	1	Parameter with synchronisation. This identifier works only in the AUTOMATIK operation when processing a NC program. Becomes from a NC program if parameters with this identifier described, becomes at the NC end of record synchronizes. (the advance of the theorem interpreter disassembled).
	bit 4	Inch bit. 0 1	Inch bit. Parameter is not influenced by input system. After switching the system of units of inch - > metric or metric - > inch becomes this parameter in each case into that different one system of units converted (see also P11308).
	bit 5 - 6	-	
	bit 7	1	FAST parameter. Parameter is transferred over fast SMMS channel. (system internal information).

8.1 General (continued)

Parameter status

Status byte 2	bit 0	1	Parameter is transferred when describing to the Interpolator.
	bit 1	1	Parameter is transferred when describing to the PLC. All parameters with settinged PLC bit become of the CNC transfer automatically after each switching on routine to the PLC.
	bit 2	1	Parameter is transferred when describing to the operating panel. With each run of the switching on routine this bit becomes with all parameters reset.
	bit 3	1	Identifier procedure parameter. (SMMS chain is passed through when describing).
	bit 4 - 5	-	
	bit 6	1	Parameter is transferred when each describing to the operating panel. (speed Par function)
	bit 7	0	Parameter sample identifier not settinged
		1	Parameter sample identifier settinged, i.e. if P11271..=4 becomes, describing this parameter in the sample buffer logs.

## 8.1 General (continued)

### Parameter status

Status byte 3		With activated parameter barrier
		- is the parameter status nevertheless to be described
		- can the PLC nevertheless the parameter value change
Bit 0	1	Parameters closed, if parameter barrier 1 is settinged
Bit 1	1	Parameters closed, if parameter barrier 2 is settinged
Bit 2	1	Parameters closed, if parameter barrier 3 is settinged
Bit 3	1	Parameters closed, if parameter barrier 4 is settinged
Bit 4 - 7	-	
Status byte 4	Bit 0 - 3	Format for display: Number of post-decimal positions
	Bit 4	0 Decimal notation
		1 Hex notation
	Bit 5	0 Parameters do not store
		1 Parameters in the EEPROM store
	Bit 6 - 7	-

## 8.2 System Initializing

If a parameter in the area of q0 . . . q9 is changed, the control must be reset with 'Clear parameter'.

- q1      Number of axes  
Is written at the end of the starting routine by the system. The number of axes is calculated according to the definitions in the channel descriptors (q110..). q1 is transmitted to the PLC.
- q2      Number of valid channel - descriptors.  
Corresponds to the number of channels started when initializing.
- q3      Number of q-parameters, minimum 30000.  
Attention: When making a change, the NC - memory is formatted.
- q4      -
- q5      Pointer on system data enlargement
- q6      -
- q7      -
- q8      CPU clock  
One describes by the system
- q9      Version of the operating system of the operating panel  
Parameter is written from the operating panel after the starting routine.  
Enable new operating panel commands  
0  
1      new actual position display

8.2 System - Initializing (continued)

q10 FLASH Functions / special functions

So long a FLASH function actively is, should not the system not switched off become! For processing a q10-Funktion itself the machine must in operating mode HAND to find.

99 Activate channel descriptors (function 99 is effective only with EA import)

Application:

With this function defined channel descriptors (q100.., q200.., q300..) become in accordance with q2 (number of valid channel descriptors) activates.

Channels are however not started!

This function is helpful while the loading of the machine data, even if here channel parameters must be described by channels, which not yet actively are.

Example:

```
q 2 : x
q 100 : ...
:
q 200 : ...
:
q 300 : ...
:
:
q 1000 : ...
:
q 2000 : ...
:
q 10 : 99 Activate channel descriptors
:
K1:P8250 : ...
:
K2:P8250 : ...
:
K3:P8250 : ...
:
```

**8.2 System - Initializing (continued)**

q10 Functions:

120 Reset all parameters in the FLASH

125 Reset all NC programs in the FLASH

170 Store all marked parameters in the FLASH memory (max. 14000 parameters).

Being supposed the parameter areas of several channels to be stored, the following is to be observed:

Channel descriptors that channels which can be stored must available / defined to be, i.e., q2 (number of channels) was changed, to start then the CNC is before memory again. Only with the passing through of the switching on routine become in the CNC, in accordance with q2, channels started.

In the machine data file with q10:99 if the channel descriptors was activated, so the parameters can to be stored immediately.

175 Store all visible NC programs / cycles from that NC memory in the FLASH (max. 262kBytes).

In the starting routine after the ' NC memory ' all will reset in the FLASH stored programs into the NC memory written back.

176 Store all cycles of the NC memory in the FLASH

In the starting routine after the ' NC memory ' all will reset in the FLASH stored programs into the NC memory written back.

190 Restore q0..q999 from the FLASH memory.

200 Restore all parameters (apart from q0..q999) from the FLASH memory.

205 Restore all NC programs / cycles from the FLASH.

## 8.2 System - Initializing (continued)

500 With the I/O picture in the CNC direktory of the NC memory one displays.

501 With the I/O picture in the CNC Direktory FLASH Contents are displayed.

510 The CNC DLL Left is removed

Caution: With the next start of the system, those is to CNC DLL not more for the order.

Function is executed only if in q11:510 one enters before.

520 The switch ' NO\_DMA ' is removed

Function is executed only if in q11:520 one enters before.

521 The switch ' NO\_DMA ' is settinged

Function is executed only if in q11:521 one enters before.


530 The switch ' PLC\_BIG ' is removed

Function is executed only if in q11:530 one enters before.

531 The switch ' PLC\_BIG ' is settinged

Function is executed only if in q11:531 one enters before.

8.2 System - Initializing (continued)



**8.2 System - Initializing (continued)**

q12 Operating system - version  
q13 Operating system - check sum  
q14 Operating system - time stamp day  
q15 Operating system - time stamp month  
q16 Operating system - time stamp year  
q17 Operating system - time stamp hour  
q18 Operating system - time stamp minute  
q19 Operating system - time stamp second

q22 DLL version  
q23 DLL check sum  
q24 DLL time stamp day  
q25 DLL time stamp month  
q26 DLL time stamp year  
q27 DLL time stamp hour  
q28 DLL time stamp minute  
q29 DLL time stamp second

q32 PLC version (planned)  
q33 PLC check sum (planned)  
q34 PLC time stamp day (planned)  
q35 PLC time stamp month (planned)  
q36 PLC time stamp year (planned)  
q37 PLC time stamp hour (planned)  
q38 PLC time stamp minute (planned)  
q39 PLC time stamp second (planned)

q42 OP version (planned)  
q43 OP check sum (planned)  
q44 OP time stamp day (planned)  
q45 OP time stamp month (planned)  
q46 OP time stamp year (planned)  
q47 OP time stamp hour (planned)  
q48 OP time stamp minute (planned)  
q49 OP time stamp second (planned)

**8.2 System - Initializing (continued)****ESR (starting routine) information**

q50	Info	1	Parameters are deleted in ESR.
		0	Parameters are not deleted in ESR. Parameter shows information of the latest ESR.
q51	Info	1	Parameters are deleted in ESR. Parameter is waiting and has to be deleted by the user.
q52	Info	1	NC program memory is deleted in ESR.
		0	NC program memory is not deleted in ESR. Parameter shows information of the latest ESR.
q53	Info	1	NC program memory is deleted in ESR. Parameter is waiting and has to be deleted by the user.
q60	Password	1	(planned)
:			
q68	Password	9	(planned)
q70	Priority PLC		(planned)
q71	Priority channel	1	(planned)
:			
q78	Priority channel	8	(planned)

8.2 System - Initializing (continued)

Internal system parameter to the PLC

- q97 Fatal error  
0 or — No error  
< > 0 Error number  
a cause for fatal error (M1800)
- q98 Error message information for the display  
q98 and q99 are set again at each channel changeover
- Byte 1 Channel 1  
Bit 0: System message  
Bit 1: High priority message  
Bit 2: Low priority message  
Bit 3: Display message  
Bit 4: PLC high priority message  
Bit 5: PLC low priority message  
Bit 6: free  
Bit 7: free
- Byte 2 Channel 2
- Byte 3 Channel 3
- Byte 4 Channel 4
- q99 Error message informations  
Byte 1 Channel 5

## 8.3 Channel - descriptor

The channel - descriptors are in the area of q100 ... 899, that means:

Channel 1 q100 ... q199  
Channel 2 q200 ... q299  
Channel 3 q300 ... q399  
Channel 4 q400 ... q499  
Channel 5 q500 ... q599  
Channel 6 q600 ... q699  
Channel 7 q700 ... q799  
Channel 8 q800 ... q899

If a parameter in the area of q100 ... q899 is changed, the control must be restarted.

**8.3 Channel - descriptor (continued)****Parameters for channel - descriptor 1**

- q101 Channel - No. 1 channel 1 fix defined
- q102 Parameter - relocator  
Here is defined, from which q on the channel starts, e.g. q102: 10000,  
i.e. P0 shows on q10000
- q103 Amount of channel - parameters in the 1st user block P0 ... P6999  
Here is defined, how many parameters actually should be reserved.  
Input: 1 ... 7000  
The fixed defined channel-parameters succeed to the 1st user block  
(3000 parameters).
- q104 Parameter - relocator for 2nd user block P20000 ...  
Here is defined, from which q on this block starts, e.g. q104: 15000,  
i.e. P20000 shows on q15000  
The area for the fixed defined channel-parametes is between the 1st. and 2nd user  
block (3000 parameter).
- q105 Amount of the channel - parameters in the 2nd. user block P20000 ... P29999  
Here is defined, how many parameters actually should be reserved.  
Input: 1 ... 10000
- q106 Parameter - relocator for 3rd user block P30000 ...  
Here is defined, from which q on this block starts, e.g. q106: 10000  
i.e. P30000 shows on q10000
- q107 Amount of channel - parameters in the 3rd. user block P20000 ... P39999  
Here is defined how many parameters actually should be reserved.  
Input: 1 ... 10000



8.3 Channel - descriptor (continued)

Parameters for channel - descriptor 1

q110 Axis name and axis assignment  
 Here is defined, with which name the axis is programmed and which physical axis is addressed.  
 The Control determines with the system initialising the number of the axes available in the channel using this data.

1st. log. axis assignment -> to physical axis!  
 byte 1 Axis name (ASCII)

ASCII	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
Hex	41	42	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F	50	51	52	53	54	55	56	57	58	59	5A
ASCII	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z
Hex	61	62	63	64	65	66	67	68	69	6A	6B	6C	6D	6E	6F	70	71	72	73	74	75	76	77	78	79	7A

Not certified axis identifiers are deposited with raster.

byte 2 Axis identifier extended 1... 8  
 e.g.: X1, X2 etc.  
 note: If byte 1 and byte 2 = 0,  
 there is no actual position display at the operating panel.  
 If byte 2 = 0, consists the axis identifier only of one character (byte 1).

byte 3 Physical axis number 1... 32  
 Defines, which physical axis is to be addressed.  
 To observe: Input in the hexadecimal system  
 e.g.: axis number 32 —> input: \$20



byte 4 Key allocation  
 Defines, with which key in the operating panel axis block this axis one selects.  
 0 Axis is not selectable  
 1... 79 Key number  
 To observe: Input in the hexadecimal system  
 e.g.: key number 66 —> input: \$42

8.3 Channel - descriptor (continued)


Parameters for channel descriptor 1

q110 Axis identifier and axis allocation (continuation)

Examples:



Key numbers



- q111 2nd. log. Axis
- q112 3rd. log. Axis
- :
- q141 32nd.log. Axis

**8.3 Channel - descriptor (continued)****Parameters for channel - descriptor 1**

q142	Spindel assignments	
:	Assignment of the in the NC - program programmed spindle data to	
q149	the corresponding spindle blocks. Example: q143 : 4	
	When programming S2 in the NC - program, the number of revolutions in the 4th.	
	spindle block is changed. Input: 1...8	
q142	Spindle block reference for S	
q143	Spindle block reference for S2	
q144	Spindle block reference for S3	
q145	Spindle block reference for S4	
q146	Spindle block reference for S5	
q147	Spindle block reference for S6	
q148	Spindle block reference for S7	
q149	Spindle block reference for S8	
q150	Polar co-ordinate system : Name for radius (e.g. 'x')	Input the ASCII - code
q151	Polar co-ordinate system : Name for angles (e.g. 'c')	Input the ASCII - code

**8.3 Channel - descriptor (continued)****Parameters for channel - descriptor 1**

q152 Definition of the coordinate system for G17  
byte 1 1. logical axis number abscissa (horizontal axis)  
01 centre point identifier I  
byte 2 2. logical axis number ordinate (vertically axis)  
02 centre point identifier J  
byte 3 3. logical axis number  
03 vertically axis on the interpolation plane.  
default \$030201

q153 Definition coordinate system for G18  
byte 1 1. logical axis number abscissa (horizontal axis)  
03 centre point identifier K  
byte 2 2. logical axis number ordinate (vertically axis)  
01 centre point identifier I  
byte 3 3. logical axis number  
02 vertically axis on the interpolation plane.  
default \$020103

q154 Definition coordinate system for G19  
byte 1 1. logical axis number abscissa (horizontal axis)  
02 centre point identifier J  
byte 2 2. logical axis number ordinate (vertically axis)  
03 centre point identifier K  
byte 3 3. logical axis number  
01 vertically axis on the interpolation plane.  
default \$010302

8.3 Channel - descriptor (continued)

Parameters for channel - descriptor 1

- q157 CNC error message Acknowledgement  
 0 or — The acknowledgement of pending CNC Error messages takes place with mode change after HAND (—> when describing P8683). Additional is possible it to acknowledge over P8508 CNC Error messages.  
 1 The acknowledgement of pending CNC Error messages takes place only with describing P8508.  
 With the mode change after HAND NO CNC becomes error messages acknowledges.
- q158 M function definition block from system or channel  
 0 or — M0..M199 are defined in the system block (i.e. P11050..P11099)  
 M200..M999 are defined in the channel block (i.e. P8300..P8499)  
 1 M0..M999 are defined in the channel block (i.e. P8250..P8499)
- q159 Default of the number of post-decimal positions of the position parameters  
 After ' parameter = resetting ' (switching on routine) the following parameters become (in accordance with contents of q159 adjusted in the FLASH Memory) to post-decimal positions:  
 - axis displays P12150... 12169....  
 - null point record  
 - tool data theorem (starting from P10)  
 0 or — 3 post-decimal positions (standard adjustment)
- q166 Definition of the Robot record (1... 2)  
 Robot record 1 (P11800..P11809)  
 Robot record 2 (P11810..P11819)  
 0 or — off  
 1 on
- q167 Deinition of the polar record (1... 2)  
 Polar record 1 (P11820..P11824)  
 Polar record 2 (P11825..P11829)  
 0 or — off  
 1 on

**8.3 Channel - descriptor (continued)**

**Parameters for channel - descriptor 1**

q171	Number zero point blocks Standard adjustment 1	work areas (see P8555)
q172	Number of additional groups per zero point blocks Defined, from many individual shifts itself the total shift together settings. Standard adjustment 0	
q173	Number of items (axes) per group Number of entries per zero point. The zero point array always becomes for 7 points of zero created. Number of used parameters:	
	Number zero point blocks * (number of groups +1) * number of items per group * 7	(q171 of work areas) (q172 + 1) (q173 axes) (number of points of zero with q174 = 0, -)
-----		
	Number of used parameters for zero point array	
q174	Number of usable, programmable points of zero 0 or — (preset) 7 available points of zero G53.. G59 (G153 always programmable)	
	1 G154.. G159 additionally programmable altogether 13 points of zero available G53.. G59, G154.. G159	
	2 G254.. G259 additionally programmable altogether 19 points of zero available G53.. G59, G154.. G159, G254.. G259	
	:	
	9 G954.. G959 additionally programmable altogether 61 points of zero available G53.. G59, G154.. G159.... G954.. G959	
	The zero point array is increased at additional points of zero: Number of used parameters:	
	Number zero point-corrodes * (number of groups + 1) * number of items per group * number of points of zero	(q171 of work areas) (q172+1) (q173 axes) (q174*6 + 7)
-----		
	Number of used parameters for null point array	

### 8.3 Channel - descriptor (continued)

#### Zero point records q170... q174

Example: Zero point box with 2 work areas

q170	20000	at the beginning of the zero point record
q171	2	number of zero point blocks (work areas)
q172	2	number of additional groups per zero point block (shift)
q173	3	number of items (axes) per group
q174	-	number of usable, programmable zero points: G53... G59 = 7

Work area			sum shift	shift 1	shift 2
Work area 1	G53	1. Achse	P20000	P20021	P20042
		2. Achse	P20001	P20022	P20043
		3. Achse	P20002	P20023	P20044
	G54	1. Achse	P20003	P20024	P20045
		2. Achse	P20004	P20025	P20046
		3. Achse	P20005	P20026	P20047
	G55	1. Achse	P20006	P20027	P20048
		2. Achse	P20007	P20028	P20049
		3. Achse	P20008	P20029	P20050
	G56	1. Achse	P20009	P20030	P20051
		2. Achse	P20010	P20031	P20052
		3. Achse	P20011	P20032	P20053
	G57	1. Achse	P20012	P20033	P20054
		2. Achse	P20013	P20034	P20055
3. Achse		P20014	P20035	P20056	
G58	1. Achse	P20015	P20036	P20057	
	2. Achse	P20016	P20037	P20058	
	3. Achse	P20017	P20038	P20059	
G59	1. Achse	P20018	P20039	P20060	
	2. Achse	P20019	P20040	P20061	
	3. Achse	P20020	P20041	P20062	
Work area 2	G53	1. Achse	P20063	P20084	P20105
		2. Achse	P20064	P20085	P20106
		3. Achse	P20065	P20086	P20107
	G54	1. Achse	P20066	P20087	P20108
		2. Achse	P20067	P20088	P20109
		3. Achse	P20068	P20089	P20110
	G55	1. Achse	P20069	P20090	P20111
		2. Achse	P20070	P20091	P20112
		3. Achse	P20071	P20092	P20113
	G56	1. Achse	P20072	P20093	P20114
		2. Achse	P20073	P20094	P20115
		3. Achse	P20074	P20095	P20116
	G57	1. Achse	P20075	P20096	P20117
		2. Achse	P20076	P20097	P20118
3. Achse		P20077	P20098	P20119	
G58	1. Achse	P20078	P20099	P20120	
	2. Achse	P20079	P20100	P20121	
	3. Achse	P20080	P20101	P20122	
G59	1. Achse	P20081	P20102	P20123	
	2. Achse	P20082	P20103	P20124	
	3. Achse	P20083	P20104	P20125	



8.3 Channel - descriptor (continued)

Zero point records q170... q174

Example: Zero point box with extended zero points

q170	20000	at the beginning of the zero point record
q171	1	number of zero point blocks (work areas)
q172	3	number of additional groups per zero point block (shift)
q173	4	number of items (axes) per group
q174	1	number of usable, programmable zero points: G53 ... G59 and G154 ... G159 = 13

Work area 1			sum shift	shift 1	shift 2	shift 3
G53	1. Achse	P20000	P20052	P20104	P20156	
	2. Achse	P20001	P20053	P20105	P20157	
	3. Achse	P20002	P20054	P20106	P20158	
	4. Achse	P20003	P20055	P20107	P20159	
G54	1. Achse	P20004	P20056	P20108	P20160	
	2. Achse	P20005	P20057	P20109	P20161	
	3. Achse	P20006	P20058	P20110	P20162	
	4. Achse	P20007	P20059	P20111	P20163	
G55	1. Achse	P20008	P20060	P20112	P20164	
	2. Achse	P20009	P20061	P20113	P20165	
	3. Achse	P20010	P20062	P20114	P20166	
	4. Achse	P20011	P20063	P20115	P20167	
G56	1. Achse	P20012	P20064	P20116	P20168	
	2. Achse	P20013	P20065	P20117	P20169	
	3. Achse	P20014	P20066	P20118	P20170	
	4. Achse	P20015	P20067	P20119	P20171	
G57	1. Achse	P20016	P20068	P20120	P20172	
	2. Achse	P20017	P20069	P20121	P20173	
	3. Achse	P20018	P20070	P20122	P20174	
	4. Achse	P20019	P20071	P20123	P20175	
G58	1. Achse	P20020	P20072	P20124	P20176	
	2. Achse	P20021	P20073	P20125	P20177	
	3. Achse	P20022	P20074	P20126	P20178	
	4. Achse	P20023	P20075	P20127	P20179	
G59	1. Achse	P20024	P20076	P20128	P20180	
	2. Achse	P20025	P20077	P20129	P20181	
	3. Achse	P20026	P20078	P20130	P20182	
	4. Achse	P20027	P20079	P20131	P20183	
G154	1. Achse	P20028	P20080	P20132	P20184	
	2. Achse	P20029	P20081	P20133	P20185	
	3. Achse	P20030	P20082	P20134	P20186	
	4. Achse	P20031	P20083	P20135	P20187	
G155	1. Achse	P20032	P20084	P20136	P20188	
	2. Achse	P20033	P20085	P20137	P20189	
	3. Achse	P20034	P20086	P20138	P20190	
	4. Achse	P20035	P20087	P20139	P20191	
G156	1. Achse	P20036	P20088	P20140	P20192	
	2. Achse	P20037	P20089	P20141	P20193	
	3. Achse	P20038	P20090	P20142	P20194	
	4. Achse	P20039	P20091	P20143	P20195	
G157	1. Achse	P20040	P20092	P20144	P20196	
	2. Achse	P20041	P20093	P20145	P20197	
	3. Achse	P20042	P20094	P20146	P20198	
	4. Achse	P20043	P20095	P20147	P20199	
G158	1. Achse	P20044	P20096	P20148	P20200	
	2. Achse	P20045	P20097	P20149	P20201	
	3. Achse	P20046	P20098	P20150	P20202	
	4. Achse	P20047	P20099	P20151	P20203	
G159	1. Achse	P20048	P20100	P20152	P20204	
	2. Achse	P20049	P20101	P20153	P20205	
	3. Achse	P20050	P20102	P20154	P20206	
	4. Achse	P20051	P20103	P20155	P20207	

## 8.3 Channel - descriptor (continued)

### Parameters for channel - descriptor 1

- |      |  |
|------|--|
| q175 | Beginning of the tool data blocks 1. parameter<br>Defines, from which parameter on the tool data array starts. |
| q176 | Number of tool data blocks<br>Number of elements of the tool data arrays.                                      |
| q177 | Number of sub data blocks  |
| q178 | Number of parameters of a tool block<br>Total length of an element in the tool data array.                     |
| q179 | Number of tool places available in the tool magazine   |

### 8.3 Channel - descriptor (continued)

#### Configuration - Example

Example: Amount of channels : 1  
Amount of axes : 3

q2	1	channels	
q101	1	channel number	
q102	10000	parameter - relocator user block 1	(q number)
q103	5000	number of channel parameters in the 1st. block	
q104	18000	parameter - relocator user block 2	(q number)
q105	2000	number of channel parameters in the 2. block	
q110	\$010058	1st. logical axis = 1. physical axis, axis name 'X', key 1	
q111	\$020059	2nd. logical axis = 2. physical axis, axis name 'Y', key 18	
q112	\$03005A	3rd. logical axis = 3. physical axis, axis name 'Z', key 3	
q170	20000	beginning of the zero point data block	
q171	1	number of zero point blocks	
q172	0	number of groups per zero point block	
q173	32	number of elements per group	
q175	21000	beginning of the tool data block	
q176	50	number of tool data blocks	
q177	1	number of sub data blocks	
q178	20	number of elements per data block	

Parameters for this example are lying for this example as follows:

	q0 ... q99	general system configuration
	q100 ... q999	definition channel descriptors
P11000 ... P11999	q1000 ... q1999	system overlapping data
P12000 ... P13599	q2000 ... q3599	axis data
P0 ... P4999	q10000 ... q14999	customer parameter block 1
P7000 ... P9999	q15000 ... q17999	fix defined channel parameters
P20000 ... P21999	q18000 ... q19999	for zero pointes, tool data

## 8.4 Modes of operation - groups

### Operating mode network 1

The following parameters contain bit information for suitable channel selection.

q903 Operating mode switching in the network

Bit information: bit 0 channel 1

bit 1 channel 2

:

e.g.: \$00000003: Channel 1 & channel 2

(P8683 in the defined channels is simultaneous setting)

With the describing of q903 operating mode switching in the network becomes changes immediately.

q904 Stop in the network (see q903)

Stop in the network works only for STOP key

i.e. if a channel over STOP key is stopped, become the remaining channels in network also stopped.

Stop in the network does not work with stop by messages, measuring stops, Program end etc.

With the describing of q904 stop in the network is changed immediately.

q905 Abort in the network (see q903)

With the describing of q905 abort in the network is changed immediately.

q908 Message display in the network  
(messages of the CNC)

Byte 1 Messages system and channel-specific messages of the PLC

Byte 2 Messages High Prio.

Byte 3 Messages Low Prio.

Byte 4 Messages display and channel-specific messages of the PLC

All bytes contain the following

Bit information bit 0 channel 1

bit 1 channel 2

:

bit 7 channel 8

Example q908 \$00030303

i.e.. Messages that priority system / High Prio. / Low Prio.

in both channels (K1 + K2) are displayed.

The display messages are displayed only in the selected channel (byte 4 = 0).

## 8.4 Modes of operation - groups (continued)

Operating mode network 1

q909 PLC message display in the network  
(messages of the PLC)  
Byte 1 PLC Messages High Prio.  
Byte 2 PLC Messages Low Prio.

see further q908

q910 Operating mode network 2  
:  
q919

q920 Operating mode network 3  
:  
q929

q930 Operating mode network 4  
:  
q939

## 8.5 Standard channel parameters

### Milling cycles

(only if the milling cycles G71 / G72 / G73 / G74 / G75 are used, otherwise freely available)

P11	Pocket dimension in x-direction
P12	Pocket dimension in y-direction
P13	Pocket depth in z-direction
P14	Corner radius
P15	Allowance on outline in x and y-direction
P16	Setting measure in x or y-direction (sign + / -)
P17	Setting measure in z-direction
P18	Allowance on pocket depth in z-direction
P19	Safety margin in z-direction
P21	Feed in z-direction (when immersing into the material)

8.5 Standard channel parameters (continued)

**Drill cycles**

(only if the drill cycles G81 / G83 / G84 / G85 are used, otherwise freely available)

P30	Free cutting time		
P31	Balance fodder	G84	
		P31: 3	= thread cutting without balance fodder on the right
		P31: 4	= thread cutting without balance fodder links
		P31: 0 or --	= G84 standard cycle (with balance fodder)
P32	Drill feed		
P32	Thread pitch	G84	
P33	Drilling depth		
P33	Hread depth	G84	
P34	Anticipation plane		Safety margin of the processing upper edge
P35	Retreat plane		To running around obstacles in the setting axis
P36	Stroke rate		G83, constant setting depth = $(P33 - P34) / P36$
P36	Setting depth		G83, degressive setting depth
P37	1. Stroke		G83, degressive setting depth
P38	Safety margin		G83, default = 1mm
P39	Gradual decrease		G83, degressive setting depth
		P39: 1	= on
		P39: 0 or --	= off

**8.5 Standard channel parameters (continued)****Cycle patterns**

(only if the cycle patterns G86 / G87 / G88 / G89 are used, otherwise freely available)

**G86 vector type processing**

P100	Coordinate of the 1. Axis (x)
P101	Coordinate of the 2. Axis (y)
P103	Vector bracket related to the 1.Achse (x)
P104	Vector length
P105	Vector splitting
P106	Number of points of positioning

**G87 scope handling of a parallelogram**

Vector 1	Vector 2	
P100	P110	Coordinate of the 1. Axis (x)
P101	P111	Coordinate of the 2. Axis (y)
P103	P113	Vector bracket related to the 1.Achse (x)
P104	P114	Vector length
P105	P115	Vector splitting
P106	P116	Number of points of positioning

**G88 grid handling**

Vector 1	Vector 2	
P100	P110	Coordinate of the 1. Axis (x)
P101	P111	Coordinate of the 2. Axis (y)
P103	P113	Vector bracket related to the 1.Achse (x)
P104	P114	Vector length
P105	P115	Vector splitting
P106	P116	Number of points of positioning

**G89 circle handling**

P120	Coordinate of the 1. Axis (x) of the pitch diameter centre point
P121	Coordinate of the 2. Axis (y) of the pitch diameter centre point
P122	Circle diameter
P123	Start bracket
P124	Travel bracket
P125	Vector part
P126	Number of points of positioning

**8.5 Standard channel parameters (continued)**

**Measuring cycle**

(only if the measuring cycle G69 are used, otherwise freely available)

P140	Cycle selection	
P141	Safety margin	[ mm ]
P143	Measuring rate	[ mm/min ]
P144	Number of measurements at the same point (> 0)	[ n ]
P147 (P147)+4	Pointer on the measuring tolerance data Confidence interval	[ mm ]
P148	Measuring axis in plane system (1... 3)	
P149	Pointer on the data of point of trigger	
(P149)+0	XN, point of trigger in negative direction 1. Axis	[ mm ]
(P149)+1	XP, point of trigger in positive direction 1. Axis	[ mm ]
(P149)+2	YN, point of trigger in negative direction 2. Axis	[ mm ]
(P149)+3	YP, point of trigger in positive direction 2. Axis	[ mm ]
(P149)+4	ZN, point of trigger in negative direction 3. Axis	[ mm ]
(P149)+5	ZP, point of trigger in positive direction 3. Axis	[ mm ]
P150	Pointer on the calibrating drilling data	
(P150)+0	Position of the calibrating drilling centre point 1. Axis (i)	[ mm ]
(P150)+1	Position of the calibrating drilling centre point 2. Axis (j)	[ mm ]
(P150)+2	Position of the calibrating drilling centre point 3. Axis (k)	[ mm ]
(P150)+3	Calibrating drilling diameter	[ mm ]
P152	Expected drilling diameter	[ mm ]
P154	Pointer on the measuring data	
(P154)+0	Measuring position 1. Axis	[ mm ]
(P154)+1	Measuring position 2. Axis	[ mm ]
(P154)+2	Measuring position 3. Axis	[ mm ]

8.5 Standard channel parameters (continued)

Channel parameters

P70	Graphical programming environment with phase Input leg length	(G12)	[mm]
P71	Graphical programming environment with radius Input radius	(G12)	[mm]
P160	$U_0$ Origin axis 1 of the system UV (Rotating 45) Parameter is activated in the block with G45.		[mm]
P161	$V_0$ Origin axis 1 of the system UV (Rotating 45) Parameter is activated in the block with G45.		[mm]
P163	E Rotating angle Content is activated in the block with G45. Conversion of the coordinates of the UV-system into coordinates of the XY-system $X_b = (U \cdot \cos E - V \cdot \sin E) + U_0$ $Y_b = (U \cdot \sin E + V \cdot \cos E) + V_0$ see also G45/G56		[degree]
P165	U additive shift axis 1 (rotation G45 planned)		[mm]
P166	V additive shift axis 2 (rotation G45 planned)		[mm]
P168	E incrementing of the rotating angle (planned)		[degree]

**8.5 Standard channel parameters (continued)**

P7000 Parameter area is used by the system  
.  
.  
P7999

	Offset
- Measuring position	0 ... 31
- Display positions	32 ... 63
- Program positions	64 ... 95
- Delta positions	96 ... 127
- Display shifts	128 ... 159

**8.5 Standard channel parameters (continued)**

**ZSM control parameter**

P7950 ZSM command  
 0 in the case of current measurement, the measurement is aborted.  
 1 start ZSM measurement  
 - > P7960 to 1 is settinged  
 - > if P7960 = 10 measurement terminates error free.

Internal operational sequence with the measuring start:  
 With the ZSM command ' start ZSM measurement ' becomes with the suitable Measuring axis (P7951) the ZSM Messaufzeichnung activates.  
 In accordance with the defined measuring logic of this measuring axis (P12045, byte 4), becomes with the switch edge defined there the ZSM recording started. The first edge defines a gap/tooth change.

Example: P12045: \$0 xx xx xx switch edge positively effectively  
 i.e.. The measured value recording starts with a positive switch edge at the sensor input (0/24V-Sprung).  
 A positive edge is detected as gap/tooth change —> beginning of the tooth.  
 A negative edge is detected as tooth/gap change —> beginning of the gap.

P7951 Axis number  
 Contents log. Axis number (1... 32)

P7952 Number of teeth which can be measured (max. 250)

P7954 Correction window [ % ]  
 0... 100  
 Here the ZSM Korrekturalgorithmus can be influenced,  
 100 ZSM Korrekturalgorithmus ineffektiv.  
 0 ZSM Korrekturalgorithmus fully effectively  
 if 0 or -- 80

8.5 Standard channel parameters (continued)

ZSM Statusparameter

P7960	<p>ZSM status                  Parameter may not be described.</p> <ul style="list-style-type: none"> <li>1 measured value recording runs</li> <li>5 measuring analysis runs</li> <li>10 measurement terminates, measured value error free valid (P7950 reaches 0)</li>   <li>&gt; 10 measurement incorrectly or aborted</li>   <li>20 measurement aborted</li> <li>21 no edges were detected</li> <li>22 division ?? 0 determines</li>   <li>24 measuring recording not correctly, missing measured values in the data array</li> <li>25 measuring recording not correctly, measured values not continuously up/down-rising</li> <li>30 incorrect input, P7951 / P7952 check</li> </ul>	
P7961	<p>Measured value 1                  Tooth center                  Area 0... measured division</p>	[ ° ]
P7962	<p>Measured value 2                  Gap center                  Area: P7962 &gt; P7961</p>	[ ° ]


8.5 Standard channel parameters (continued)

ZSM Statusparameter

Example of a measuring flow in the NC program

```

N100 P7950:1           { start measurement }
N110 M1               { loop re-entry point }
N120 P7960<10.110     { control room, to measurement terminates or aborted }
N130 P7960=10.200     { branch, if measurement of OK ONE }
N140...              { error handling, measurement aborted or errors }
:
:
N200...:P7961         { measured value process }
:
    
```



8.5 Standard channel parameters (continued)

Channel parameters

P8000 Axis shifts  
:  
P8031

P8000 Shift axis 1  
P8001 Shift axis 2  
P8002 Shift axis 3  
P8003 Shift axis 4  
:  
P8031 Shift axis 32

**8.5 Standard channel parameters (continued)****Tool - Data - Interface**

P8040 T read in locking  
0 or -- T read in locking is open  
1 T read in locking is set  
When a locking is set, it is prevented that the realtime data block (P8200...) is written by the system.

If the read in locking is set and 'T' is programmed in the NC block, the NC program run is stopped as long as the T read in locking is set.

T read in locking is reset:  
- at a NC program start  
- when copying the real time data block into the spindle data block (P8046 : 2).

P8043 Tool exchange in the manual mode  
Loading the tool data block into the PLC tool data block (P8050 ... P8099) and into the real time data block (P8200...).  
Example: P8043:1  
The tool group number 1 is searched in the tool data array. If the search is successful, the corresponding data block is copied to P8050... and P8200.  
At P 8043=0 the tool data are set to zero.  
If the data block can not be found, a message appears.  
Subsequently, it is switched to AUTO and Z6 is called up.  
At the end of Z6, it is changed back to MANUAL.  
If Z6 does not exist, M6 is sent to the PLC.

At DLL active tool change command 1 is sent to the DLL before Z6 is called up.

8.5 Standard channel parameters (continued)

Tool - Data - Interface

P8045 Tool datas input

- Byte 1 CMD
- Byte 2 CMD Extention

CMD 1

Thus the PLC becomes tool record (P8050..) into the spindle tool record (P8100..) and the offsettings record (P8150..) copies.

CMD 2

Thus the real time record becomes (P8200...) into the spindle tool record (P8100...) copies. Additionally T read in barrier reset (P8040:0). In the operating mode HAND becomes additional the spindle tools record (P8100...) in the offsettings record (P8150...) copies.

With CMD Extention: Channel number real time of the record.

- 0 or -- copy over within the channel
- 1...8 copy over channel-spreading spindle tool record 1..8. channel becomes in the spindle tool record (P8100...) copies.

In the tool record array becomes with the suitable tools that Tool workstation zeroed.

P8046 Tool datas copy over

- 1 Thereby the spindle tools record (P8100..) becomes in offsetting record (P8150) copies.
- 2 Thereby the PLC becomes tool record (P8050...) into that offsetting record (P8150) copies.

8.5 Standard channel parameters (continued)

Tool - Data - Interface

- P8047 Tool datas placings  
1 Thereby the spindle tool data block (P8100..) becomes in the suitable tool data block array back-stored and afterwards the actual spindle tool data block reset.  
  
If P8100 = 0 or -- (no tools in the spindle) this procedure becomes leave immediately.  
With active tool change DLL only command 2 is transmitted to the DLL.
- P8048 Tool group number (t-paragraph from NC program)  
(parameter to the real time is described)  
The parameter is described only if ' T ' is programmed in the NC block
- P8049 Info NC block contains tool-controlling m-function  
0 no tool-controlling m-function  
6 M06 in the block  
16 M16 in the block  
P8049 is described in the advance, if T is programmed in the NC block  
P8049 is updated, before the parameter block P8050... is described.

## 8.5 Standard channel parameters (continued)

Tool - Data - Interface

Actual PLC tool data block

P8050 Actual PLC tool data (interface to the PLC).  
: Here are the tool data, which were transmitted to the PLC.  
P8099 Is loaded during block analysis with the tool data according to the T programmed in the NC - program (see also P8049).

Special case:

If the tool group number (T number) is the same like the tool group number of a spindle data block, the PLC tool data are not loaded from the tool data array, but the spindle data block is copied into the PLC tool data block.

P8050 Tool group number (T - number)  
P8051 Tool number (e.g. continuous numbering)  
P8052 Tool place in the magazine  
P8053 Tool sub data block (selected)

P8058 Tool life status  
0 or -- tool life o.k.  
1 tool life run down

P8060 Tool radius  
P8061 Tool length  
P8062 Radius correction offset  
P8063 Length correction offset  
P8064 Tool type (active quadrant 0...9)  
P8065 Customer data ← Here the customer specific area begins  
:  
P8099

**8.5 Standard channel parameters (continued)****Tool - Data - Interface****Actual spindle tool data block**

P8100 Actual spindle tool data block.  
: The data block refers to the actual tool in the spindle.  
P8149 This data block is loaded from the tool data array and when laying back the tool stored again into the array.

P8100	Tool group number	(T - number)
P8101	Tool number	(e.g. continuous numbering)
P8102	Tool place in the magazine	
P8103	Tool sub data block	(selected)

P8108	Tool life status	
	0 or --	tool life o.k.
	1	tool life run down

P8110	Tool radius	
P8111	Tool length	
P8112	Radius correction offset	
P8113	Length correction offset	
P8114	Tool type (active quadrant 0...9)	
P8115	Customer data	← Here the customer specific area begins
:		
P8149		

## 8.5 Standard channel parameters (continued)

### Tool - Data - Interface

#### Actual data block

P8150 Actual data block.  
: This is the data block, which is calculated into the NC program.  
P8199 From this data block, it can not be stored back to the data array.

P8150 Tool group number (T - number)  
P8151 Tool number (e.g. continuous numbering)  
P8152 Tool place in the magazine  
P8153 Tool sub data block (selected)

P8158 Tool life status  
0 or -- tool life o.k.  
1 tool life run down

P8160 Tool radius  
P8161 Tool length  
P8162 Radius correction offset  
P8163 Length correction offset  
P8164 Tool type (active quadrant 0...9)  
P8165 Customer data ← Here the customer specific area begins  
:  
P8199

## 8.5 Standard channel parameters (continued)

### Tool - Data - Interface

#### Real time data block

This is the data block that is loaded from the system to the real time:

- T programmed in the NC block
- T M6 programmed in the NC block (is not written at T M16)

Special case:

If the tool group number (T number) is the same like the tool group number of a spindle data block, the PLC tool data are not loaded from the tool data array, but the spindle data block is copied into the PLC tool data block.

See also T read in locking P8040

With external tool administration, the real time data block is loaded with calling up command 3.

P8200	Tool group number	(T number)
P8201	Tool number	(e.g. continuous numbering)
P8202	Tool place in the magazine	
P8203	Tool sub data block	(selected)
P8208	Tool life status	(-, 0 tool life o.k., 1 tool life over)
P8210	Tool radius	
P8211	Length of the tool	
P8212	Radius correction	
P8213	Length correction	
P8214	Tool type	(active quadrant 0..9)
P8215	Customer specific area	
.		
.		
P8249		


8.5 Standard channel parameters (continued)

Tool data blocks in the overview

**Tool data interface**  
specifies firmly

**Tool data array**  
freely definably


PLC interface



8.5 Standard channel parameters (continued)

Channel specific definition of the M functions

Information for a M - function



P8250 Channel-specific definition of the M functions  
 see table starting from P11050, see also q158  
 Here 1000 channel-specific M functions can be specified.  
 Note: A modification in P8250.. becomes with a operating modes changes  
 by HAND after AUTO effectively.



8.5 Standard channel parameters (continued)

Definition of the M functions

P8250 M	03	02	01	00	P8300 M	203	202	201	200
P8251 M	07	06	05	04	P8301 M	207	206	205	204
P8252 M	11	10	09	08	P8302 M	211	210	209	208
P8253 M	15	14	13	12	P8303 M	215	214	213	212
P8254 M	19	18	17	16	P8304 M	219	218	217	216
P8255 M	23	22	21	20	P8305 M	223	222	221	220
P8256 M	27	26	25	24	P8306 M	227	226	225	224
P8257 M	31	30	29	28	P8307 M	231	230	229	228
P8258 M	35	34	33	32	P8308 M	235	234	233	232
P8259 M	39	38	37	36	P8309 M	239	238	237	236
P8260 M	43	42	41	40	P8310 M	243	242	241	240
P8261 M	47	46	45	44	P8311 M	247	246	245	244
P8262 M	51	50	49	48	P8312 M	251	250	249	248
P8263 M	55	54	53	52	P8313 M	255	254	253	252
P8264 M	59	58	57	56	P8314 M	259	258	257	256
P8265 M	63	62	61	60	P8315 M	263	262	261	260
P8266 M	67	66	65	64	P8316 M	267	266	265	264
P8267 M	71	70	69	68	P8317 M	271	270	269	268
P8268 M	75	74	73	72	P8318 M	275	274	273	272
P8269 M	79	78	77	76	P8319 M	279	278	277	276
P8270 M	83	82	81	80	P8320 M	283	282	281	280
P8271 M	87	86	85	84	P8321 M	287	286	285	284
P8272 M	91	90	89	88	P8322 M	291	290	289	288
P8273 M	95	94	93	92	P8323 M	295	294	293	292
P8274 M	99	98	97	96	P8324 M	299	298	297	296
P8275 M	103	102	101	100	P8325 M	303	302	301	300
P8276 M	107	106	105	104	P8326 M	307	306	305	304
P8277 M	111	110	109	108	P8327 M	311	310	309	308
P8278 M	115	114	113	112	P8328 M	315	314	313	312
P8279 M	119	118	117	116	P8329 M	319	318	317	316
P8280 M	123	122	121	120	P8330 M	323	322	321	320
P8281 M	127	126	125	124	P8331 M	327	326	325	324
P8282 M	131	130	129	128	P8332 M	331	330	329	328
P8283 M	135	134	133	132	P8333 M	335	334	333	332
P8284 M	139	138	137	136	P8334 M	339	338	337	336
P8285 M	143	142	141	140	P8335 M	343	342	341	340
P8286 M	147	146	145	144	P8336 M	347	346	345	344
P8287 M	151	150	149	148	P8337 M	351	350	349	348
P8288 M	155	154	153	152	P8338 M	355	354	353	352
P8289 M	159	158	157	156	P8339 M	359	358	357	356
P8290 M	163	162	161	160	P8340 M	363	362	361	360
P8291 M	167	166	165	164	P8341 M	367	366	365	364
P8292 M	171	170	169	168	P8342 M	371	370	369	368
P8293 M	175	174	173	172	P8343 M	375	374	373	372
P8294 M	179	178	177	176	P8344 M	379	378	377	376
P8295 M	183	182	181	180	P8345 M	383	382	381	380
P8296 M	187	186	185	184	P8346 M	387	386	385	384
P8297 M	191	190	189	188	P8347 M	391	390	389	388
P8298 M	195	194	193	192	P8348 M	395	394	393	392
P8299 M	199	198	197	196	P8349 M	399	398	397	396

8.5 Standard channel parameters (continued)

Definition of the M functions

P8350 M	403	402	401	400	P8400 M	603	602	601	600
P8351 M	407	406	405	404	P8401 M	607	606	605	604
P8352 M	411	410	409	408	P8402 M	611	610	609	608
P8353 M	415	414	413	412	P8403 M	615	614	613	612
P8354 M	419	418	417	416	P8404 M	619	618	617	616
P8355 M	423	422	421	420	P8405 M	623	622	621	620
P8356 M	427	426	425	424	P8406 M	627	626	625	624
P8357 M	431	430	429	428	P8407 M	631	630	629	628
P8358 M	435	434	433	432	P8408 M	635	634	633	632
P8359 M	439	438	437	436	P8409 M	639	638	637	636
P8360 M	443	442	441	440	P8410 M	643	642	641	640
P8361 M	447	446	445	444	P8411 M	647	646	645	644
P8362 M	451	450	449	448	P8412 M	651	650	649	648
P8363 M	455	454	453	452	P8413 M	655	654	653	652
P8364 M	459	458	457	456	P8414 M	659	658	657	656
P8365 M	463	462	461	460	P8415 M	663	662	661	660
P8366 M	467	466	465	464	P8416 M	667	666	665	664
P8367 M	471	470	469	468	P8417 M	671	670	669	668
P8368 M	475	474	473	472	P8418 M	675	674	673	672
P8369 M	479	478	477	476	P8419 M	679	678	677	676
P8370 M	483	482	481	480	P8420 M	683	682	681	680
P8371 M	487	486	485	484	P8421 M	687	686	685	684
P8372 M	491	490	489	488	P8422 M	691	690	689	688
P8373 M	495	494	493	492	P8423 M	695	694	693	692
P8374 M	499	498	497	496	P8424 M	699	698	697	696
P8375 M	503	502	501	500	P8425 M	703	702	701	700
P8376 M	507	506	505	504	P8426 M	707	706	705	704
P8377 M	511	510	509	508	P8427 M	711	710	709	708
P8378 M	515	514	513	512	P8428 M	715	714	713	712
P8379 M	519	518	517	516	P8429 M	719	718	717	716
P8380 M	523	522	521	520	P8430 M	723	722	721	720
P8381 M	527	526	525	524	P8431 M	727	726	725	724
P8382 M	531	530	529	528	P8432 M	731	730	729	728
P8383 M	535	534	533	532	P8433 M	735	734	733	732
P8384 M	539	538	537	536	P8434 M	739	738	737	736
P8385 M	543	542	541	540	P8435 M	743	742	741	740
P8386 M	547	546	545	544	P8436 M	747	746	745	744
P8387 M	551	550	549	548	P8437 M	751	750	749	748
P8388 M	555	554	553	552	P8438 M	755	754	753	752
P8389 M	559	558	557	556	P8439 M	759	758	757	756
P8390 M	563	562	561	560	P8440 M	763	762	761	760
P8391 M	567	566	565	564	P8441 M	767	766	765	764
P8392 M	571	570	569	568	P8442 M	771	770	769	768
P8393 M	575	574	573	572	P8443 M	775	774	773	772
P8394 M	579	578	577	576	P8444 M	779	778	777	776
P8395 M	583	582	581	580	P8445 M	783	782	781	780
P8396 M	587	586	585	584	P8446 M	787	786	785	784
P8397 M	591	590	589	588	P8447 M	791	790	789	788
P8398 M	595	594	593	592	P8448 M	795	794	793	792
P8399 M	599	598	597	596	P8449 M	799	798	797	796

8.5 Standard channel parameters (continued)

Definition of the M functions

P8450 M	803	802	801	800
P8451 M	807	806	805	804
P8452 M	811	810	809	808
P8453 M	815	814	813	812
P8454 M	819	818	817	816
P8455 M	823	822	821	820
P8456 M	827	826	825	824
P8457 M	831	830	829	828
P8458 M	835	834	833	832
P8459 M	839	838	837	836
P8460 M	843	842	841	840
P8461 M	847	846	845	844
P8462 M	851	850	849	848
P8463 M	855	854	853	852
P8464 M	859	858	857	856
P8465 M	863	862	861	860
P8466 M	867	866	865	864
P8467 M	871	870	869	868
P8468 M	875	874	873	872
P8469 M	879	878	877	876
P8470 M	883	882	881	880
P8471 M	887	886	885	884
P8472 M	891	890	889	888
P8473 M	895	894	893	892
P8474 M	899	898	897	896
P8475 M	903	902	901	900
P8476 M	907	906	905	904
P8477 M	911	910	909	908
P8478 M	915	914	913	912
P8479 M	919	918	917	916
P8480 M	923	922	921	920
P8481 M	927	926	925	924
P8482 M	931	930	929	928
P8483 M	935	934	933	932
P8484 M	939	938	937	936
P8485 M	943	942	941	940
P8486 M	947	946	945	944
P8487 M	951	950	949	948
P8488 M	955	954	953	952
P8489 M	959	958	957	956
P8490 M	963	962	961	960
P8491 M	967	966	965	964
P8492 M	971	970	969	968
P8493 M	975	974	973	972
P8494 M	979	978	977	976
P8495 M	983	982	981	980
P8496 M	987	986	985	984
P8497 M	991	990	989	988
P8498 M	995	994	993	992
P8499 M	999	998	997	996



8.5 Standard channel parameters (continued)

Messages

P8500	Message	system	causes	abort of all channels
P8501	Message	high - priority	causes	abort of the channel
P8502	Message	low - priority	causes	stop of the channel
P8503	Message	only display		
P8504	Additional information	of axis		
P8505	Additional information 1	for message	Info1	in the picture with key '?'
P8506	Additional information 2	for message	Info2	in the picture with key '?'
P8507	Additional information 3		Info3	in the picture with key '?'
P8508	Acknowledgement of pending CNC messages (see also q157)			
P8509	Actually displayed message (parameter of the PLC one describes)			
	Byte 1	Message paragraph		
	Byte 2	Message paragraph		
	Byte 3	Channel number (1... 8)		
	Byte 4	Axis paragraph (1... 32)		

(see also parameter status byte 3)

## Channel locking

P8510 Automatic transmission locking

The lockings that are defined here are activated in the AUTOMATIC mode.

Activating can be done with the mode of operation changeover (see also P11010 . . .)

Byte 0

Bit 0 Parameter locking 1 (see also parameter status byte 3)

Bit 1 Parameter locking 2 (see also parameter status byte 3)

Bit 2 Parameter locking 3 (see also parameter status byte 3)

Bit 3 Parameter locking 4 (see also parameter status byte 3)

Byte 2

Bit 0 NC-memory locking

Bit 1 Cycle-memory locking

**8.5 Standard channel parameters (continued)****Channel informations**

- P8540 M function - interface diagnosis  
Diagnostic parameter only described with active PLC< >CNC
- P8549 interface diagnosis. (P11280 = 1)  
Byte 1 M function paragraph  
Byte 2 M function paragraph  
Byte 3 M function definition
- P8550 Channel number, is pre-allocated.
- P8551 Number of axes of this channel, is obtained when the switching on routine.
- P8552 Final axis in the channel (logical axis paragraph)  
After the switching on routine one obtains.
- P8553 Mapping test parameter  
Mode of operation: P8553 is described with a p-paragraph, sees P8554.
- P8554 Those obtains the Procedure called when describing the parameter P8553  
q paragraph this parameter and this writes after P8554.
- P8555 Actual work area, switches zero point blocks over  
0 or -- Invalid work area  
1 1. Record of the zero points actively  
2 2. Record of the zero points actively  
:  
:
- P8559 Control rooms on end of block acknowledgement with M function with stop  
0 or -- ok  
1 Wait for acknowledgement (block release)  
(CNC waits for the PLC Acknowledgement of a m-function with stop)

**8.5 Standard channel parameters (continued)****Channel informations**

P8570 ... Actual reference point display

P8570	1st display field	Content:	1..32 logical axis number
:			0 no display

P8577 8th display field

P8578 Number of max. reference point displays in the status line, if P8578 < axis number of the last channel axis, the reference point displays are showing the subsequent reference points.

P8679	All reference points taken	
0 or --	Not all reference points taken	
1	All reference points in the channel taken	

**8.5 Standard channel parameters (continued)****Channel informations**

P8580 Actual organization of the actual position display  
:  
P8587 This parameter area is set by the operating system.  
(may not be written).

P8580 Number of the display field  
Content: 1..32 logical axis number  
0 no axis display  
Byte 1 display field 1  
Byte 2 display field 2  
Byte 3 display field 3  
Byte 4 display field 4

P8581 Number of the display field  
Byte 1 display field 5  
Byte 2 display field 6  
Byte 3 display field 7  
Byte 4 display field 8

:  
P8587 Number of the display field 29..32

P8588 Maximum number of actual display fields

**8.5 Standard channel parameters (continued)****Channel informations**

P8590 Standard (customer specific) organization of the actual position display  
: At each operating mode change, the here defined actual position display is activated.  
P8597

P8590 Number of the display field  
Content: 1..32 logical axis number  
0 no axis display  
Byte 1 display field 1  
Byte 2 display field 2  
Byte 3 display field 3  
Byte 4 display field 4

**Comment:**

With the describing of P8590 the Istpositionsanzeige is again structured.  
(trigger parameters)

P8591 Paragraph of the indication area  
Byte 1 display field 5  
Byte 2 display field 6  
Byte 3 display field 7  
Byte 4 display field 8

P8597 Paragraph of the indication area 29.. 32  
Parameter with trigger function.  
With each describing P8597 becomes into that  
parameters P8590... activates p8597 specified Istpos display.

P8598 Display mode of the actual position display  
0 or -- If the actual position display knows not all available axes at the same time  
to raise, if this becomes on the final indication area with the axis selection  
of an axis, which not at the moment to display comes, another axis  
to displace.  
1 Actual position display does not change.

8.5 Standard channel parameters (continued)

Channel informations

Example actual position display

X	13.000	Y	0.000	Z	1.000	A	1.000
B	2.000	C	2.000	U	3.000	V	3.000
Kanal							

Display field 1

Display field 2

Display field 3

Display field 4

Display field 5

Display field 6

Display field 7

Display field 8

---

**8.5 Standard channel parameters (continued)**

**Presettings MANUAL** (planned)

P8600 Presetting axis position display

:

P8639

## 8.5 Standard channel parameters (continued)

### Presetting **AUTO** (planned)

P8640 Presetting axis position display

:

P8679

**8.5 Standard channel parameters (continued)****Channel - Commands to PLC**

P8681	Key Manual 0 Key released 1 Key pressed P8681 is written by the operating panel.	(to PLC)	is written by the operating panel  (PLC:THANDK1)
P8682	Key Start / Stop 0 Keys released 1 Key Stop pressed 2 Key start pressed When writing P8682, P8684 is written with AUTO Start /-Stop and answered to the PLC.	(to PLC)	is written by the operating panel  (PLC:TSTOPK1) (PLC:TSTARK1)
P8683	Mode of operation change 1 Manual Pending CNC messages become with mode change after hand reset. 2 Automatic sequential block 3 Automatic single block 8 Automatic positioning block	(to PLC)	  (PLC:BAWHAK1)  (PLC:BAWAUK1) (PLC:BAWAUK1) (PLC:BAWAUK1)

8.5 Standard channel parameters (continued)


Channel - Commands to PLC

P8684 Automatic transmission Start/Stop (to PLC)  
 0 Stop (PLC:TASTOK1)  
 1 Start (PLC:TASTAK1)

Example: NC Program start

When writing P8682, P8684 is written with AUTO- Start/Stop and answered to the PLC. If there are no start interlocking in the PLC, the Start/Stop command is answered to P8704. With P8704 the NC program (P8800) is started.

Example: Flow of a NC program start



P8685 Automatic program active (to PLC)  
 The CNC indicates here the actual condition.  
 The parameters may not be written.

0 Program not yet active or finished. (PLC:ANAK\_K1)  
 1 Program active Stop (PLC:AASP\_K1)  
 2 Program active Start (PLC:AAST\_K1)

**8.5 Standard channel parameters (continued)****Channel - Commands to PLC**

- P8686 Restarting info. at PLC  
0 No restarting, normal railway company.  
1 Restarting without axis movement, NC program is in the browsing.  
2 Restarting at outline (axis movement), starting block was found.  
Outline on direct path started with rapid traverse feed (P8816).  
With achieving the outline P8686:0
- P8689 Actual type of coordinate (see also P8759)  
0 or -- Transformation out  
15, 16 Polar transformation  
47, 48, 49 Robot transformation
- P8690 M function code at PLC  
Transmit a m-code at PLC in the manual operation.
- P8695 Acknowledgement for remainder path resetting  
0 or -- With NC block with M26 a NC nC-Verfahrweg becomes over  
- hardware sensor input  
- P8715  
aborted,  
P8695 with the actual NC record number is described.
- P8696 Acknowledgement for measuring position accommodation  
0 or -- With start of a measuring travel P8717 measuring position raised over  
- hardware sensor input  
- P8716  
aborted,  
P8696 with the actual NC record number is described.

**8.5 Standard channel parameters (continued)**

**Channel commands of the PLC**

P8700	Enable regulator for channel 0 no regulator enabling, i.e. command = actual of the axis 1 enable regulator	(PLC:REOK_K1)
P8701	Enable move of all axes in the channel 0 no channel enabling, i.e. stopping the axes without dynamics 1 channel enabling	(PLC:KAFR_K1)
P8702	Security stop of all axes in the channel 1 Stop, i.e. stopping the axes with dynamics	(PLC:SICHAK1)
P8703	Mode of operation 1 MANUAL 2 AUTO sequential block 4 AUTO single block 8 AUTOpositioning block	(PLC:BA_K1) (PLC:HAND_K1) (PLC:AUTF_K1) (PLC:AUTE_K1) (PLC:AUTP_K1)
P8704	AUTO Start / Stop Herewith a NC program is started (number is in P8800). 0 Stop 1 Start	(PLC:STARTK1)
P8705	NC program abort 1 Abort	(PLC:ABBRUK1)
P8706	Enable block Sentence by sentence control of a NC program 0 No block change 1 Block change	(PLC:SAFREK1)
P8709	Reference points taken 0 Reference points not yet taken 1 All reference points taken	(PLC:REFALK1)


**8.5 Standard channel parameters (continued)**

**Channel command of PLC**

- P8710 Emergency programm call 1 (PLC:NPA1K1)  
 0 No call  
 1 Program call  
 Program - and block number according to P8820, P8821  
 Function:  
 When calling up an emergency program a running NC program is interrupted.  
 When activating a emergency program in manual mode, the operating mode AUTO sequential block is changed.  
 If operating mode change is locked, the message 1320 appears.  
 At the end of the emergency program the mode of operation AUTO sequential block remains. When starting the emergency program P8710 is loaded with 0.
- P8711 Emergency program call 2 (PLC:NPA2K1)  
 0 No call  
 1 Program call  
 Program- and block number according to P8822, P8823  
 Function see P8710
- P8714 Conditional block skip (M22) (PLC:BSP22K1)  
 0 no skip  
 1 skip after block number
- P8715 Trigger for clearing movement in progress (M26) (PLC:TRWLOK1)  
 1 trigger
- P8716 Trigger for software-measuring key (PLC:TSWMTK1)  
 1 trigger
- P8717 Measuring position release  
 1 Measuring position release over sensor input  
 unique release for measuring position accommodation  
 2 Measuring position release over sensor input  
 constant release for measuring position accommodation  
 (see P8696)

8.5 Standard channel parameters (continued)

Clearing residual traverse (movement in progress) Measuring position logics



note:

\* see also P12045 measuring logic

\*\* see also P12153 measuring position  
 P12181 measuring position achieves  
 P8855 measuring position type of display  
 P8655 acknowledgement measuring position accommodation

## 8.5 Standard channel parameter (continued)

### Teach-in

- P8747 Axis selection at Teach-In  
0 or -- All existing axis positions are overtaken in the NC block at key target=actual  
<>0 Only axis positions according to selection are overtaken in the NC block  
Example:  
P8747: 0FH At axis 1 to 4, the position is overtaken in the NC block.
- P8748 Radius of the tool used in Teach-In.
- P8749 Mode of coordinate for Teach - In  
Input 0 off  
48 tool coordinate mode  
49 work piece coordinate mode

**8.5 Standard channel parameters (continued)**

**Manual operation**

P8750	Traverse mode selection	
	1 Continuously (relative)	(PLC:KONT_K1)
	2 Step (relative)	(PLC:STEP_K1)
	3 Hand-wheel	(PLC:HARA_K1)
	4 Divide (absolute/relative)	(PLC:TEIL_K1)
	5 Home (absolute/relative)	(PLC:HOME_K1)

P8751	Axis selection Logical axis number 1...32	(PLC:RAGAWK1)
-------	--	---------------

P8752	Manual move + / -	
	0 stop	
	1 +	(PLC:HAND+K1)
	2 -	(PLC:HAND-K1)

With the describing of this parameter the technique becomes the axis (P8751) started in the suitable procedure mode (P8750). Parameter becomes of the system with depressing the key hand + / - described.

P8753	Relative-travel in manual mode (internally used parameter)	
-------	---	--

P8754	max. programmable manual feed	[mm/min, degree/min]
-------	-------------------------------	----------------------

P8755	Programmed manual feed rate	[mm/min, degree/min]
-------	-----------------------------	----------------------

P8756	Actual manual feed rate	[mm/min, degree/min]
-------	-------------------------	----------------------

**8.5 Standard channel parameters (continued)****Manual operation**

- P8757 Coordinate system in HAND  
Input -- , 0 , 17 G17  
18, 19, 117, 118, 119 Gxxx  
The tool length always affects the vertically axis of the interpolation plane.  
Parameter wid after each passing through of the switching on routine reset.
- P8758 Zero pointes in Manual  
- display of the actual zero point in manual operation.  
- When writing the corresponding zero point is activated.  
Input 53 . . . 59  
Parameter wid after each passing through of the switching on routine reset.
- P8759 Coordinate mode in Manual  
0 transformation off  
Polar transformation  
Input 15 off  
16 on  
Robot transformation  
Input 47 off  
48 Tool - coordinates  
49 Workpiece - coordinates  
4849 Automatic switch between 48 and 49  
Parameter wid after each passing through of the switching on routine reset.

8.5 Standard channel parameters (continued)

Step operation

P8760	Actual step width		[mm]
P8761	step width 1 h on step width		
P8762	Pointer on selected step		
P8763	Step width table		
:			
P8769			
P8763	Step width 1 default	10	
P8764	Step width 2 default	1	
P8765	Step width 3 default	0,1	
P8766	Step width 4 default	0,01	
P8767	Step width 5 default	0,001	
P8768	Step width 6 default	0	
P8769	Step width 7 default	0	

8.5 Standard channel parameters (continued)

Hand-wheel

- P8770 Active hand-wheel  
0 No hand-wheel switched on  
1..8 Number of hand-wheel switched on
- P8771 Hand-wheel 1  
Bitinfo for axes, which may proceed with hand-wheel.  
Example: 8771: 03  
The 1st and 2nd axis can only be selected with the hand-wheel.
- :
- :
- P8778 Hand-wheel 8
- P8779 Hand-wheel definition  
Byte 1 0 Hand-wheels are activated individually with the hand-wheel key.  
Hand-wheel multiplier is modified individually.  
During hand-wheel for one circuit axis selection is not changed.
- \$10 All hand-wheels are always simultaneous activated.  
Hand-wheel multiplier is modified individually.  
During the hand-wheel for circuit the former axis selection becomes this hand-wheel again activates.

---

**8.5 Standard channel parameters (continued)**

**Indexing** (planned)

P8780

:

P8789

---

**8.5 Standard channel parameters (continued)**

**Home** (planned)

P8790

:

P8799

**8.5 Standard channel parameters (continued)****Start data**

P8800	Program number of the program to be started (see P8704)
P8801	Block number Start from this block.
P8802	Program number in the case of the NC program abort Parameter is described by the system see function: Restart at outline
P8803	Record number in the case of the NC program abort Parameter is described by the system see function: Restart at outline
P8804	Restarting at outline 0 or -- Restarting function not actively 1 Restarting function actively

Mode of operation restarting at outline:

In the case of the abort of a current NC program (HAND abort, message) becomes of system the actual NC program position in the parameters P8802, P8803 and P8807 stored. A properly terminated NC program resets these information.

After an NC abort if the restarting mode is switched on and the NC program started, then if the NC program up to the restarting point is simulated, i.e.. no axis movements egeben themselves.

In the restarting block the simulation is switched off. The restarting position on direct path one starts. With achieving the restarting position becomes P8804=0 settinged.

One restarts on the initial position of the aborted block.

If the NC program in a process cycle is aborted, then becomes to cycle start started.

When restarting become accordingly m-functions, M6 and m-cycles  
M function definition (P11050..., P8250...) treats.

During the restarting simulation P8050 (advance t NR.) becomes to the PLC do not transfer.


see also P8686

8.5 Standard channel parameters (continued)

Start data

P8805 Restarting adjustments

Example:



**8.5 Standard channel parameters (continued)**

**Start data**

P8806	Start data flag		
	Byte 1 bit 0	0	No block display during cycle handling
		1	Block display runs during cycle handling
	Byte 2 bits 0	0	Increasing automatic file barrier actively, i.e. of the NC interpreter processed NC programs and cycles remain up to the program end (abort or M30) with the editing barrier provide (max. 250 entries).
		1	Increasing automatic file barrier not actively, now the editing barrier is only so long active, as the NC interpreter the NC program opened (interpreter operates in the advance).
	Byte 3 bit 0	0	Drill cycles do not pend to modal, G80 does not have effect.
		1	Drill cycle modality switched on, i.e. with the unique programming of a Bohrzyklus (G81, G83, G84, G85) becomes in the following NC blocks 'also path' implicitly the drill cycle programmed first called. This Modalitaet is switched off with G80.
P8807	Internal restarting information		
P8809	Graphics on/off		
	0	Graphics off	
	1	Graphics on	
P8810	Block skip		
	0	Block skip not switched on	
	1	Block skip switched on	
P8811	Dripfeed operation		
	0	No Dripfeed operation	
	1	With Dripfeed operation	
P8812	Without axis movement		
	1	NC program sequence without axis movement	

## 8.5 Standard channel parameters (continued)

### Start data

P8813	Without M - function 1 NC program sequence without M-function - M-functions at PLC are not transmitted - program-controlling M-functions work unchanged - branch M-functions do not branch	
P8814	Single block mode with / without stop in intermediate blocks 0 or -- each main block is stopped in the single block mode 1 after each block end is stopped in the single block mode (at cycle blocks, insert block etc.)	
P8815	Test feed rate 0 or -- switched off <>0 at G01, G02 and G03 this programmed feed is used.	[mm/min]
P8816	Rapid traverse G00 0 or -- Manual feed rate active max. Axis speed (P12004) the axes available in the channel positions. < > 0 with prog. Rapid traverse is positioned with this speed.	[mm/min]
P8817	Asynchronous feed rate The programmed feed rate of the active NC block is replaced until the block end by the feed rate of P8817	[mm/min]
P8818	Percentage feed rate change The programmed feed rates in the NC program are changed with this percentage value.	[%]

**8.5 Standard channel parameters (continued)****Start data**

P8820	Program number	Emergency program 1
P8821	Block number	Emergency program call up see P8710
P8822	Program number	Emergency program 2
P8823	Block number	Emergency program call up see P8711
P8824	Program number	
P8825	Block number	Emergency program call up see P8712
P8826	Program number	
P8827	Block number	Emergency program call up see P8713
P8830	Zero point in AUTO	
	0 or --	NC program starts with G53
	53..59,153..	NC program starts with the programmed zero point

8.5 Standard channel parameters (continued)

Program controlling parameters

P8840 Definition of the coordinate system for G117  
(see also q152...)

- Byte 1 1. logical axis paragraph  
abscissa (horizontal axis)  
centre point identifier I
- Byte 2 2. logical axis paragraph  
ordinate (vertically axis)  
abscissa and ordinate specify the level, in which the circular interpolation  
takes place.  
centre point identifier J
- Byte 3 3. logical axis paragraph  
definition of the vertically axis on the interpolation level

The definition of the sense of circle turning a right-angled coordinate system always becomes assumed.

The direction of rotation in the various levels is as follows determined:

One looks against the direction of the axis, which is vertically on the level.  
(axis No. in byte 3).

With G02 now in the clockwise direction one interpolates.

With G03 against the clockwise direction one interpolates.

Programming example:

```
N100 G117 P8840:$00010302
      byte:  4 3 2 1
```

P8841 Definition of the coordinate system for G118 (see also q153..)

Default, if

0 or -- \$020103

Byte 1 03 (centre point identifier K)

Byte 2 01 (centre point identifier I)

Byte 3 02

P8842 Definition of the coordinate system for G119 (see also q154..)

Default, if

0 or -- \$010302

Byte 1 02 (centre point identifier J)

Byte 2 03 (centre point identifier K)

Byte 3 01


8.5 Standard channel parameters (continued)

Program controlling parameters

P8843 Max. one permitted radius error during centre point programming [ mm ]  
 0 or -- Default radius error 0.003mm  
 otherwise error message M1238  
 < > 0 Permitted error of the radius during centre point programming, starting from that the error message M1238 is output.

P8844 Radius correction messages suppress  
 Byte 1  
 bit 0 0 M1154 release  
 1 M1154 is suppresses  
 bit 1 0 M1155 release  
 1 M1155 is suppresses

P8845 Inserting sets / intersections with werkzeugradius-Korrektur.  
 -- at outside edges sets are always inserted.  
 0 in the case of direction deviation over 120 degrees sets are inserted under 120 degrees intersections are calculated.  
 0... 180 [ degrees ] in the case of direction deviations, which are larger than the input degree number, sets are inserted and in the case of direction deviations, which are smaller than the input degree number, intersections are calculated.  
 Example:  
 Direction deviation 120° and degree number of 110: Circle is inserted.  
 Direction deviation 120° and degree number of 130: Intersection is calculated.



**8.5 Standard channel parameters (continued)****Program controlling parameters**

P8846 Spline modification  
0 or -- 3D-spline (standard)  
< > 0 5D-spline switched on  
byte 1 logical axis paragraph of the 4. spline axis  
byte 2 logical axis paragraph of the 5. spline axis

1., 2., 3. Spline axis are specified over G17, G18, G19.

Example: P8846:\$0604 means

4. Spline axis is 4th logical axis

5. Spline axis is 6th logical axis

P8847 Spline modification  
0, -- or 0,5 Standard spline  
0,5... 2 Spline modifies  
i.e. decaying the Splines is influenced.  
0,5 Flat spline  
0,85 Spline decays more

Effectiveness becomes clear with large bracket steps.

8.5 Standards channel parameters (continued)

**Program controlling parameters**

Feed increase or feed degradation with convex or concave sections

P8848 Feed dynamics convex Input: [ 0-100% positively or negatively ]  
 Feed is proportionally increased or lowered.

P8849 Feed dynamics concave Input: [ 0-100% positively or negatively ]  
 Feed is proportionally increased or lowered.

When inserting values in P8848 and P8849 the following formula applies:

- F calculated feed
- F\_p programmed feed in the NUMERICAL CONTROL program
- R outline radius
- WR radius of the tool

$$F = F\_p * (1 + (P8848 \text{ or } P8849)/100 * (P8850 - R)/(P8850 - WR))$$

with  $R > P8850$  is  $F = F\_p$

P8850 Feed dynamics

- 0 or -- Feed dynamics switched off
- 1 With switched on werkzeugradiuskorrektur the feed becomes the actual path adapted, i.e. the programmed path feed applies to the edge contact tool.
- > 1 Petition of the outline Referenzradiuses, starting from which no feed modification one executes. P8848 and P8849 actively.

8.5 Standards channel parameters (continued)


Program controlling parameters

P8851 Corner dynamics [ Input: 0... 10 ]  
 0 or -- Standard corner dynamics actively  
 < > 0 Corner dynamics  
 -1 Switch off

Function of the standard corner dynamics

When approaching a corner, the contour feedrate is reduced in dependency of the corner angle, that means slow down before corners. Because of the corner angle, a reducing factor is effective (cos), which results in the contour feedrate before the corner when multiplying with the programmed feed rate.

Example: Corner angle	Corner feed reduction	
	at P8851:1	at P8851:3
≤90 degree	0	0
120 degree	0,5	0,125
135 degree	0,707	0,353
150 degree	0,866	0,649
180 degree	1	1



Function corner dynamics

At P8851>0, the standard reducing factor is raised to a power with the content of P8851. The larger P8851 is, the more it is slowed down before corners.

8.5 Standards channel parameters (continued)

Program controlling parameters

P8852	Circle dynamics	[mm]
0 or --	Circle dynamics switched off	
<>0	Circle dynamics active	
	input value permissible path deviation	[mm]
	function reduction of the feedrate at circular interpolation	

At circular interpolations (G02/G03), an internal circle feed rate is calculated with the help of the permissible path deviation which is limiting the feed rate that is programmed in the NC program.


Internal circle feed rate is dependant of

- programmed radius
- KV factor
- P8852

Remark:

P8852 always has to be smaller than the programmed radius, if not error message M1237 appears

Example



8.5 Standards channel parameters (continued)

Program controlling parameters

- P8853 Preset coordinate mode at NC program start  
 0 or -- No coordinate mode selected  
 49 NC program is starting with the indicated coordinate mode 49
- P8854 Radius correction at G49  
 0 or -- Radius correction in space, spline-contour G50  
 1 Radius correction in plane
- P8855 Measuring position modification (P12153)  
 0 or -- Store measuring position ref. display position  
 1 Store measuring position ref. machine position
- P8856 Internal parameter  
 (zero point setting CNC < —> Bediendeld)
- P8857 Outline dynamics with path interpolation  
 0 or -- Outline dynamics switched off  
 < > 0 Outline dynamics actively
- Input value certified path deviation [ mm ]  
 Function reduction of the feed  
 drive path (G1, G2, G3, G50)  
 The programmed points of path are connected with sets.  
 Thus the calculated circle radii form the basis for one  
 possible path feed reduction. To calculation see P8852.
- P8858 Definition of rapid traverse (G00)  
 Rapid traverse rate (see P8816)  
 0 or -- Rapid traverse always with exact stop,  
 i.e.. at the end of record feed = 0,  
 lag distance < exact stop  
 1 Rapid traverse always with feed stop  
 i.e.. at the end of record feed = 0,  
 for lag distance < exact stop is not waited  
 2 Rapid traverse no stop  
 end of record handling as with (G1, G2, G3, G50)

8.5 Standards channel parameters (continued)

Program controlling parameters

- P8859 G92-Modifikation  
 Parameter must be settinged before the NC program start!  
 Byte 1  
     bit 0 0 G92-Verschiebung rotates with 1. Rotation axis  
           1 G92-Verschiebung no rotating with 1. Rotation axis  
     bit 1 0 G92-Verschiebung is turned by G45 (starting from version 090)  
           1 G92-Verschiebung is not driven by G45
- P8860 G95-Modifikation  
 Byte 1  
     \$xx 0 G95 acquisition data concerning spindle data 1 (P11640)  
         1 - 8 G95 reference spindle from spindle data 1-8  
 Byte 2  
     \$xx 1 - 8 G95 acquisition data bezueghlich coupling data 1-8  
           (\* tooth number of masters / tooth number of Slave)
- P8861 Feed modification for not interpolated axes  
 Only effectively if P8893 < > 0;  
 0 or -- Axis feed concerning absolute feed P12122  
     1 Equal axis feed programmed path feed in the NC program  
     2 Axis feed equal programmed path feed proportion everything  
        in the NC Progroram more programmieter (not interpolated axes)  
        i.e.. Axis final positions are achieved at the same time.
- P8865 Channel-specific definition of the Overrides for interpolation rate  
 0 or -- Default Override 1 (1-8)  
         Observe:  
         Override Definitions in the axis data (P12125) are superordinate!
- P8866 Channel-specific definition of the Overrides for relative velocity  
 0 or -- Default Override 1 (1-8)  
         Observe:  
         Override Definitions in the axis data (P12126) are superordinate!
- P8867 Channel-specific definition of the Overrides for absolute speed  
 0 or -- Default Override 1 (1-8)

Note: Override Definitions in the axis data (P12127) are superordinate!

8.5 Standards channel parameters (continued)

Program controlling parameters

P8880 Axis change, switch on, switch off  
0 or -- Switched off  
1 Axis change on

If an axis change is switched on, the display position is exchanged.

Zero point shifts from G53 to G59 effect on the physical axes, they remain at the same physical axis at an axis change.

Zero point shift G92 and correction G44 effect on logical axes and are influenced therefore by the axis exchange.

P8881 Exchange the two physical axes  
Byte 1: on axis  
Byte 2: from axis  
Input of the logical axis numbers

Example: P8881 : \$0106  
P8882 : \$0601

i.e. axis change between axis 1 and axis 6

Programmed commands in the NC program for 1st axis are transmitted to 6th axis, for 6th axis are transmitted to 1st axis.

P8882 Axis change  
P8883 Axis change  
:  
P8889

**8.5 Standard channel parameters (continued)**

**Program controlling parameters**

P8890 Tangential axis  
 0 No tangential axis available in the channel  
 1-32 logical axis number  
 The here indicated axis becomes tangential the programmed path of the NC program adjusted.

P8891 Axis specific block locking  
 Bit 0 1 1st logical axis with axis-specific block locking  
  
 Bit 1 1 2nd logical axis  
 :  
 Bit 31 1 32nd logical axis

Function:  
 If the axis-specific block locking is selected, executing the NC program in the interpolator is stopped if axes should be moved which are selected with the axis-specific block locking.

P8892 Axis reflection  
 Parameter contains bit information  
 Bit 0 1 1. logical axis reflect  
 Bit 1 1 2. logical axis reflect  
 : :  
 Bit 31 1 32. logical axis reflect

Mode of operation:  
 One reflects around the actual machine position P12150.  
 Is modified thus the debit position P12151 of + < - > -;  
 and the indicator position P12154 of + < - > -;  
 e.g.. P12154: 150,0 P12154 becomes: -150.0  
 With programmed positive drive, the axis moves around this amount in negative direction.

Parameter is reset with each mode change after HAND.

**8.5 Standard channel parameters (continued)**

**Program controlling parameters**

P8893 Traverse axis not interpolating  
 Parameter with bit information

Bit 0	1	1st logical axis with axis-specific block locking
Bit 1	1	2nd logical axis
:		
Bit 31	1	32nd logical axis

Mode of operation:

During the processing of a NC program in the Interpolator, the setting axis becomes from the interpolation removes and parallel (as absolute position with feed P12122... or with progr. To path feed see P8861 driven).

At the NC end of record an exact stop requested waits the CNC to all axes (also the not interpolated) in position, or with not interpolated axes and programmed Vorposition P12113, this is achieved

Parameter is reset in each switching on check.

P8894 Axes reduct switch off  
 Parameter contains bit information

Bit 0	1	1. logical axis no Achsreduct
Bit 1	1	2. logical axis
:		
Bit 31	1	32nd logical axis

Mode of operation:

During processing of a NC program the axes indicated here become with the calculation of the feed dynamics (P8851) does not consider, or with programmed path feed (see P8861) proceed.

Parameter is reset in each switching on routine.

P8899 Bracket axis system modification (see P11830 etc..)

0	Path operation (display as programmed, to axes drive with bracket proportions)
1	Axis operation (drive display with bracket proportions, of axes as programmed)

## 8.5 Standard channel parameters (continued)

### Real time - Information block analysis

P8900	Actual program numbers of the NC - program
P8901	Actual block number of the NCS - program
P8904	Actual cycle number if cleared, no cycle active.
P8905	Actual block number in the cycle if cleared, no cycle active.
P8906	Actual program number when NC program is aborted - is loaded with the actual program number when NC program is aborted - is written 0 at program end with M30
P8907	Actual block number when NC program is aborted - is loaded with the actual program number when NC program is aborted - is written 0 at program end with M30
P8910	Faulty program - When the actual NC - program is aborted by the NC - interpreter (because of error message) the faulty program, which has led to the abort, is indicated here.
P8911	Faulty block - When the actual NC - program is aborted by the NC - interpreter (because of error message) the faulty block, which has led to the abort, is indicated here.
P8912	Actual sub-program plane
P8913	Actual sub-program call up, program number Here the actual program number is placed when switching to a sub-program.
P8914	Actual sub-program call up, block number Here the actual block number is placed when switching to a sub-program.
P8918	I
P8919	J
P8920	K
P8921	R
P8925	S1 programmed in NC - block
:	
P8932	S8 programmed in NC - block

8.5 Standard channel parameters (continued)

Real time - Information block analysis

P8934	Programmed loop counter	M24	
P8935	Actual loop counter	M24	
P8936	Programmed feedrate F		
P8937	Programmed block end feedrate		
P8938	Actual feed F (of the interpolator)		
P8940	Actual interpolation mode	G00 / G01 / G02 / G03	(to the PLC)
	0	G00	(PLC:G00_K1)
	1	G01	(PLC:G01_K1)
	2	G02	(PLC:G02_K1)
	3	G03	(PLC:G03_K1)
P8941	Programmed dwell	G04	[ s ]
P8942	Actual dwell	G04	[ s ]
	When running a dwell (G04) programmed in the NC - program, the remaining dwell is indicated here.		
P8943	Actual rotating direction circular axis	G05 / G06 / G07	
P8945	Actual polar coordinate programming	G10 / G11	
P8946	Actual contour programming	G12	
P8947	Actual tangential axis	G13 / G14	
P8948	Actual polar transformation	G15 / G16	
P8950	Actual interpolation plane	G17 / G18 / G19	
P8951	Axis 1		
P8952	Axis 2		
P8953	Axis 3		
P8958	Actual exact stop modal	G28 / G29	
P8964	Actual tool - radius - function	G40 / G41 / G42	
P8965	Actual axis correction	G43 / G44	
P8966	Actual rotating on / off	G45 / G46	
P8967	Actual co-ordinate system	G47 / G48 / G49	
P8968	Actual	G50 / G51 / G52	
P8969	Actual zero point	G53 .. G59	
	Content: G53 .. G59		(actual zero point - shift see P12155..)

**8.5 Standard channel parameters (continued)**

**Real time - information block analysis**

P8970	Actual reflecting on	G61
P8971	Actual reflecting on	G62
P8972	Actual feedrate 100%	G63 / G64
P8973	Actual	G65
P8974	Actual corrections switched off	G66
P8975	Actual	G67 / G68 / G69
P8978	Actual absolute/chain dimension	G90 / G91
P8979	Actual zero point - shift	G92
	Content: 0 no G92 - shift active	
	92 G92 - shift active	
P8880	Actual feedrate definition actually	G93 / G94 / G95
P8981	Actual number of revolution mode spindle	G96 / G97 / G98
P8982	Actual end feedrate	G99
P9080	Tool group number (T-No.)	
P9083	Tool Sub record (selected)	
P9090	Radius of the tool	
P9091	Length of the tool	
P9092	Radius correction	
P9093	Length correction	
P9094	Type of tool (active quadrant 0... 9)	

**Real time - data blocks**

P9100	Actual G92 shift 1st. axis	[mm]
P9101	Actual G92 shift 2nd. axis	
:		
P9131	Actual G92 shift 32nd. axis	
:		
:		
P9199		

8.5 Standard channel parameters (continued)

Preanalysis-information block of the block interpreter

P9300	Actual program numbers of the block interpreter	
P9301	Actual block number of the block interpreter	
P9303	Sub-program - plane	
P9304	Actual cycle number of the block interpreter If cleared, no cycle in the block interpreter.	
P9305	Actual block number in the cycle of the block interpreter If cleared, no cycle in the block interpreter.	
P9318	I	
P9319	J	
P9320	K	
P9325	S1	
:		
P9332	S8	
P9334	Loop depth M24	
P9336	Programmed feedrate F	
P9340	Type of interpolation programmed 0, 1, 2, 3, 50, 51, 52 Contents with program start      1	G00 / G01 / G02 / G03 G50 / G51 / G52
P9341	Retention time programmed	G04
P9343	Direction of rotation programmed round axis	G05 / G06 / G07
P9344	Programmed exact stop	G08 / G09
P9345	Polar coordinates programming programmed 10, 11 Contents with program start      11	G10 / G11
P9346	Outline path programming programmed	G12

**8.5 Standard channel parameters (continued)**

**Preanalysis-information block of the block interpreter**

P9350	Interpolation level programmed 17, 18, 19, 117 Contents with program start	17	G17 / G18 / G19 / G117
P9351	Axis 1 (1st principal axis)		contents of logical record number
P9352	Axis 2 (2nd principal axis)		contents of logical record number
P9353	Axis 3 (delivering axis)		contents of logical record number
P9358	Programmed exact stop modal 28, 29 Contents with program start	29	G28 / G29
P9364	Tool offset compensation programmed 40, 41, 42 Contents with program start	40	G40 / G41 / G42
P9365	Programmed axis correction 43, 44 Contents with program start	43	G43 / G44
P9366	Programming rotation in/out 45, 46 Contents with program start	46	G45 / G46
P9367	Programmed coordinate system 47, 48, 49, 147 Contents with program start	147	G47... G147
P9369	Programming actual zero point 53, 54, 55, 56, 57, 58, 59, 153, 154, 155... Contents with program start	53	G53... G159
P9370	Programming reflecting 60, 61 Contents with program start	60	G60 / G61
P9371	Programming reflecting 60, 62 Contents with program start	60	G60 / G62

8.5 Standard channel parameters (continued)

Preanalysis-information block of the block interpreter

P9372	Programmed feed 100% 63, 64 Contents with program start	60	G60 / G63 / G64
P9373	Programmed		G65
P9374	Programmed outlines switched off		G66
P9375	Programmed		G67 / G68 / G69
P9378	Programmed absolute measure/chaining absolute 90, 91 Contents with program start	90	G90 / G91
P9379	Zero shift programmed actively 0, 92 Contents with program start	0	G92

## 8.5 Standard channel parameters (continued)

### Preanalysis data blocks

P9500	Actual G92 shift 1st. axis	[mm]
P9501	Actual G92 shift 2nd. axis	
:		
P9531	Actual G92 shift 32nd. axis	
:		
:		
P9699		

## 8.5 Standard channel parameters (continued)

### Preanalysis NC-Block - informations

P9700	Programmed position	1st. Axis
:		
P9731	Programmed position	32nd. Axis
P9732	I	
P9733	J	
P9734	K	
P9735	R	
P9736	T	
P9739	F	
P9740	G-function	1
:		
P9747	G-function	8
P9748	G-function	enlargement field
P9750	M-function	1
P9761	M-function	1 enlargement field 1
P9762	M-function	1 enlargement field 2
:		
P9771	M-function	8
P9772	M-function	8 enlargement field 1
P9773	M-function	8 enlargement field 2
P9780	Speed	1
:		
P9787	Speed	8
P9800	Tool data - interface	
:	- Interface to the PLC	
:	- Actual spindle tool - data block	
:	- Actual active data block	
P9999		

## 8.6 System parameters

### Key - switch - information

The following parameters are copies of the key-switches.


P11000 Key - switch 1 (Info)  
0 : Switch open  
1 : Switch closed  
With the key - switch 1 the conduct of the starting routine is influenced.  
P11000 : 0 → ESR must be confirmed with pressing the key  
P11000 : 1 → ESR runs automatically, in so far as no errors appear.  
(e.g.: parameters def., or NC - memory def.)

P11001 Key - switch 2  
P11002 Key - switch 3  
P11003 Key - switch 4

P11008 Software locking 1  
0 not active  
1 active lockings activated according to P11018.

8.6 System parameters (continued)

Overall view parameter and NC memory barriers



**8.6 System parameters (continued)****Key - switch - definitions**

Definition, which locking is selected with the switch.

P11010 Key-switch 1 (see also P8510)  
Observe

With activated parameter barrier

- the parameter status is to be described nevertheless,
- the PLC can change nevertheless the parameter value.

Byte 1      Bit 0 parameter locking 1 (see also parameter status byte 3)  
              Bit 1 parameter locking 2 (see also parameter status byte 3)  
              Bit 2 parameter locking 3 (see also parameter status byte 3)  
              Bit 3 parameter locking 4 (see also parameter status byte 3)

Byte 2

Byte 3      Bit 0 NC memory locking  
              Bit 1 Cycle memory locking

Byte 4      Editing lockings of the MMI's  
              Bit 0 editing locking parameter mantissa  
              Bit 1 editing locking parameter status  
              Bit 2 editing locking axis / spindle / coupling data  
              Bit 3 editing locking zero point data  
              Bit 4 editing locking tool data  
              Bit 5 editor OFF locked

P11011 Key - switch 2

P11012 Key - switch 3

P11013 Key - switch 4

P11018 Software switch 1

## 8.6 System parameters (continued)

### Active lockings

P11020 0 Locking not active  
: 1 Locking active  
P11049

This area is updated with each modification of a key switch status and each mode change.

P11020 System - parameter - locking 1  
P11021 System - parameter - locking 2  
P11022 System - parameter - locking 3  
P11023 System - parameter - locking 4

P11036 NC memory locking  
P11037 Cycle memory locking

### Editing lockings of the MMI's


P11044 Editing locking parameter mantissa  
P11045 Editing locking parameter status  
P11046 Editing locking axis / spindle / coupling data  
P11047 Editing locking zero point data  
P11048 Editing locking tool data  
P11049 Editor OFF locked

8.6 System parameters (continued)

Definitions of the M - functions

Maximum 200 system overlapping M - functions are programmable (M000 . . . M199). If more than 200 M - functions are required, those must be defined channel specifically (to M999). 4 M - functions are defined per parameter. Input in hexadecimal!

Info for a M - function :



M-functions without stop are transmitted 'flying' to the PLC according to definition before traverse, after traverse or both. The NC - program runs continuously.



**8.6 System parameters (continued)**

M-functions with stop are transmitted to the PLC according to definition before traverse, after traverse or both. Axes run directly before the transfer of the M-function approach their end position with exact-stop. The NC-program sequence is stopped until the M -function is confirmed. The program pre analysis continues working. The confirmations are controlled in the PLC-program with enable block (SAFREK1). Therefore the corresponding marker of a M-function must be connected with stop with enable block.

M-functions with skip work always before traverse with stop! The traverse can be cleared at any time through the single - confirmation of the programmed M-function. When clearing the delay traverse, the measuring - position - parameters are written. In this case the NC program branches to the programmed skip target.

If the skip - M - function is not confirmed, the programmed NC - block is processed completely and switched on to the next block. Marker of a M - function with skip in the PLC may not be connected with enable block (SAFREK1).

M - Function as cycle. If this bit is set in the M - function - definition, no M -function code is sent to the PLC, but a cycle with the corresponding number is called up, i.e. M234 starts Z234.

At this definition the other definitions of this M - function are not considered (before traverse, after traverse or with skip).

The programmed M - function must be programmed without extension (e.g.: M1234.56 is not allowed). The cycle becomes active at the block end. The M - function number must be larger than 30!

Example:

P11051	\$	10	05	06	01
M - number		7	6	5	4

i.e.:

M07	with skip
M06	before traverse active, with stop
M05	after traverse active, with stop
M04	before traverse active, without stop

Note: Modifications in P11050... becomes with a mode change by HAND after AUTO effectively.

8.6 System parameters (continued)

Definitions of the M - functions

P11050M	03	02	01	00
P11051M	07	06	05	04
P11052M	11	10	09	08
P11053M	15	14	13	12
P11054M	19	18	17	16
P11055M	23	22	21	20
P11056M	27	26	25	24
P11057M	31	30	29	28
P11058M	35	34	33	32
P11059M	39	38	37	36
P11060M	43	42	41	40
P11061M	47	46	45	44
P11062M	51	50	49	48
P11063M	55	54	53	52
P11064M	59	58	57	56
P11065M	63	62	61	60
P11066M	67	66	65	64
P11067M	71	70	69	68
P11068M	75	74	73	72
P11069M	79	78	77	76
P11070M	83	82	81	80
P11071M	87	86	85	84
P11072M	91	90	89	88
P11073M	95	94	93	92
P11074M	99	98	97	96
P11075M	103	102	101	100
P11076M	107	106	105	104
P11077M	111	110	109	108
P11078M	115	114	113	112
P11079M	119	118	117	116
P11080M	123	122	121	120
P11081M	127	126	125	124
P11082M	131	130	129	128
P11083M	135	134	133	132
P11084M	139	138	137	136
P11085M	143	142	141	140
P11086M	147	146	145	144
P11087M	151	150	149	148
P11088M	155	154	153	152
P11089M	159	158	157	156
P11090M	163	162	161	160
P11091M	167	166	165	164
P11092M	171	170	169	168
P11093M	175	174	173	172
P11094M	179	178	177	176
P11095M	183	182	181	180
P11096M	187	186	185	184
P11097M	191	190	189	188
P11098M	195	194	193	192
P11099M	199	198	197	196

**8.6 System parameters (continued)****Internal oscilloscope**

P11100	Amount of active tracks	1 to 4	
P11101	Parameter address for track 1		
P11102	Parameter address for track 2		
P11103	Parameter address for track 3		
P11104	Parameter address for track 4		
P11110	Trigger track 1 to 4		
P11111	Trigger level		
P11112	Trigger slope		
	1	trigger on rising edge	
	-1	trigger on dropping edge	
	0	trigger immediately	
P11113	Scanning time		[ms]
P11114	Oscilloscope Start/Stop		
	0	stop	
	1	start	
	2	automatic new start	
P11115	Triggerpoint reached		
	0	not reached	
	1	reached	

8.6 System parameters (continued)

Graphics parameter

- P11120 Origin of the co-ordinate system screen X
- P11121 Origin of the co-ordinate system screen Y
- P11122 Origin of the co-ordinate system screen Z
- P11123 Zoom - size (P11123 small \_> drawn picture large)
  
- P11124 Graphics display
  - 0 X,Y - Plane
  - 1 Z,X - Plane
  - 2 Y,Z - Plane
  - 3 3-D
  
- P11125 X tilt
- P11126 Z tilt
- P11127 Forward / backward of the display
  
- P11128 Display bits
  - Byte 1
    - Bit 0 free
    - Bit 1 free
    - Bit 2 free
    - Bit 3 1 display with actual path
    - Bit 4 1 display with zero point
    - Bit 5 1 display with circle centre points
    - Bit 6 1 display with bores
    - Bit 7 1 display with direction arrows

**8.6 System parameters (continued)****System commands / informations**

- P11130 Selected language  
0 or -- 1st language  
1 2nd language  
: :
- P11131 Default language  
If the language text accord. to P11130 is not available, the default language is used.  
0 or -- 1st language  
1 2nd language  
: :
- P11132 Teachpanel operating mode  
0 or -- Teachpanel off  
1 Teachpanel switched on
- P11133 Teachpanel key pressed / unpressed  
Byte 1 Key code (see list from P11200 on)  
Byte 2 0 unpressed  
1 pressed  
Byte 3 Channel number 1..8
- P11134 LED's teachpanel (planned)
- P11135 Desired channel in MMI
- P11136 Selected channel in MMI


8.6 System parameters (continued)

System commands / information

P11137 Keyboard code pressed / unpressed (only CNC keys)  
(parameter is transmitted to the PLC)

- Byte 1 Key code
- Byte 2 0 unpressed  
1 pressed
- Byte 3 Channel number 1..8

Key code CNC keys



**8.6 System parameters (continued)**

**System commands / information**

P11138 LEDs 1..12 (bit information)

Byte 1	bit 0	0	LED key 40 out
		1	LED key 40 on
	bit 1		key 41
	bit 2		key 42
	bit 3		key 43
	bit 4		key 44
	bit 5		key 45
	bit 6		key 46
	bit 7		key 47
Byte 2	bit 0		key 48
	bit 1		key 49
	bit 2		key 50
	bit 3		key 51

P11139 LEDs (bit information) extended

Byte 1	bit 0	0	LED key 52 out
		1	LED key 52 on
	bit 1		key 53
	bit 2		key 54
	bit 3		key 55
	bit 4		key 56
	bit 5		key 57
	bit 6		key 58
	bit 7		key 59
Byte 2	bit 0		key 60
	bit 1		key 61
	bit 2		key 62
	bit 3		key 63

**8.6 System parameters (continued)****System - memory / Informations**

- P11140 Free NC memory
- P11141 Amount of NC programs
- P11142 Number of NC programs
- 
- P11145 Number of latest edited NC - program
- P11146 Number of latest edited NC - block
- 
- P11149 Display mode in the NC - directory  
0 There appears no Z - programs in the directory-list  
1 In the directory ALL programs are displayed.
- P11150 Display mode 2 in the NC-directory  
0 Display of the time stamp and file size  
1 Display of the 1st NC block
- P11152 First block number when numerating a NC program  
If not loaded, the first block number is 10.
- P11153 Block step width when numerating a NC program  
If not loaded, the step width is 10.
- 
- P11159 OVERLAY insertion in operating panel surface  
0 or -- Overlay operation reset  
1.. Overlay operation display

## 8.6 System parameters (continued)

### System - Clock

P11160 Second

P11161 Minute

P11162 Hour

P11163 Day

P11164 Month

P11165 Year

P11166 Weekday

P11169 100 ms timer parameter is incremented in stroke of 100 ms



8.6 System parameters (continued)

I/O circulation Interface 1

P11179 Block test character with I/O traffic

With P11179 the block test character is switched with I/O IN/COoutputs.

Method of operation: With activated block test character the data link becomes between operating console and external data terminal secured. practical in connection with the archiving program NCARC.EXE. The block test character is stored in no file, but in an educated manner from the sender / recipient to the real time in each case / checks.

0 or -- no block test character

I/O INPUT

The block test character of the data which can be read in is optional. If a block test character is received, it is checked.

With not correct test character:  
M1115 and abort of EA traffic.

I/O OUTPUT

no block test character with data output.

1 block test character activates

I/O INPUT

All read in data must with the block test character provided to be.

With missing test character:  
M1114 and abort of EA traffic

With not correct test character:  
M1115 and abort of EA traffic.

I/O OUTPUT

All data which can be output become with the block test character provide.

**8.6 System parameters (continued)**

**I/O circulation Interface 1**

- P11181 Parameter output mode  
Parameter is reset after each knocked against parameter output!
- 0 or -- Parameter EA output from parameter memory  
1 Parameter EA output from FLASH Memory  
output: D+, i.e. status are also settinged when rereading in  
5 Parameter EA output of all parameters from the parameter memory  
output: D+, i.e. status are also settinged when rereading in
- |        |     |       |  |
|--------|-----|-------|--|
| q0     | ... | q999  |  |
| q1000  | ... | q1999 |  |
| q2000  | ... | q...  | (number of axes)                           |
| P0     | ... | P5xxx | (user block 1aller of channels)            |
| P7000  | ... | P9999 | (fixed channel parameters of all channels) |
| P20000 | ... | P2xxx | (user block 2 of all channels)             |
- 10 output of the SAMPLE buffer (see also P11270...)  
15 output of the ZSM recordings (see P7950...)  
50 output of the oscilloscope memory  
output format: Fixed point (ulongs)
- P11183 Info. parameter  
actual program number EA input/output
- P11184 Info. parameter  
actual record number EA input/output

**8.6        System parameters (continued)**

**I/O circulation    Interface 2**

P11185    Interfaces 2    (planned)

:

P11199

8.6 System parameters (continued)

I/O circulation Information for diagnostic purposes

P11250 Error messages, which are entered into the error message history of the PLC  
i.e. each detailed error message.  
(parameter of the PLC is described)  
Byte 1 Message paragraph  
Byte 2 Message paragraph  
Byte 3 Channel number (1... 8)  
Byte 4 Axis paragraph (1... 32)

P11251

:


P11259 Actual pending error messages of the actually selected channel  
(parameter of the PLC is described)  
Byte 1 Message paragraph  
Byte 2 Message paragraph  
Byte 3 Channel number (1... 8)  
Byte 4 Axis paragraph (1... 32)

8.6 System parameters (continued)

Information for event logging for diagnostic purposes

P11260 Key information (parameter by the operating console one describes)  
total palpation printouts in this parameter are logged

Byte 1	Key paragraph or ASCII character	(CNC keys) (keyboard)
Byte 2 0	Key released	(only with CNC Keys)
1	Key pressed	
Byte 3 0		
Byte 4 0	Keyboard key	
1	Function key	
2	CNC Key	
3	Teachpanel key	



P11261 Bildname1 CNC Surface (parameter by the operating console one describes)  
Byte 1 CHAR 1  
Byte 2 CHAR 2  
Byte 3 CHAR 3  
Byte 4 CHAR 4

P11262 Bildname2 CNC Surface (parameter by the operating console one describes)  
Byte 1 CHAR 5  
Byte 2 CHAR 6  
Byte 3 CHAR 7  
Byte 4 CHAR 8

**8.6 System parameters (continued)****Event logging for diagnostic purposes**

- P11270 Activation of the recording ring buffer  
(in further Textals SAMPLE buffer marks)
- 0 Events are written into the SAMPLE buffer
  - 1 SAMPLE buffer is not no more described

With active SAMPLE buffer (P11270:0) all CNC Key generally always becomes presses and all messages (CNC messages P8500.. P8503 and SPS messages (P8509 or over P11263) as well as P11279 with a zeitmarke stored. Memory depth corresponds to 100 (083671 before index C) or 2000 (084564) Recordings.

The available recordings can over I/O circulation with parameter output to be read, if before the output the parameter output mode (P11181) = 10 one settings.

Starting from status 082 of 1.2.99

With a function call in the CNC DLL can this SAM polarizing ring buffer as section NC RAM to be specified.

The size of this buffer is freely definable. (number of Samples)

The available NC memory is reduced accordingly.

Contents of this static ring buffer remain after switching off that Controller preserve. (is with back-up battery like the NC memory)

8.6 System parameters (continued)

Event logging for diagnostic purposes

An output could look as follows:

---

SAM polarizing DATA

---

Output:

DATE: 1. 2,99 date / time-of-day of the output

Time: 02:12:57

# hh:mm:ss, ms cmd

1 00:00:00,000 ===== system boot =====

2 02:08:39,445 PICTURE: INIT picture change

3 02:08:42,455 PICTURE: A\_INIT picture change

33 02:11:55,650 C-KEY AX 1 CNC key axis selection 1

34 02:11:56,965 F-KEY F5 function key F5

35 02:11:58,525 KEY ' 1 ' PC key ' 1 '

42 02:12:00,655 F-KEY RETURN function key RETURN

43 02:12:01,290 F-KEY cursor V function key cursor

57 02:12:08,990 PARA CNC → PLC K0 q1137: 65822 Parameter transmitted by CNC at PLC

60 02:12:08,995 PARA CNC< —PLC K1 P8703: 1 parameter transmitted by PLC at CNC

97 02:12:13,820 K0 message: M3498 message M3498

448 02:12:21,015 PROG: K1 P1000 N11160 processing of NC block

449 02:12:21,015 PROG: K1 P1000 N11170

831 02:12:21,340 K1 M30 → PLC, NR in the Satz:0, without branch  
transfer of m functions at PLC

832 02:12:21,340 K1 END OF BLOCK CNC → PLC, CNC WAITS for acknowledgement

834 02:12:21,340 K1 CNC < — PLC SAFRE: 1

934 02:13:22,540 P11279: 12345 entry over P11279

---

SAM-POLARIZE-END

---



**8.6 System parameters (continued)**

**System diagnostic**

P11280	Activating the interface diagnostic		
	0	Interface diagnostic off	
	1	PLC <-> CNC interface diagnostic on	
	P11281...P11289	direction CNC → PLC	
	P11290...P11299	direction CNC ← PLC	
P11281	Event counter	CNC → PLC	
P11282	Channel number	CNC → PLC	
P11283	Parameter number	CNC → PLC	
P11284	Parameter content	CNC → PLC	
P11291	Event counter	CNC ← PLC	(q1160 is not indicated and not counted as event.)
P11292	Channel number	CNC ← PLC	
P11293	Parameter number	CNC ← PLC	
P11294	Parameter content	CNC ← PLC	

**8.6 System parameters (continued)**

**System data for Interpolator**

P11300 Interpolation nicety [ INC/mm ]  
 Specifies the internal path resolution at the Interpolator  
 0 preset: 10000  
 Input 100, 1000, 10000  
 In the case of a modification of this parameter the controller must again be started.

P11301 Position adjustment timer [ ms ]  
 In the case of a modification of this parameter the controller must again be started.

P11302 DSI timer [ ms ]  
 In the case of a modification of this parameter the controller must again be started.

P11305 Definition of the axis card off set  
 In the case of a modification of this parameter the controller must again be started.  
 This axis allocation can by means of P12003... for each axis separately and to be made axis-card-independently.

0 or -- physical axis numbering sequentially

Example:	1. Axis card	physical numbering
	ASM 1	1
	2	2
	3	3
	2. Axis card	
	AAZ4 1	4
	2	5
	3	6
	4	7

1 per card slot 4 physical axes are addressed

Example:	1. axis card	physical numbering
	ASM 1	1
	2	2
	3	3
	2. Axis card	
	AAZ4 1	5
	2	6
	3	7
	4	8

**8.6 System parameters (continued)**

**System data for Interpolator**

P11306 Definition for axis cards disable  
 In the case of a modification of this parameter the controller must again be started.  
 0 or -- physical axis numbering sequentially

Bit 0-31 No. of the respective slot  
 e.g.. 0x2 in slot 2 no card (AAZ, DAW, ADW) is detected

P11308 Input system

- 0 or -- Input system metrically
- 1 Input system inch, post-decimal positions around a position extends
- 2 Input system inch, post-decimal positions around two positions extends
- 3 Input system inch, post-decimal positions around three positions extends

**Inch switching**

With ' parameter reset ' in the switching on routine becomes

- in the zero point data array,
- all kanalgemappten Achsparametern, (P12153..12157...),
- the tool data interface, (P8110/11/12/13 and P8160/61/62/63),
- and the feed parameters in the channel

the inch bit in the parameter status settinged.

With the axis data of round axes no inch information is settinged. If one is linear axis without inch switching to be, then if the inch bit is to be removed in the q2x54.

After switching the system of units of INCH - > METRIC or METRIC - > INCH only these parameters become into respective the different one.

System of units converted, which the ZOLL bit in the parameter status settinged.

**Step-by-step operation:**

Incrementation table is preserved, however the actual incrementation becomes always over factor 10 reduces (see also G170 / G171).

P11309 System internal command parameter  
 Interpolator —> CNC  
 1 trigger for reference status

**8.6 System parameters (continued)**

**Override (1 - 9)**

The override allocation is defined depending on the traverse mode per axis (see P12125..).

General: From the operating panel the corresponding override value is written in P11311 (content : 0.. 255). P11311 is a procedure - parameter. In the started system sub-routine the override-schedule is accessed according to P11314 (pointer on table). The result is copied to P11310. P11310 is limited through P11312/P11313.

	Override 1		
P11310	Actual value	[%]	value from table
P11311	Actual value		from digital-to-analogue converter
P11312	Minimum limit	[%]	e.g. 0 %
P11313	Maximum limit	[%]	e.g. 120%
P11314	Pointer on override-table		
	If pointer on override-schedule is cleared or =0, the override is active continuously. Pointer-number shows on a q-parameter.		
P11315	Override 2		
P11320	Override 3		
P11325	Override 4		(Teachpanel)
P11330	Override 5		(fixed value 0%)
P11335	Override 6		(fixed value 10%)
P11340	Override 7		(fixed value 50%)
P11345	Override 8		(fixed value 100%)

## 8.6 System parameters (continued)

### Override (1 - 9)

P11370	Override-table	Amount: Preset 27 values
P11371	0 %	
P11372	1 %	
P11373	2 %	
P11374	5 %	
P11375	10 %	
P11376	15 %	
P11377	20 %	
:		
P11397	120 %	

**8.6 System parameters (continued)**

**Hand-wheels (1 - 8)**

P11400	Hand-wheel 1 Hand-wheel connected on axis	(physical axis number)
P11401	Hand-wheel works on axis	(physical axis number)
P11402	Activating the hand-wheel 0 or -- Hand-wheel not active 1 Hand-wheel active	
P11403	Hand-wheel resolution The pulses of the measuring system are quadrupled in the AAZ. Example: resolution 1000, At 1000 INC 1mm is driven. The sign determines the traverse direction.	[INC/mm]
P11404	Actual hand-wheel - multiplier With help of the hand-wheel - multiplier the hand wheel- pulses are multiplied. Example: P11404 = cleared or 0 or 1, 1000 INC -> 1mm distance P11404 = 10 1000 INC -> 10mm distance	
P11405	Switch to next multiplier 1 switch to next	
P11406	Pointer on multiplier, parameters is used from the system.	
P11407	Multiplier 1	
P11408	Multiplier 2	
P11409	Multiplier 3	
P11410	Hand-wheel 2	
:		
P11420	Hand-wheel 3	
:		
P11430	Hand-wheel 4	
:		
P11440	Hand-wheel 5	
:		
P11450	Hand-wheel 6	
:		
P11460	Hand-wheel 7	
:		
P11470	Hand-wheel 8	
:		

8.6 System parameters (continued)

Couplings (1 - 8)

	Coupling 1		
P11480	Master - axis	(physical axis number)	
P11481	Slave - axis	(physical axis number)	
P11482	Coupling mode		
	Byte 1	\$01 Machine coordinates coupling	
	Byte 2	\$01 Rigidity coupling	
	Byte 3	\$00 Type of status coupling	master <—> Slave
		\$01 Differential coupling	master —> Slave
P11483	Coupling modification		
	0 or --	Coupling correction on	
	1	Coupling correction off	
	2	Coupling correction off, however with coupling error control procedure actively	
P11484	Coupling error limit		[mm, degree]
P11485	Coupling error supervision time		[ms]
P11486	Coupling correction P share		[1/s]
P11487	coupling correction I share		[ms]
P11490	Synchronization position of the Masteraxis		[mm, degree]
P11491	Synchronization position of the Slaveaxis		[mm, degree]
P11492	Transmission ratio - relationship masteraxis		
P11493	Transmission ratio - relationship slave axis		
P11494	Differential constant		
P11495	Coupling on / off		
	1	Coupling on	(PLC:KOP1)
	2	Coupling synchronization on (see P11490 or P11491)	(PLC:KOPSYN1)
P11496	Coupling activated		
	1	Coupling on	
	2	Coupling synchronization accomplished	

**8.6 System parameters (continued)**

**Couplings (1 - 8)**

P11500 Coupling 2  
:  
P11520 Coupling 3  
:  
P11540 Coupling 4  
:  
P11560 Coupling 5  
:  
P11580 Coupling 6  
:  
P11600 Coupling 7  
:  
P11620 Coupling 8  
:

8.6 System parameters (continued)

Spindle (1 - 8)

Spindle 1

P11640	Spindle works on axis	(physical axis number)	
P11641	Reference axis for G96	(physical axis number)	
	If P11641 = 0, then reference position in P11642 is valid.		
P11642	Reference position for G96		[mm]
	e.g. grinding wheel diameter		
P11643	Reference factor for G96		[mm/min]
	0 or --	mm/min	
	1000	m/min	
P11644	Maximum speed for G96		[mm/min]
P11645	Maximum speed for G97		[rpm]
P11646	Reference factor for G97		[ rpm ]
	0 or --	rpm	
	1	degree/min	
P11647	Definition of speed	(G96, G97)	
	Presetting 0 = G97		
P11648	Programmed speed		[rpm or mm/min]
P11649	Actual speed		[rpm or mm/min]
P11650	Spindle in/out		
	0 or --	Spindle out	
	1	Positive direction of rotation	(PLC:SPIRE1)
	-1	Negative direction of rotation	(PLC:SPILI1)
	2	Positively spindle reset	(PLC:SPIRR1)
	-2	Negatively spindle reset	(PLC:SPIRL1)
P11651	Speed achieves or programmed speed = 0		
	0 or --	Speed does not achieve	
	1	Speed achieves	
		(becomes with prog. Speed = 0 not settinged)	(PLC:SPIDZE1)
	2	Spindle resetting position achieves	(PLC:SPIRPE1)

**8.6 System parameters (continued)****Spindle (1 - 8)**

P11652 Spindle resetting position

P11653 Speed monitoring tolerance limit [ % ]  
0 or -- actual speed monitoring switched off  
1... 100 i.e. P11651=1 achieves the info. speed  
setting if programmed speed equal actual speed  
and the deviation between actual speed (Messsystem) and  
smaller than the input value is appropriate for programmed speed.

P11660 Spindle 2

:

P11680 Spindle 3

:

P11700 Spindle 4

:

P11720 Spindle 5

:

P11740 Spindle 6

:

P11760 Spindle 7

:

P11780 Spindle 8

:

**8.6 System parameters (continued)**

**Data for Robot-system 1**

P11800 Linear axes (physical axis numbers)

At 5 axes transformation (Robot)  
e.g. the first 3 axes (X, Y, Z)

Byte 3, 2, 1 03 02 01 Hex  
Byte 4 direction change (Bit 3, 2, 1)

At 3 axes transformation  
e.g. the first 2 axes (X, Y)

Byte 3, 2, 1 00 02 01 Hex  
Byte 4 direction change (Bit 2, 1)

At 6 axes transformation  
e.g. the first 3 axes (X, Y, Z)

Byte 3, 2, 1 03 02 01 Hex  
Byte 4 direction change (Bit 3, 2, 1)

P11801 Robots rotation axes (physical axis numbers)

At 5 axes transformation (Robot)  
e.g. the 4th and 5th axes (A, B)

Byte 3, 2, 1 00 05 04 Hex  
Byte 4 direction change (Bit 3, 2, 1)

At 3 axes transformation  
e.g. the 3rd axis (A)

Byte 3, 2, 1 00 00 03 Hex  
Byte 4 direction change (Bit 1)

At 8 axes transformation (Robot)  
e.g. the 4th, 5th and sixth axes (A, B, C)

Byte 3, 2, 1 06 05 04 Hex  
Byte 4 direction change (Bit 3, 2, 1)

P11802 At 5 axes transformation (Robot)  
Offset x, rotation axis - tool axis [mm]

At 3 axes transformation  
Offset radius, tilt - tool peak [mm]

**8.6 System parameters (continued)****Data for Robot-system 1**

P11803	At 5 axes transformation (Robot) Offset y, rotation axis - tilt	[mm]
	At 3 axes transformation Offset angle, tilt - tool peak	[degree]
P11804	Offset z, tool carrier length	[mm]
P11805	Offset, tilt - tool axis	[mm]
P11806	Angle, rotation axis - tilt	[degree]
P11807	Angle, at which the tool is downwards	[degree]

## 8.6 System parameters (continued)

### Data for Robot-system 2

P11810	Robot linear axes To contents see P11800	(physical axis paragraphs)	
P11811	Robot rotation axes To contents see P11801	(physical axis paragraphs)	
P11812	Offset x To contents see P11802		[mm]
P11813	Offset y To contents see P11803		[mm]
P11814	Offset z To contents see P11804		[mm]
P11815	Offset, drag axis - tool axis To contents see P11805		[mm]
P11816	Angle, axis of rotation - drag axis To contents see P11806		[degrees]
P11817	Angle, with that the tool downwards shows To contents see P11807		[degrees]

**8.6 System parameters (continued)**

**Data for polar-system**

P11820	Polar axis		(physical axis number)	
	e.g. the first 2 axes (X, Y)			
	Byte 3, 2, 1	00 02 01	Hex	
	Byte 4		direction change (Bit 2, 1)	
P11821	Offset	r0		[mm]
P11822	Offset	w0		[mm]
P11823	Offset	v0		[mm]

8.6 System parameters (continued)

Data for angle system

P11830 Angle axes (physical axis paragraph)  
e.g. the first 2 axes (X, Y)  
Byte 3, 2, 1 00 02 01 Hex

P11831 Angle value [degrees]

**8.6 System parameters (continued)****Configuration parameters for robot systems**

P11850	Mechanics	
	\$0100	6-Achsen-Knickarm even
	\$0101	6-Achsen-Knickarm diagonally
	\$0200	3-Achsen-Scara
	\$0201	2-Achsen-Scara

P11852	Pendulum axis paragraph
P11853	Pendulum angle

**Geometry parameter of the respective robot system**

P11854	lever	1
P11855	lever	2
P11856	lever	3
P11857	hand	1
P11858	hand	2
P11859	hand	3

**8.6 System parameters (continued)****Parameter for joystick**

P11880 Joystick definition  
Byte 1 Calibration paragraph  
Byte 2 Slot paragraph

P11882 info. joystick calibration value  
P11883 info. joystick calibration value  
P11884 info. joystick calibration value  
P11885 info. joystick calibration value  
P11886 info. joystick calibration value  
P11887 info. joystick calibration value  
P11888 info. joystick calibration value  
P11889 info. joystick calibration value

**Parameter for welding seam tracing**

P11890 Pointer on table

**Parameter for Teachfunktion**

P11891 Pointer on table

**Parameter for external Robot simulation**

P11892 0 Connection off  
1 Connection with ROBOT actively

8.7 Axis parameters

Each physical axis occupies a parameter block of 200 parameters.

In the system has physical axis	the area	In the channel has logical axis	the area
1.	q2000 ... q2199,	1.	P12000 ... P12199,
2.	q2200 ... q2399,	2.	P12200 ... P12399,
3.	q2400 ... q2599,	3.	P12400 ... P12599,
4.	q2600 ... q2799,	4.	P12600 ... P12799,
5.	q2800 ... q2999,	5.	P12800 ... P12999,
6.	q3000 ... q3199,	6.	P13000 ... P13199,
7.	q3200 ... q3399,	7.	P13200 ... P13399,
8.	q3400 ... q3599,	8.	P13400 ... P13599,
9.	q3600 ... q3799,	9.	P13600 ... P13799,
10.	q3800 ... q3999,	10.	P13800 ... P13999,
11.	q4000 ... q4199,	11.	P14000 ... P14199,
12.	q4200 ... q4399,	12.	P14200 ... P14399,
13.	q4400 ... q4599,	13.	P14400 ... P14599,
14.	q4600 ... q4799,	14.	P14600 ... P14799,
15.	q4800 ... q4999,	15.	P14800 ... P14999,
16.	q5000 ... q5199,	16.	P15000 ... P15199,
17.	q5200 ... q5399,	17.	P15200 ... P15399,
18.	q5400 ... q5599,	18.	P15400 ... P15599,
19.	q5600 ... q5799,	19.	P15600 ... P15799,
20.	q5800 ... q5999,	20.	P15800 ... P15999,
21.	q6000 ... q6199,	21.	P16000 ... P16199,
22.	q6200 ... q6399,	22.	P16200 ... P16399,
23.	q6400 ... q6599,	23.	P16400 ... P16599,
24.	q6600 ... q6799,	24.	P16600 ... P16799,
25.	q6800 ... q6999,	25.	P16800 ... P16999,
26.	q7000 ... q7199,	26.	P17000 ... P17199,
27.	q7200 ... q7399,	27.	P17200 ... P17399,
28.	q7400 ... q7599,	28.	P17400 ... P17599,
29.	q7600 ... q7799,	29.	P17600 ... P17799,
30.	q7800 ... q7999,	30.	P17800 ... P17999,
31.	q8000 ... q8199,	31.	P18000 ... P18199,
32.	q8200 ... q8399	32.	P18200 ... P18399

In the channel descriptor physical axes are attached to the channel axes (q110 ... q141, Byte 3).

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

- P12000 Connected axis  
 0 or — axis not connected  
 1 axis connected  
 2 axis may not be driven, otherwise message seems M2020  
 -1 axis simulation, Messystem not necessarily,  
 Command value output according to actual axis rate,  
 point of reference taken.
- P12001 Round axis  
 0 or — no round axis  
 1 round axis  
 2 round axis drives shortest path  
 3 round axis drives pursuant to  
 G5 positively  
 G6 negatively  
 G7 shortest path
- P12002 Diameter axis  
 0 or — no diameter axis  
 1 diameter axis
- P12003 Axis module address  
 0 or — address recognition internally  
 Byte 1  
 \$xx axis paragraph 1,,8 (axis on the axis module)  
 Byte 2  
 \$xx slot paragraph 1... 32  
 Byte 3  
 \$xx drive address with Sercos Axes 1... 255  
 \$00 drive address equal axis paragraph

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

P12004 Maximum axis speed [mm/min, degree/min]  
 with Sercos axes transfer at final drive is affected as:  
 S-0-0091 speed limiting value bipolar

P12005 Slope speed 1 [mm/min, degree/min]  
 0 or — Slope rate = 10 % max. axis speed  
 to Slope to activate see P12136

P12006 Slope speed 2 [mm/min, degree/min]  
 0 or — Slope rate = 20 % max. axis rate  
 to Slope to activate see P12136

P12008 Machine dynamics 1 [ms]  
 0 or — default = 250 msec

The dynamics determine the time in that the axis of 0 on max axis rate one accelerates or one brakes. Always works with manual operation and automatic (G0). With Sercos axes the transfer to the final drive is affected as:  
 S-0-0138 acceleration bipolar,  
 S-0-0042 reference driving acceleration.

P12009 Machine dynamics 2 [ms]  
 0 or — default = dynamics 1  
 dynamics 2 > dynamics 1, then always work dynamics 2 with  
 path driving (G1, G2, G3, G50) not with G0.

P12010 Dynamic definition  
 0 or — linear axis acceleration drive.  
 1 sine axis acceleration drive.



**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

P12016 Exact stop boundary finely [ mm, degree ]  
 0 or — default = square root (1 / measuring system resolution)

Example: resolution scrutineer 1000  
 denominator 1  
 Default = sqrt (1 / (1000 / 1)) = 0,0316 mm

P12017 Exact stop boundary roughly [ mm, degree ]  
 0 or — default = 8 x exact stop boundary finely

Mode of operation: An axis starts a programmed position with exact stop, i.e. programmed position is achieved:  
 - lag distance (Sollpos being) is smaller than exact stop boundary gross, in such a way the drift correction is activated.  
 - lag distance is small exact stop boundary finely, in such a way the signal driving instruction (P12188) is reset.

P12018 Downtime monitoring [ ms ]  
 0 or — default = 3000 ms

If this monitoring time is exceeded, error message (M2022) is affected.

P12020 KV factor [ 1/s ]  
 0 or — default = 16 x 1/s

The KV factor is a valuation (p-proportion) the Lagereglung.  
 With Sercos Axes transfer at final drive is affected as:  
 S-0-0104 KV factor attitude control

P12021 P-reinforcement speed controlling device  
 0 or — default = speed regulation in the drive

With Sercos Axes transfer at final drive is affected as:  
 S-0-0100 p-proportion of speed controlling devices

P12022 I-reinforcement (reset time) [ ms ]  
 0 or — default = 10000ms (drift correction)

With Sercos axes transfer at final drive is affected as:  
 S-0-0101 i-proportion of speed controlling devices

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

P12024	Lag error limit 0 or — default = 50% over debit lag distance	[ % ]
	With the help of the axis speed and the KV's that can Lag distance to be calculated. $\text{Lag distance [ mm ]} = \text{feed [ mm/min ]} / (60 \times \text{KV [ 1/s ]})$	
P12025	Lag error limit monitoring time 0 or — default = 50ms -1 error limit monitoring switched off	[ ms ]
	If this lag is exceeded, error message (M2001) is affected	
P12026	Admissible command value output Around this monitoring to switch on P12026 must be > 0, and P12142 = 1. With achieving this lag is affected error message (M2002) and analog output = 0 settinged.	[ volts ]
P12027	Maximum command value output 0 or — default = 9,5V	[ volts ]
	Those max. output voltage is achieved, if these axis with max. axis speed drives.	
P12028	Command value output direction reversal 1 inverts	
P12029	Command value output axis exchange 0 command value output to this axis 1,,32 command value output to indicated axis (caution: Duplicate of axes avoid)	

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

P12030	Software limits positive; if cleared, no limit	[mm, degree]
P12031	Software limits negative; if cleared, no limit	[mm, degree]
P12032	Emergency - position absolute absolute measure, referred to machine zero point approach emergency position see P12131	[mm, degree]
P12033	Emergency - position relative relative measure, referred to machine-location approach emergency position see P12131	[mm, degree]
P12034	Basic position absolute absolute measure, in reference to machines - zero point approach to basic position see P12131	[mm, degree]
P12035	Basic position relative relative measure, referred to machine-location approach basic position see P12131	[mm, degree]
P12036	Fixed position absolute measure, referred to machine zero point approach fixed position see P12132	[mm, degree]
P12037	Pending position relative measure, referred to machine-location approach pending position see P12132	[mm, degree]
P12038	Dwell for pending position 1 0 or cleared                      Pending position 1 with exact stop approach pending position see P12132	[s]
P12039	Dwell for pending position 2 0 or cleared                      pending position 2 with exact stop approach pending position see P12132	[s]

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

P12040 Reference point offset [mm, degree]  
 When taking the reference points (e.g. in the moment of T0), the actual position (P12151) is loaded with P12040. This means if this axis is approached, the axis is standing on it's reference point.

P12041 Modulo measure [degree]  
 0 or -- Presetting 360°

P12042 Acceptable distance (reference switch - zero pulse) [mm, degree]  
 when exceeding -> error message

P12043 Reference distance (distance coded measuring system) [mm, degree]

P12044 Reference driving logic

Byte 1

- \$01 Release of the reference accommodation in positive driving direction (see also P12130, byte 1)

Byte 2

- \$01 Release of the reference accommodation in negative driving direction (see also P12130, byte 2)

Byte 3

- Bit0 0 with switch edge
- 1 with switch and nullimpuls
- Bit4 0 standard measuring system
- 1 2. Measuring system

Byte 4

- Bit0 0 switch positively switching
- 1 switch negatively switching
- Bit1 0 reference switch info. (P12180, byte 2) always actually
- 1 reference switch info. (P12180, byte 2) becomes after point of reference taken no more does not update.

Conditions for the reference accommodation

P12044 Byte3 Reference driving logic specify

P12079 Byte3 Sercos reference driving control parameter specify

P12130 starts reference accommodation,

Reference accommodation acknowledgement P12180,

so long reference travel actively,

- P12130 Byte 3 \$01 / PLC:REPOF1 = 1 reference position release  
 is the drive to be driven as follows

- adjusted without restarting

P12140 Byte 2 \$01 / PLC:NGOW1 = 1

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

P12045 Sensor logic  
 Byte 1  
     \$01: Release of measuring position accommodation in positive driving direction  
 Byte 2  
     \$01: Release of measuring position accommodation in negative driving direction  
  
 Byte 4  
     Bit0 0 switch edge positively effectively  
           1 switch edge negatively effectively  
     Bit4 0 standard pressure foot  
           1 2. Sensor

Conditions for the measuring position accommodation

P12045 Pressure foot logic specify  
 P12079 Byte4 Sercos sensor expensive parameter specify  
 P12082 Sercos sensor of 1 measuring pos parameter specify  
           (S-0-0130 (pos edge), S-0-0131 (neg edge))  
 P12084 Sercos sensor of 2 measuring pos parameters specify  
           (S-0-0132 (pos edge), S-0-0133 (neg edge))  
 P8716, P8717, P12131 start measuring accommodation with M26,  
 Measuring accommodation acknowledgement P8696, P12181  
 Measuring position P12152

P12046 Error logic  
 Byte 1  
     \$01 Wire break T0, T1, T2, inverted signals missing  
 Byte 2  
     \$01 UAS signal responded (interference, contamination)  
 Byte 3  
     \$01 Measuring system frequency too largely  
 Byte 4  
     \$01 Sercos messages actively

P12047 Emergency stop logic  
 Bit 0 - 31 According to axis 1 - 32  
           A emergency stop position (P12032, P12033) is started,  
           the axes indicated in P12046 are stopped.

## 8.7 Axis parameters (continued)

### Machine data for the 1st. axis

#### Drift correction

P12049	Drift correction (integral action time in P12022)
0	drift correction only in standstill
1	drift correction always active
2	drift correction switched off

8.7 Axis parameters (continued)

Machine data for the 1st. axis

P12050 Feed forward correction [%]  
0 or — Feed correction out

Example:

P12050:50% the actual lag distance is bisected  
P12050:100% the actual lag distance close zero  
i.e.. Axis drives error limits freely

P12051 Feed forward delay [ms]

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

lot correction

P12052 Backlash correction [ mm, degree ]  
 0 or — Backlash correction out

Input value is bisected for both driving directions  
 Example: Input 0.042mm  
 - Korrektur +0,021 with positive drive  
 - Korrektur -0,021 with negative drive

P12053 Backlash correction time [ ms ]  
 0 or — Backlash correction in P12052 works as static value  
 > 0 Backlash correction in P12052 works as dynmischer value  
 over the time after everyone, input in P12053  
 travel direction changes  
 < 0 Backlash correction in P12052 works as dynmischer value  
 over the time after everyone, input in P12053  
 start of a movement

**Correction dynamics**

This dynamics cause that modifications of the axis correction (backlash -, measuring system -, upward gradient correction) with this admissible dynamics to be executed.

P12055 Correction dynamics [ ms ]  
 0 or — default (machine dynamics 1 / 2)

**8.7 Axis parameters (continued)**

**Machine data for the 1st. axis**

Measuring system correction with 2. Measuring system

P12056 Measuring system correction datum axis (2. Measuring system)

Byte 1

\$xx 1 - 32 physical axis paragraph 2. Measuring system  
 2. Measuring system becomes by 1. Measuring system reports.  
 Debit 2. Measuring system reference system its,  
 so P12044 must: (byte 4, Bit4=1) to be settinged.  
 1. Measuring system becomes by 2. Measuring system reports.

Byte 2

\$xx: 1 - 32 physical axis paragraph 2. Measuring system  
 2. Measuring system as exchange axis,  
 i.e.. Messsytemposition (all axis positions)  
 2. Measuring system become on the 1. Measuring system  
 rerouted and displayed.

Byte 3

\$xx: 1 - 32 physical axis paragraph 2. Measuring system  
 2. Measuring system as scrutineer axis,  
 i.e.. Messsytem scrutineer 2. Measuring system  
 become on the 1. Measuring system rerouted.

Example of activation 2. Measuring system:

q 118: \$00060000 (6th axis log on)

P13001 if round axis

P13012, P13013, P13014 Messsystem resolution

P12057	Measuring system correction reset time	[ ms ]
	0 or — Correction off	
	> 0 Correction on	
P12058	Measuring system correction admissible correction	[ mm ]
	0 or — Default 10mm	

## 8.7 Axis parameters (continued)

### Machine data for the 1st. axis

Measuring system correction with 2. Measuring system

P12059 Measuring system correction with internal correction table  
0 or — Function not actively  
> 0 Measuring system correction with correction table  
Input of the distance of the corrections [ mm ]

Note: This function should be only activated, if those resolution 2. Measuring system more roughly is than the resolution too correcting axis.  
(axis for swinging would be lively)

In order to structure the correction table, must after the activation the axis uniquely from the negative software end position to the positive software end position to be moved.

**8.7 Axis parameters (continued)**

**Drive data for digital drives 1st. axis**

Pitch correction

P12060 Pitch correction pointer on table  
Parameter (q-NR.) where table starts.

P12061 Pitch correction number of corrections  
0 or — Correction out  
> 0 Correction

P12062 Pitch correction table offset  
Table access is permitted only with values of item between the end positions.  
Thus the table offset must become so in against that this applies.  
Offset = - (machine position (βt measured value) / distance of the corrections)  
Example: P12062: -6 = (P12150: 120,000) / P12063: 20,000

P12063 Pitch correction distance of the corrections [ mm ]

P12064 Pitch correction datum axis (interaxis correction, cross correction)  
Input physical axis paragraph

- 0 or — Correction algorithm uses the axis position (q2x50) the personal axis, over in the correction table the suitable to obtain steigungsfehler.
- 1... 32 Physical axis paragraph correction algorithm uses the axis position (q2x50) the datum axis, over in the correction table the suitable to obtain steigungsfehler.

Notes to the upward gradient correction:


To obtain if the machine position of the axis becomes larger than in the correction table covered correction area, the correction algorithm ‘interconnects’ start and end the correction table around the entsprechenden correction value, i.e.. Correction values repeat themselves.

Recurring corrections can so in a compact correction table to be stored. Start and end of the correction table should contain thereby the same values, since it can lead otherwise within this area to striking the axis.

8.7 Axis parameters (continued)

Drive data for digital drives 1st. axis

Example of pitch correction



Allocation of the parameters

				table	
Pointer on table	P12060	20000	>	parameter of values	q20000 0
Number of corrections	P12061	7			q20001 0,008
Table offset	P12062	2			q20002 0,012
Distance of the corrections	P12063	50 [ mm ]			q20003 0,02
					q20004 0,027
					q20005 0,032
					q20006 0,04

## 8.7 Axis parameters (continued)

### Drive data for Sercos

P12070	Sercos parameter ("S", "p")	*
P12071	Sercos parameter (record)	*
P12072	Sercos parameter (paragraph)	*
P12073	Sercos parameter (attribute)	*
P12074	Sercos parameter (value)	*
P12075	Sercos parameter (minimum)	*
P12076	Sercos parameter (maximum)	*

\* In the menu: parameter / axis - parameters / drive - parameter contents of all Sercos (s) - product (p) - know parameters over input - boxes, output - boxes to be displayed and changed.

8.7 Axis parameters (continued)

Drive data for Sercos

- P12078 Sercos drive operating modes (selection over P12144, byte 4)
- Byte 1 S-0-0032 main operating mode
    - \$02 Speed control
    - \$03 Position adjustment error limit-afflicted with generator 1(Motor)
    - \$04 Position adjustment error limit-afflicted with generator 2(Ext.)
    - \$0b Position adjustment error limit-free with generator 1(Motor)
    - \$0c Position adjustment error limit-free with generator 2(Ext.)
  
  - Byte 2 S-0-0033 type of subsidiary establishment 1
    - \$02 Speed control
    - \$03 Position adjustment error limit-afflicted with generator 1(Motor)
    - \$04 Position adjustment error limit-afflicted with generator 2(Ext.)
    - \$0b Position adjustment error limit-free with generator 1(Motor)
    - \$0c Position adjustment error limit-free with generator 2(Ext.)
  
  - Byte 3 S-0-0034 type of subsidiary establishment 2
    - \$xx: (planned)
  
  - Byte 4 S-0-0035 type of subsidiary establishment 3
    - \$xx: (planned)

8.7 Axis parameters (continued)

Drive data for Sercos

P12079 Sercos drive definitions

Byte 1

- Bit0 0 Position data in absolute absolute
- 1 Position data in modulo format
- Bit1 0 Speed data in m/min
- 1 Speed data in U/mim

Byte 2

- \$xx External measuring system (paragraph of the axis)

Byte 3

Sercos S-0-147 reference driving control parameter

- Bit0 0 Clockwise rotation of the motor shaft
- 1 Anti-clockwise turn of the motor shaft
- Bit3 0 Reference take with motor generator
- 1 Reference take with external generator
- Bit5 0 Reference switch is analysed
- 1 Reference switch is not analysed
- Bit6 0 Reference label is analysed
- 1 Reference label is not analysed
- Bit7 0 Any position after reference take
- 1 Point of reference after reference take

Byte 4

Sercos S-0-169 sensor control parameter

- Bit0 0 Positive edge sensor 1 is not analysed
- 1 Positive edge sensor 1 is analysed
- Bit1 0 Negative edge sensor 1 is not analysed
- 1 Negative edge sensor 1 is analysed
- Bit2 0 Positive edge sensor 2 is not analysed
- 1 Positive edge sensor 2 is analysed
- Bit3 0 Negative edge sensor 2 is not analysed
- 1 Negative edge sensor 2 is analysed
- Bit4 0 Position actual value to operating mode (S-0-0051/S-0-0053) referred
- 1 Position actual value always to S-0-0051 referred
- Bit5 0 Release individual measuring for sensor 1
- 1 Release subsequent measurement for sensor 1
- Bit6 0 Release individual measuring for sensor 2
- 1 Release subsequent measurement for sensor 2

**8.7 Axis parameters (continued)****Drive data for Sercos**

- P12080 Sercos phase switching (acknowledgement in P12081)  
0 Switching on phase  
2 Parameter mode  
4 Operating mode
- P12081 Sercos system status (acknowledgement of P12080) (PLC:SZSA\_01)  
\$E001 Sercos phase 0  
\$E002 Sercos phase 1  
\$E003 Sercos phase 2  
\$E004 Sercos phase 3  
\$E005 Sercos phase 4  
Sercos drives are ready for use,  
other values show entsprechende intermediates phase on
- P12082 Sercos cyclic actual value 3 request  
Paragraph by the Sercos parameter  
z.B.:130 (S-0-0130 measured value 1-positiv)
- P12083 Sercos cyclic actual value 3 acknowledgement  
Worth from Sercos parameter  
e.g.: Worth to the s-paragraph (S-0-0130 measured value 1-positiv),  
which over P12082 was called)
- P12084 Sercos cyclic actual value 4 request  
Paragraph by the Sercos parameter  
z.B.:84 (S-0-0084 torque actual value)
- P12085 Sercos cyclic actual value 4 acknowledgement  
Worth from Sercos parameter  
e.g.: Worth to the s-paragraph (S-0-0084 torque actual value)  
which over P12084 was called)
- P12089 Sercos speed standardisation  
0 or — Standart Sercos priority  
> 0 Relation between motor priority and load priority

**8.7 Axis parameters (continued)****Area monitoring axes**

## Area 1

- P12100 Channel paragraph  
0 or — P12101 and P12102 = q-parameter  
1-8 P12101 and P12102 = p-parameter
- P12101 Reference position  
Contents: Pointer on parameters  
0 or — Reference position = internal machine position (q2150)  
-2150 Reference position = internal machine position (q2150)  
-2152 Reference position = internal machine position (q2152)  
With the reference position (internal) are these positions immediately for the order, over parameters only time-delayed.
- P12102 Control position  
Contents: Pointer on parameters  
0 or — Monitoring logic not actively
- P12103 Area 1 relative related to P12101  
Acknowledgement achieves P12188 byte 2 = 1
- P12104 Area 2 relative related to P12101  
Acknowledgement achieves P12188 byte 3 = 1

**8.7 Axis parameters (continued)**

**Area monitoring axes**

Area 2

- P12105 Channel paragraph  
0 or — P12106 and P12107 = q-parameter  
1-8 P12106 and P12107 = p-parameter
  
- P12106 Reference position  
Contents: Pointer on parameters  
0 or — Reference position = internal machine position (q2150)  
-2150 Reference position = internal machine position (q2150)  
-2152 Reference position = internal machine position (q2152)  
With the reference position (internal) are these positions  
immediately for the order, over parameters only time-delayed.
  
- P12107 Control position  
Contents: Pointer on parameters  
0 or — Monitoring logic not actively
  
- P12108 Area 1 relative related to P12106  
Acknowledgement achieves P12189 byte 2 = 1
  
- P12109 Area 2 relative related to P12106  
Acknowledgement achieves P12189 byte 3 = 1


8.7 Axis parameters (continued)

Area monitoring axes

Area 2 relative related to P12106  
 Acknowledgement achieves P12189 byte 3 = 1

Example: Area monitoring 1. and 2. Axis

P12100	0	P12300	0
P12101	0	P12301	0
P12102	2350	P12302	2150
P12103	10	P12303	-10
P12104	20	P12304	-20



If axis 1 drives 2 from axis 2 into area, indicator K1BE1 is settinged  
 If axis drives 1 into area 1 from axis 2, indicator K1B1E1 is settinged  
 If machine pos. Axis 1 = machine pos. Axis 2 is settinged indicator K1B1

If axis drives 2 into area 2 from axis 1, indicator K1BE2 is settinged  
 If axis 2 drives 1 from axis 1 into area, indicator K1B1E2 is settinged  
 If machine pos. Axis 2 = machine pos. Axis 1 is settinged indicator K1B2

**8.7 Axis parameters (continued)**


**Axis commands / functions**

P12110	Axis position setting Display or debit position is settinged to input value. If parameter is reset, then old value is displayed.	[ mm, degree ]
P12111	Relative relative start Axis starts when describing. Feed in P12121 Override in P8866 or P12126 Acknowledgement achieves P12191=1 If P12111 reset P12191=0 An active relative positioning is aborted .	[ mm, degree ]
P12112	Absolute absolute start Axis starts when describing. Feed in P12122, Override in P8867 or P12127 Acknowledgement achieves P12192=1 If P12112 reset P12192=0 An active absolute positioning is aborted.	[ mm, degree ]
P12113	Absolute before position 0 or — Before position check not actively This before position can, with programmed not-interpolated axes (P8893) in the NC program and active exact stop (G8, G28) for premature step up of the active NC block to be used. With achieving these before position this is settinged in the parameter on zero, i.e. it is active only for a monitoring. Example: N100 G28 F100 X:100 N110 P12113:20 X200 N120 Y100 i.e. with drive into block N110 and path difference to Final position X200 < = P12113 is affected block changes after N120.	[ mm, degree ]

8.7 Axis parameters (continued)

Axis commands / functions

Example of a relative / an absolute absolute



8.7 Axis parameters (continued)

Axis commands / functions

P12114 Output skip  
Axis is moving with the input (speed) without dynamic (skip function) in the selected direction. Axis position is updated.

P12115 Output via output cards (AK, AEK)  
0 or — Not actively  
-1 i.e. the four signals become into those PLC Interface (see P12195) written.

Byte 1

\$xx 1-32 AK clip No. for this axis  
Axis drives over outputs of a AK, AEK per axis of 4 binary signals:  
example:  
Kl. 1 - drive positively  
Kl. 2 - drive negatively  
Kl. 3 - drive with max axis speed  
Kl. 4 - drive with Slope speed  
(settinged if indicator SLOP11 = 1)

Byte 2

\$xx: 1-32 slot No. of the AK -, AEK card

**8.7 Axis parameters (continued)****Axis commands / functions**

P12119	Handwheel speed 0 or — max. Axis speed	[ mm/min, degree/min ]
P12120	Interpolation speed 0 or — max. Axis speed	[ mm/min, degree/min ]
P12121	Relative velocity 0 or — max. Axis speed	[ mm/min, degree/min ]
P12122	Absolute speed 0 or — max. Axis speed	[ mm/min, degree/min ]
P12123	Fixed position speed 0 or — max. Axis speed	[ mm/min, degree/min ]
P12124	Spindle speed 0 or — max. Axis speed	[ degree/min ]

**8.7 Axis parameters (continued)****Axis commands / functions**

- P12125 Override with interpolation speed drive  
0 or — Default see P8865  
Otherwise Override paragraph 1-8
- P12126 Override with relative speed drive  
0 or — Default see P8866  
Otherwise Override paragraph 1-8
- P12127 Override with Absolute speed drive  
0 or — Default see P8867  
otherwise Override paragraph 1-8
- P12128 Override with fixedposition - speed drive  
Default = 1 contents Override paragraph 1-8
- P12129 Override at spindle speed drive  
Default = 2 contents Override paragraph 1-8

8.7 Axis parameters (continued)

Parameter block of PLC (Marker interface)

P12130 Approach reference position

Byte 1

- \$00 Stop of the positive reference drive (PLC: REPO+1)
- \$01 Start of the reference drive in positive direction.  
feed: Hand feed P8755  
back message achieves P12180

Byte 2

- \$00 Stop of the negative reference drive (PLC: REPO-1)
- \$01 Start of the reference drive in negative direction.  
feed: Hand feed P8755  
back message achieves P12180

Byte 3

- \$01 Reference position release (PLC: REPOF1)  
back message achieves P12180  
(see also P12044)  
note: If with one already referenzierten axis the reference position release is again settinged, the reference point reset. the axis can again be referenziert.

Byte 4

- \$01 Reference position setting (PLC: REPOS1)  
back message achieves P12180

## 8.7 Axis parameters (continued)

### Parameter block of PLC (Marker interface)

P12131 Approach measuring position

Byte 1

\$00	Stop of the positive measuring travel	(PLC: MEPO+1)
\$01	Start of the measuring drive in positive direction. feed: Hand feed P8755 back message started P12181	

Byte 2

\$00	Stop of the negative measuring drive	(PLC: MEPO-1)
\$01	Start of the measuring drive in negative direction. feed: Hand feed P8755 back message started P12181	

Byte 3

\$01	Measuring position release back message settinged P12181	(PLC: MEPOF1)
------	---	---------------

Byte 4

\$01	Measuring position setting back message settinged P12181	(PLC: MEPOS1)
------	---	---------------

**8.7 Axis parameters (continued)**

**Direction PLC → interpolator**

P12132 Approach emergency position, basic position

- |        |  |               |
|--------|--|---------------|
| Byte 1 | 0 Stop for emergency position absolutely achieve<br>1 Start for emergency position absolutely achieve  | (PLC: NOPOA1) |
|        | Position in P12032<br>Feed: max. axes speed<br>Override 100%<br>All other axes in the channel go on axis stop.<br>Back message achieves in P12182<br>When starting to that emergency position drive becomes those message M2000 settinged. |               |
| Byte 2 | 0 Stop for emergency position relatively achieve<br>1 Start for emergency position relatively achieve  | (PLC: NOPOR1) |
|        | Position in P12033<br>Feed: max. axes speed<br>Override 100%<br>All other axes in the channel go on axis stop.<br>Back message achieves in P12182<br>When starting to that emergency position drive becomes those message M2000 settinged. |               |
| Byte 3 | 0 Stop for reason of position absolutely achieve<br>1 Start for reason of position absolutely achieve  | (PLC: GRPOA1) |
|        | Position in P12034<br>Feed: max. axes speed<br>Back message achieves in P12182<br>Override P12128  |               |
| Byte 4 | 0 Stop for reason of position relatively achieve<br>1 Start for reason of position relatively achieve  | (PLC: GRPOR1) |
|        | Position in P12035<br>Feed: max. axes speed<br>Back message achieves in P12182<br>Override P12128  |               |

**8.7 Axis parameters (continued)****Direction PLC → interpolator**

P12133 Approach fixed position, pending position

Byte 1 0 Stop for approaching fixed position (PLC: FEPO1)

1 Start for approaching fixed position  
Position in P12036,  
Feed in P12123,  
Feedback reached in P12183

Byte 2 0 Stop for approaching pending position (PLC: PEPO1)

1 Start for approaching pending position  
Position in P12037,  
Feed in P12123  
Feedback reached in P12183

P12134 Drive spindle

Byte 1 0 Stop for driving spindle positive (PLC: SPE+1)

1 Start for driving spindle positive  
Speed in P12124,  
Feedback reached in P12184

Byte 2 0 Stop for driving spindle negative (PLC: SPE-1)

0 Stop for driving spindle negative  
1 Start for driving spindle negative  
Speed in P12124,  
Feedback reached in P12184

**8.7 Axis parameters (continued)**

**Direction PLC → interpolator**

P12135 End position reached

Byte 1 1 Positive hardware end position reached (PLC: EL+1)

Byte 2 1 Negative hardware end position reached (PLC: EL-1)

P12136 Slope

Byte 1 1 Activate slope 1 (PLC: SLOP11)  
 actual axis speed ≤ slope speed 1  
 slope speed in P12005

Byte 2 1 Activate slope 2 (PLC: SLOP21)  
 actual axis speed ≤ slope speed 2  
 slope speed in P12006

P12137 Drive locking / drive stop

Byte 1 1 Drive locking for positive direction (PLC: FASP+1)

Byte 2 1 Drive locking for negative direction (PLC: FASP-1)

Byte 3 0 Axis stops with dynamics function (axis stop) (PLC: FASOD1)  
 1 Axis stops without dynamics function (axis locking)  
 Dynamics in P12008, P12009

**8.7 Axis parameters (continued)****Direction PLC → interpolator**

P12138 Axis simulation

Byte 1 1 Simulation without output voltage (PLC: SIMMA1)  
i.e. the axis moves controlled (P12139) and  
the reference signal is simulated internally.

P12139 Axis controlled

Byte 1 1 Controlled with measuring system (PLC: GSMM1)  
i.e. the real axis position is carried internally.  
If controlled is cleared (positioning control on), this axis position is taken  
as actual position

Byte 2 1 Controlled without measuring system (PLC: GSOM1)

P12140 Axis updated (target = actual)

Byte 1 1 Updating with reapproaching the old position (PLC:NGMW1)

Byte 2 1 Updating without reapproaching (PLC: NGOW1)

P12141 Axis clamped

Byte 1 1 Clamping is switched on (PLC: GEKL1)  
i.e. no drive locking for axis;  
drift correction is switched off  
Axes output = 0 volts

**8.7 Axis parameters (continued)**

**Direction PLC → interpolator**

- P12142 Admissible output monitoring  
 0 or — Monitoring switched off  
 Around this monitoring to switch on must:  
 P12026 > 0, and P12142 = 1 its.  
 With achieving this boundary is affected error message (M2002)  
 and analog output = 0 is settinged.
- P12143 Relative positions separately announce  
 Byte 1 1 Relatively movements (P12111) are summed up in P12158.  
 Display position is preserved.  
 P12158 is reset when switching on on.  
 Byte 2 1 Handwheel movements are summed up in P12158
- P12144 Sercos drive control word (PLC - > Interpolator - > Sercos Drive)  
 Byte 1  
     \$00 drive off (PLC:ATEIN1)  
     \$01 drive on  
 Byte 2  
     \$00 no release (PLC:ATFRG1)  
     \$01 drive release  
 Byte3  
     \$00 drive stop (PLC:ATSTR1)  
     \$01 drive start  
 Byte4  
     \$00 selection head operating mode (PLC:ATBTR1)  
         (byte specifies 1) in P12078,  
         e.g.: Position of control with generator 1 drag errors freely  
     \$01 selection apart from operating mode 1  
         (byte specifies 2) in P12078,  
         e.g.: Speed control

**8.7 Axis parameters (continued)**

**Axis feedbacks / informations**

P12150	Machine position actual mechanical position of the axis	[mm, degree]
P12151	Target position position of the axis referred to the machine reference point G53	[mm, degree]
P12152	Actual position actual measuring position of the axes	[mm, degree]
P12153	Measuring position (display) stored display position at measuring signal (P8855) (Channel mapping) *	[mm, degree]
P12154	Display - position Display = target position - display shift (Channel mapping) *	[mm, degree]
P12155	Programmed position position programmed in the NC block (Channel mapping) *	[mm, degree]
P12156	Delta position Delta = programmed position - display position (Channel mapping) *	[mm, degree]
P12157	Display - shift Sum of all shifts (e.g. zero point, G92 shift, tool length) (Channel mapping) *	[mm, degree]

\* Channel mapping parameters are channel specific, i.e.. it does not exist a channel-spreading q-parameter. During the switching on routine becomes however the parameter status q-parameter into the parameter status of the p-parameter copies; i.e. is in a parameter with channel mapping the parameter status to be redefined, then this must in suitable status of the q-parameter are affected.

Example: P12153 is to be provided with 4 post-decimal positions  
           —> setting parameter status of q2153 with \$24xxxxxx

After restarting parameter status in P12153 corresponds the parameter status q2153

**8.7 Axis parameters (continued)****Axis feedbacks / information**

P12158	Position shift (e.g. handwheel-shift in Automatic)	[mm, degree]
P12159	Distance reference switch -> reference mark	[mm, degree]
P12160	Actual lag distance	[mm, degree]
P12161	Actual coupling correction	[mm, degree]
P12162	Actual drift correction	[mm, degree]
P12163	Actual backlash correction	[mm, degree]
P12164	Actual measuring system correction	[mm, degree]
P12165	Actual pitch correction	[mm, degree]

**8.7 Axis parameters (continued)****Axis feedbacks / information**

P12167	Command speed (regulator) Access with oscilloscope functions	[ mm, degree ]
P12168	Actual speed (measuring system) Access with oscilloscope functions	[ mm, degree ]
P12169	Actual output voltage of the position adjustment	[ V ]
P12170	Actual axis speed	[mm/min, degree/min]
P12171	Actual relative speed	[mm/min, degree/min]
P12172	Actual absolute speed	[mm/min, degree/min]
P12173	Actual fixed position speed	[mm/min, degree/min]
P12174	Actual spindle speed	[degree/min]

**8.7 Axis parameters (continued)**

**Axis feedbacks / information**

- P12176 ADW module Address  
Byte 1  
    \$xx ADW input Paragraph 1... 4  
        (selection of the A/D transducer on the ADW Module)  
Byte 2  
    \$xx slot paragraph 1... 32
- P12177 ADW Input value  
the A/D of transducer addressed in P12176  
Contents: [ 32767... -32768 ]
- P12178 DAW module address  
Byte 1  
    \$xx DAW output Paragraph 1... 4  
        (selection of the D/A transducer on the DAW module)  
Byte 2  
    \$xx slot paragraph 1... 32
- P12179 DAW output value [ V ]  
the D/A of transducer addressed in P12178  
Note:  
If P12178 does not specify, the DAW value becomes up  
the axis module of this axis output.

## 8.7 Axis parameters (continued)

### Parameter block to the PLC (marker interface)

P12180	Reference position		
	Byte 1 1	Reference point taken	(PLC: REF1)
	Byte 2 1	Switch, active edge going	(PLC: REFS1)
P12181	Measuring position		
	Byte 1 1	measuring position taken	(PLC: MEGT1)
	Byte 2 1	switch, active edge going	(PLC: MES1)
P12182	Emergency position, basic position reached		
	Byte 1 1	emergency position reached	(PLC: NOPOE1)
	Byte 3 1	Basic position reached	(PLC: GRPOE1)
P12183	Fixed position, pending position reached		
	Byte 1 1	fixed position reached	(PLC: FEPOE1)
	Byte 2 1	pending position reached	(PLC: PEPOE1)
P12184	Speed reached		
	Byte 1 1	speed reached	(PLC: DREZE1)
P12185	Software end position		
	Byte 1 1	positive software end position	(PLC: SWEL+1)
	Byte 2 1	negative software end position	(PLC: SWEL-1)

**8.7 Axis parameters (continued)**

**Parameter block to the PLC**

- P12186 Axis drives  
 Byte 1 (PLC: ACHFA1)  
 0 No axis specification  
 i.e.: Axis does not drive or axis builds the even lag distance off  
 1 Axis does not drive → axis specification / axis feed to zero  
 i.e.: Axis specifications are available.
- P12187 Driving instruction  
 0 No driving instruction pends  
 i.e.. - no verfahrweg for axis  
 - axis finds within exact stop  
 finely (P12016)  
 Byte 1 (PLC: FB+1)  
 1 Driving instruction for positive driving direction  
 (driving instruction remains pending, if e.g. in the drive path  
 the feed to zero becomes)  
 Byte 2 (PLC: FB-1)  
 1 Driving instruction for negative driving direction  
 (driving instruction remains pending, if e.g. in the drive path  
 the feed to zero becomes)  
 Byte 3  
 1 Axis drive actual actively  
 i.e. the even position actual which can be started yet does not achieve.
- P12188 Back message area monitoring axes area 1  
 Byte 1 1 Reference position (P12101) = control position (P12102) (PLC: K1E1)  
 Byte 2 1 Control position area 1 (P12103) achieves (PLC: K1B1E1)  
 Byte 3 1 Control position area 2 (P12104) achieves (PLC: K1BÈ1)
- P12189 Back message area monitoring axes area 2  
 Byte 1 1 Reference position (P12106) = control position (P12107) (PLC: KÈ1)  
 Byte 2 1 Control position area 1 (P12108) achieves (PLC: K2B1E1)  
 Byte 3 1 Control position area 2 (P12109) achieves (PLC: K2BÈ1)

8.7 Axis parameters (continued)

Parameter block to the PLC

P12191	Relative position achieves		
	Byte 1	1	Relative position achieves i.e.: Axis actual around the error limit from the target position removes.
			(PLC: REPOE1)
P12192	Absolute position achieves		
	Byte 1	1	Absolute position achieves i.e.: Axis actual around the error limit from the target position removes.
			(PLC: ABPOE1)
P12194	Sercos drive status (Sercos drive - > Interpolator - > PLC)		
	Byte 2	1	
		\$0000	Drive not yet ready for the performance power, there drive check not finally.
		\$0001	Drive ready for the performance power,
		\$0100	Drive actual ready for use and performance supply switched on, note: due to this back message are those to operate drive releases (P12144)
		\$0101	Drive actual ready for use, drive releases (P12144) are effective, drive output stage actual actively.
P12195	AK / AEK - outputs		
	Definition in P12115		
	Byte 1		
		\$01	drive in positive direction
	Byte 2		
		\$01	drive in negative direction
	Byte 3		
		\$01	drive with max. Axis speed
	Byte 4		
		\$01	drive with Slope speed

## 8.7 Axis parameters (continued)

### Parameter block to the PLC

P12197	Message number Message display for this axis e.g. M2110 approach reference position	(PLC: MELNR1)
P12198	Channel number Axis belongs to this channel (1...8)	(PLC: KANNR1)
P12199	Logicals axis number Axis has this logical number (1. ...32) in the channel	(PLC: LANA1)

**9. Messages**

9.1	Groups of messages	9 - 2
9.2	General CNC messages	9 - 3
9.3	Messages at input/output	9 - 4
9.4	Messages with the tools radius correction	9 - 6
9.5	Messages of the NC interpreter	9 - 7
9.6	Messages of the system	9 -12
9.7	Messages of the interpolator	9 -15
9.8	Messages of the PLC	9 -17
9.9	Messages of the operating panel	9 -18
9.10	Cycle messages	9 -21

**9.1 Groups of messages**

M1000 .. M1999	Messages of the CNC, block interpreter, I/O
M1150... M1199	Error off tool radius correction
M1950... M1999	SYSTEM error with the call by DLL Functions
M2000 .. M2999	Messages of the interpolator
M3000 .. M3999	Messages of the PLC
M3000 .. M3499	Global messages of the plant (i.e. channel overlapping)
M3000 .. M3249	Messages are indicated with gray writing on red ground
M3250 .. M3499	Messages are indicated with black writing on turquoise ground
M3500 .. M3999	Channel specific messages
M3500 .. M3749	Messages are indicated with gray writing on red ground
M3750 .. M3999	Messages are indicated with black writing on turquoise ground
M4000 ... M4999	Messages of the operating panel
M4000 ... M4499	BWO messages
M4000 ... M4299	DOS messages
M4300 ... M4399	Messages of the system
M4400 ... M4499	Messages of the MMI
M4500 ... M4999	free for the user
M5000 .. M7999	Reserved
M8000 .. M8999	Messages of cycles
M8000 .. M8499	Standard cycles
M8500 .. M8999	Free for users
M9000... M9999	Error message off CNC DLL
M9000... M9099	Reserves for BWO
M9100... M9999	Freely for users

**9.2 General CNC messages**

Message    Meaning

---

1000	Error when writing in Flash-memory P8505    Error code P8506    Channel number
1001	FLASH Function not executed
1002	No NC program in the Flash-memory
1008	Approach reference points
1009	Switching AUTO <—> POS not allowed Switching has to be done in MANUAL!
1050	Tool group not found in the tool data memory
1098	Error message when renumbering a NC program -> skip target is not available. The renumbering is not executed. Number of the NC block which has caused this message is written in P8505.
1099	Error message when renumbering a NC program -> indirect skip in NC memory available. Renumbering is not stopped, but this NC block is marked with the text 'warning'.

**9.3 Messages at input/output**

Message    Meaning

---

1100	Error in the test character or in the character number with the datentransfer between operating panel and CNC, i.e. the operating panel obtain on divergent Test character / file size as the CNC.
1102	No abort confirmation from the operating panel Each I/O-abort-confirmation-telegram (CNC → OP) has to be confirmed by the operating panel. If this is not the case, the message 1102 is
1105	Error when opening a program in the NC memory
1106	NC program becomes overwritten
1107	NC program is already existing and will not be overwritten
1110	Wrong file identification i.e.: the identification at the file start is not correct 'P' for NC programs 'D' for parameters 'B' for zero points Line number in P8505
1111	Line read can not be interpreted Line number in P8505  Reasons e.g.: - NC block does not start with block number - parameter line is damaged - preceding file has no end identification (#) - I/O parameter is not correct (Baudrate, parity ...)
1112	Invalid channel Reason: Read or write operations with channel parameters of which the channel does not exist.

**9.3 Messages at input/output (continued)**

Message Meaning

---

- 1113 Reception string overflow with I/O traffic (input)  
(max. character length of a line: 400)  
Read in string actual longer than reception s string.  
A cause: - It tried on false file format to read in (EXE, being file...)  
- Errors in the input file
- 1114 Reception string does not contain a test character
- 1115 Reception string contains false test character
- 1120 Memory space problem with the system down load  
(too little temporary memory (HEAP) available)
- 1121 Download software does not fit the hardware version of the CNC Card,  
e.g.. to charge it tried on BS902.xxx into a CNC Hardware 084564.
- 1122 Check total the loaded system software actual not correctly.  
- > file possibly damages  
- > problems while the loading.
- 1123 Check total the system software actual burned in the FLASH not correctly.  
- > file possibly damages  
- > hardware problem

**9.4 Messages with the tools radius correction**

Message Meaning

---

1151	Tool radius too largely
1152	Circle radius too small (message with stop)
1153	Tool radius correction error with ON/OFF drive
1154	G0 / G1 with tool radius correction not possibly
1155	G2 / G3 with tool radius correction not possibly
1156	With tool radius correction no intersection of the sets
1157	Too many blocks without path
1158	G12 not possible
1159	No path difference

**9.5 Messages of the NC interpreter**

Message    Meaning

---

1200	Coprocessor is missing
1201	Channel descriptor not valid
1202	Parameter number too large
1203	Division through zero
1207	Too many axes programs. Message only in the export version A cause: It is tried, in a block more axes to interpolate as certified. Error correction: Program fewer axes in the incorrect block.
1208	Too many parameters programmed in the block (max. 32)
1209	Too many bracket levels (maximum 10)
1210	Bracket is missing
1211	Syntax error
1212	Negative root
1213	Function can not be executed e.g. at        - logarithm-calculation - tan (90) ...
1214	No parameter operation
1215	Syntax error
1216	Unknown axis name
1217	Error at M25 The NC program contains on loop end (M25) without loop start (M24).
1218	Error at M24
1219	Errors at sub-routine call up
1220	Too many sub-routine call up

9.5 Messages of the NC interpreter (continued)

Message Meaning

---

1221	Parameters not loaded
1222	too many M - or G - or P - functions in a block programs
1223	<p>Error in the outline path                      In the case of NC program abort:                      A possible cause            tool radius actual too largely, in order to process outline.                      Error correction            Tool with smaller tool tools use.</p> <p>With NC program stop:                      Programmed outline radius actual smaller than the half chord. Radius is corrected.                      NC program can be started again.</p>
1224	Spindle not available
1225	No tool group defined
1226	<p>Geometry error                      possible reason: - at G12, G123 next block with travel is missing                                               - function G123 is programmed with M01</p>
1227	M - function number too large
1228	<p>M - function definition not correct                      - a M-function with skip target is in the NC program.                        M-Function is not defined as skip-M-function.                      - a M-function without skip target is in the NC program.                        M-Function is defined as skip-M-function.</p>
1229	<p>M1 is not allowed in this block                      e.g. it may not be synchronized if tool radius correction is switched on.</p>
1230	No feed was programmed for G01/02/03
1231	G02/G03 without path difference
1232	Not allowed combination of G or M function programmed in the NC block.
1233	Circular interpolation (G02/G03) programmed without R or I / J / K

---

**9.5 Messages of the NC interpreter (continued)**

Message    Meaning

---

1234	Programmed outline radius actual smaller than the half chord, i.e. with this programmed radius can the programmed terminator point not to be achieved. NC program is stopped. Radius is corrected. NC program can be started again.
1235	Spline not possible
1237	Circle dynamics, Error when calculating feed Reason: Acceptable path deviation (P8852) is larger than the programmed radius. Erasing the error: Reduce path deviation (P8852)
1238	Programmed centre point is not correct with programmed start and terminator point (see also P8843)
1240	No valid operation range defined (P8555) Message appears e.g. at zero point call up
1249	Invalid NC interpreter default Error correction: The following parameters check: Parameter P8830      Preset zero point Parameter P8853      Preset type of coordinate
1252	Program not found
1255	Block not found
1256	NC memory full
1257	Memory error in drip-feed-buffer Over - or underflow
1258	Memory error in drip-feed-buffer Faulty block synchronization when reading the buffer
1259	NC block with defective check sum

**9.5 Messages of the NC interpreter (continued)**

Message    Meaning

---

1260	Error when reading NC memory
1261	Error when writing in NC memory
1262	File not defined
1263	Program not found
1264	Program not opened for reading
1265	Program write-locked Interlocking through key-operated switch etc..
1266	NC program is locked Program is already opened for writing by an other user.
1267	Too many programs opened
1268	Circle buffer - overflow e.g. Drip-feed-buffer overflow
1269	Applied function is not supported at ring - buffer (Drip-feed-operation)
1270	Format error (The opened file is not a NC program)
1271	Faulty NC block e.g. 'N' is missing before the block number
1272	Error at access on the NC memory
1280	Directory chain of NC memory defective
1281	File chain of NC program defective
1283	System data for NC memory organization defective
1285	Blocks in the NC memory are double-chained
1290	NC blocks are not sorted (beginning with the small number and ending with the big one) P8505     old block number P8506     new block number





9.6 Messages of the system

Message Meaning

---

1800	Fatal error; System start again After sequence error - M1820 - M1830 - M1840
1810	Interface CNC → PLC: Data overflow During a parameter transfer to the PLC there was a data overflow. (floating decimal point format does not fit into the fixed point format, mantissa too largely) Information: Parameter number in P8505 (info. 1), channel in P8506 (info. 2)
1811	Parameter test character defectively If the channel 1 in the operating mode HAND is, becomes from the operating system in background constantly the total parameter area checks. Info.: Q-parameter number in P8505 (info. 1)
1815	Real time buffer overflow - faulty real time buffer administration or - faulty feedback of the interpolator
1816	Feed back buffer overflow - Feedbacks of the interpolator can not be processed any more.
1820	Floatingpoint exception Exception reason in P8505: Bit 0 : Inexact Bit 1 : Underflow Bit 2 : Overflow Bit 3 : Divide by Zero Bit 4 : Invalid operation Bit 5 : Unimplemented operation  System address in   P8506 Task-Id in           P8507

9.6 Messages of the system (continued)

Message Meaning

---

1830	NA signal became intermittently active After the message M1830 position adjustment may not be eingeschaltet any longer! (interlock in the PLC) No more NC programs may be started! Axis positions cannot be correct possibly. To start after the occurrence of of this error message actual the system again. (power OFF / on)	(NA: Power failure signal)
	A cause: Errors eliminate:	Cure-early mains voltage failure Mains voltage check Power supply unit check
1840	(F0)	General hardware error. Module or network failed. (see also at the operating panel under DIAGNOSIS system configuration)
1841	(F1)	Battery voltage is missing Causes: - Battery defectively - contact problems of the battery plug
1842	(F2)	±15V-Spannung is missing
1843	(F3)	Battery and ±15V-Spannung are missing
1844	(F4)	Processor fan defectively Caution: With defective fan overheating danger consists, there that processor on the CNC Module is no longer sufficiently cooled. an overheating of the CNC Processor leads to malfunctions or to complete failure of the system.

9.6 Messages of the system (continued)

Message Meaning

---

- 1950 DLL Function or subfunction missing  
Off the CNC DLL a function in the CNC CORE is called, which does not exist.  
Information: Info1 / P8505: Function code  
Info2 / P8506: Subfunction paragraph
- 1951 Invalid channel with function call  
Off the CNC DLL a function in the CNC CORE is called, also invalidly / illegal channel number  
Information: Info1 / P8505: Function code  
Info2 / P8506: Subfunction paragraph
- 1952 Invalid axis paragraph with function call  
Off the CNC DLL a function in the CNC CORE is called, also invalidly / illegal axis paragraph  
Information: Info1 / P8505: Function code  
Info2 / P8506: Subfunction paragraph

**9.7 Messages of the interpolator**

Message Maning

---

2001	Lag distance too large
2004	Measuring system signal is missing
2005	Measuring system UAS is missing
2006	Measuring system frequency too large
2007	Measuring system correction too large
2020	Axis can not be moved
2022	Axis not in position
2023	Coupling difference too large
2024	Reference distance too large
2050	Block buffer overflow in the interpolator
2052	Coordinate mode not defined Possible causes: <ul style="list-style-type: none"><li>- Type of coordinate does not specify, i.e. e.g. with the Robot system is missing to Robot definition in P11800</li><li>- When switching on of a type of coordinate (G48 on, G49...) are yet all axes involved does not report.</li></ul> Errors eliminate: <ul style="list-style-type: none"><li>- Type of coordinate specify</li><li>- Axes report</li></ul>
2101	Hardware end position +
2102	Hardware end position -
2103	Software end position +
2104	Software end position -

---

**9.7 Messages of the interpolator (continued)**

Message Meaning

---

- 2110 Approach reference position
- 2112 Approach measuring position
- 2114 Approach emergency position
- 2116 Approach basic position

**9.8 Messages of the PLC**

Message    Meaning

---

3000        Connection operating panel <-> CNC was interrupted  
             - Security stop of all axes is set

3501        Mode of operation change -> Automatic locked

3502        Mode of operation change -> Manual locked

**9.9 Messages of the operating panel**

Message    Meaning

---

Range 4000 .. 4299 are DOS error messages

4002	File not found
4003	Path not found
4004	Maximum number of files already opened (FILES=xx)
4005	File access refused
4006	Invalid file handle not defined or
4012	Invalid file mode
4015	Drive number not allowed
4016	Actual directory can not be cleared
4100	Error when reading the disc
4101	Error when storing on the disc
4102	File variable is not allocated to a file
4103	File is not opened
4104	File was not opened for reading operations
4105	File was not opened for storing operations
4106	Invalid numerical format

**9.9 Messages of the operating panel (continued)**

Message Meaning

---

4150	Disc is not write-locked
4151	Peripheral device unknown / not connected
4152	Drive not ready
4153	Invalid DOS function
4154	Check sum error when reading from the floppy / hard disc
4155	Invalid disc parameter block
4156	Head-positioning error on the floppy / hard disk
4157	Sector format unknown
4158	Disc sector can not be localised
4160	Write error when accessing a peripheral device
4161	Read error when accessing a peripheral device
4200	Division with zero
4201	Range test: error
4202	Stack test: overflow
4203	No more space in the Heap-range
4204	Invalid pointer operation
4205	Floating point overflow
4206	Floating point underflow
4207	Floating point error
4211	Program too deep

---

**9.9 Messages of the operating panel (continued)**

Message Meaning

---

Area 4300... 4399 messages of the operating system operating panel

4300 More than 400 programs in the directory (CNC: NCDATA \...). it cannot do all to be displayed.

4301 Operating panel Input SIO parity error

4302 Operating panel Input SIO Overrun error

4303 Operating panel Input SIO Framing error

4310 More than 1600 programs in the directory (CNC: NCDATA \...). it cannot do all to be displayed. (only on PC operating panel with driver CNC900X.EXE starting from 09.06.97.)

4390 Connection operating panel <-> CNC actual interrupted.  
No response of the CNC within Timeout.

Area 4400... 4499 messages of the control surface

4400 Control not in MANUAL

4401 Changeover to AUTO not made

4402 Graphics simulation not active

**9.10 Cycle messages**

Message    Meaning

---

8001	Geometry errors in the cycle This message appears when the control finds out that the pocket-contour can not be processed with the programmed tool data. E.g. P14 smaller than tool radius or tool radius = 0, or tool radius is not programmed.	(G71, 72, 73, 74, 75)
8003	Corner radius too small	
8004	Corner radius too big	
8005	Invalid tool radius	
8006	Sequence error	
8007	Pocket radius < tool radius	
8008	Pre-bore tool radius > pocket radius	
8009	In-feed > pocket depth (P13) - allowance on pocket depth (P18)	
8010	Invalid inner radius	(P11)
8011	Invalid 1st. pocket dimension	(P11)
8012	Invalid 2nd. pocket dimension	(P12)
8013	Invalid pocket depth	(P13)
8014	Invalid radius	(P14)
8015	Invalid allowance	(P15)
8016	Invalid in-feed	(P16)
8017	Invalid in-feed	(P17)
8018	Invalid allowance on pocket depth	(P18)
8019	Invalid safety allowance	(P19)
8020	Invalid fine-infeed	(P20)

---

**9.10 Cycle messages (continued)**

Message Meaning

---

8021	Invalid plange in feed	(P21)
8032	Invalid feed	(P32)
8033	Invalid drilling depth	(P33)
8034	Invalid preliminary stop plane	(P34)
8035	Invalid retraction plane on pocket depth	(P35)
8036	Invalid stroking rate	(P36)
8037	Invalid parameter for 1st. stroke	(P37)
8038	Invalid safety allowance	(P38)

**9.10 Cycle messages (continued)**Message Meaning

---

8100	Invalid X-coordinate X(AB)	(P100)
8101	Invalid Y-coordinate Y(AB)	(P101)
8103	Invalid angle (E1)	(P103)
8104	Invalid vector length (L1)	(P104)
8105	Invalid vector division (T1)	(P105)
8106	Invalid number of positionings (N1)	(P106)
8107	Vector division (T1) or number of positionings (N1) is missing	(P105) (P106)
8110	Invalid X-coordinate X(AC)	(P110)
8111	Invalid Y-coordinate Y(AC)	(P111)
8113	Invalid angle (E2)	(P113)
8114	Invalid vector length (L2)	(P114)
8115	Invalid vector division (T2)	(P115)
8116	Invalid number of bores (N2)	(P116)
8117	Vector division (T2) (P115) or number of positionings (N2) is missing	(P116)
8120	Invalid X-coordinate pitch circle centre point	(P120)
8121	Invalid Y-coordinate pitch circle centre point	(P121)
8122	Invalid pitch circle diameter (D)	(P122)
8123	Invalid starting angle (E)	(P123)
8124	Invalid travelling angle (L)	(P124)
8125	Invalid pitch angle (T)	(P125)
8126	Invalid number of bores (N)	(P126)



**9.10 Cycle messages (continued)**

Message Meaning

---

8300	No spindle speed programmed	(G81, G83, G84, G85)
8301	No spindle direction of rotation	(G81, G83, G84, G85)
8302	Spindle speed = 0	(G81, G83, G84, G85)
8303	Spindle speed not reached	(G81, G83, G84, G85)
8309	Oversized pitch dimension (T1) and number of positionings (N1)	(P105) (P106)
8310	Oversized vector division (T1) and final point B (Final point B is defined by X and Y coordinate (P101 and P102))	(P105)
8311	Oversized vector length (L1) and final point B (Final point B is defined by X and Y coordinate (P101 and P102))	(P104)
8313	Oversized vector length (L1) and vector part (T1)	(P104) (P105)
8315	Oversized vector division (T1) and number of positionings (N1)	(P105) (P106)
8316	Input number of positionings with 0	(P106)
8320	Oversized vector division (T2) and final point C (Final point C is defined by X and Y coordinate (P111 and P112))	(P115)
8321	Oversized vector length (L2) and final point C (Final point C is defined by X and Y coordinate (P111 and P112))	(P114)
8323	Oversized vector length (L2) and vector division (T2)	(P114) (P115)
8325	Oversized vector division (T2) and number of positionings (N2)	(P115) (P116)
8326	Input number of positionings with 0	(P116)

---

**9.10 Cycle messages (continued)**

Message    Meaning

---

8332	Wrong proportioned travelling angle L (P124) and pitch angle T (P125)	
8333	Oversized pitch angle T and number of positionings N	(P125) (P126)
8334	Indicate pitch angle with 0	(P125)
8335	Indicate pitch angle with 1	(P125)
8336	Indicate number of bores N with 0	(P126)
8337	Indicate number of bores N with 1	(P126)